

MONITOR

MTR-89

595-2508

Operation Manual

ZENITH
data systems





MONITOR

MTR-89

595-2508

ZENITH DATA SYSTEMS
SAINT JOSEPH, MICHIGAN 49085

Copyright © 1980
ZENITH DATA SYSTEMS
All Rights Reserved
Printed in the United States of America

Table of Contents

Introduction	3
Theory of Operation	4
Displaying and Altering Memory	6
Program Execution Control	8
Advanced Control	10
Floppy Boot	12
Switch SW501	14
Appendix A — MTR-89 Listing	15
Appendix B — Octal Definitions	96

INTRODUCTION

This Manual describes the functions and operation of the Z89 Monitor Program, MTR-89, that is contained in a read-only memory (ROM) in your Z89. Some of the major features of MTR-89 are:

- Memory contents display and alteration.

- Program execution control.

- Floppy diskette boot-strap routine.

In addition, MTR-89 can be instructed (by means of a flag byte maintained in read/write memory) to bypass some or all of its normal functions. In this manner, a sophisticated user can augment or replace these functions.

THEORY OF OPERATION

This section supplements the information in the “Operations” and “Circuit Description” sections of your Z89 Operations Manual. In order to use all of the features of MTR-89, it is necessary to understand the Z80 operation codes and the circuit of your Z89. This section gives you details of the operation of MTR-89. The listing of MTR-89 is given in Appendix A.

Power Up and Reset

MTR-89 initializes the Z89 whenever you power-up or RESET. To power-up, use the switch on the back of the Z89. To RESET, simultaneously press the RESET key and the right-hand SHIFT key on the keyboard. MTR-89 sounds the electronic “bell” and resets to its normal state. During the initialization procedure, MTR-89 determines the high limit of continuous RAM in your Z89. Once this high limit has been determined, the Z80’s stack pointer is set to this value. Then MTR-89 enters a loop waiting for you to enter a command.

Clock Interrupts

The Clock Interrupt is a crucial element in the operation of the Z89. It is a level one interrupt and is generated on the Z89 CPU board every 2 ms (millisecond). MTR-89 maintains “TICCNT” which counts up one every 2 ms. See the listing in Appendix A for the location of TICCNT.

Note that MTR-89 uses interrupts, so you should not disable interrupts for a long period of time. MTR-89 also requires a stack pointer at the top of memory with at least 80 bytes.

General Operations

When you RESET or power-up your Z89, MTR-89 responds by clearing the screen and displaying "H:". This tells you that it is ready to respond to your typed commands. When you type in something, MTR-89 will either accept it or give a beep, indicating an error.

If the letter you enter is the first letter of one of MTR-89's commands, it will display the remaining letters of the word. If the letter is not the start of a command, MTR-89 will sound the "bell" and ignore the letter.

The DELETE key will kill a partially entered line and cause MTR-89 to return to the "H:" prompt. You can use this to correct typing errors.

NOTE: In this manual, the symbol "Δ" means type a space and "Ⓢ" means type a RETURN.

The following is a list of the acceptable MTR-89 commands. You type the first letter of the command, and MTR-89 will supply the remainder of the word. You have to press the RETURN key before MTR-89 will respond.

TABLE OF MTR-89 COMMANDS

Substitute	— Display or alter memory.
Go	— Start a program
Program Counter	— Set an address in the PC
Boot	— Boot from a diskette

These commands are described in the remainder of this Manual.

DISPLAYING AND ALTERING MEMORY

One of the major features of MTR-89 is its ability to examine the contents of any Z89 memory location and to modify the contents of that location if it is in RAM.

The Substitute command is used to display memory locations. After a memory location has been displayed, its value can be changed before you proceed to something else. There is an example showing the Substitute procedure at the end of the description. You may jump ahead to it at any time.

To start the substitution process, first type "S". MTR-89 will respond by completing the word "Substitute". You should then enter the address of the memory location you want to inspect, followed by a RETURN. This address **must** be given in split-octal. Refer to Appendix B for the definitions of octal and split-octal.

MTR-89 will respond by re-displaying the address with leading zeros. Following the address, MTR-89 will display the contents of that memory location in octal.

Once the value of the memory location has been displayed, you may change it. To change it, simply type in the new value (in octal). The new value will be inserted after you complete the next step.

NOTE: MTR-89 will use the last three digits that you enter. That is, the entry "12345" will be entered as "345". You may use this to correct errors as entries are made.

After you have inspected or changed the value of a memory location, you have three options. First, you can cause MTR-89 to advance to the next memory location and display it by pressing the Space Bar. Second, you can cause MTR-89 to retrieve the previous memory location and display it by pressing the minus key, "-". Finally, you can cause MTR-89 to return to its initial "H:" by pressing the RETURN key.

The following example shows these features. To help you follow what you enter and what the computer responds, your entries and the computer's responses are shown on different lines. If a new line is really used, the new line will start at the left of the page. Otherwise, the output is shown just down a line.

EXAMPLE

H:		computer
S		you
ubstitute		computer
	2146 Ⓢ	you
002146 041		computer
	Δ	you
002147 011		computer
	Δ	you
002150 040		computer
	—	you
002147 011		computer
	Ⓢ	you
H:		computer
S		you
ubstitute		computer
	40100 Ⓢ	you
040100 xxx		computer
	123 Δ	you
040101 xxx		computer
	—	you
040100 123		computer
	Ⓢ	you
H:		computer

PROGRAM EXECUTION CONTROL

MTR-89 allows you to start a program that you have loaded into memory. It also offers a form of breakpointing.

The standard way of starting a program is to use the Go command. After you type in "G", MTR-89 responds "o". You should then type in the address (in split octal) where you want execution of your program to start. For example, if you have loaded a program at 040100, you can start it with:

```
H: Go 40100 @
```

MTR-89 allows another method of starting programs. MTR-89 maintains in its working memory a value for the Program Counter. If you enter "G" and then a RETURN after MTR-89 prints "o", MTR-89 will use the value in the PC as the starting address of your program.

To set the value in the Program Counter, you use the "P" command. After you enter "P", MTR-89 will respond "rogram Counter" and you can then enter the value you want. For example:

```
H: Program Counter 40100 @
```

```
H: Go @
```

Your program will now be started at 40100.

If you do not enter a value after "P", but simply press RETURN, then MTR-89 will display the current value of the PC on the next line. You can change the PC by typing in a new value or you can leave it un-altered by pressing RETURN. For example:

```
H: Program Counter @  
277377 40100 @
```

(You type the second number.)

When you are debugging an assembly language program, you can use MTR-89 to set breakpoints at various places in the program. To set a breakpoint, use the Substitute command and put an HLT (166 octal) instruction where you want your program to stop.

When your program reaches the breakpoint HLT instruction, it will return to MTR-89, display an "H", and then advance to a new line and display "H:". You can now use any of the MTR-89 commands.

To continue your program, you will first have to restore the byte in the location where you placed the breakpoint HLT. Since the computer had to execute the HLT instruction, the PC will point one beyond where you placed the HLT. To continue, you will have to decrease the PC value by one.

Do this by entering the "P" command and a RETURN. When the current value of the PC is shown, subtract one from it, and enter this value as the new value for the PC. Remember that you have to subtract in octal, so ten minus one is seven!

Alternatively, you can use the "Go" command to start the program from whatever address you want, including from the place where you put the HLT.

Note that if the program that you are debugging uses keyboard interrupts, MTR-89 and your program may "fight" for keyboard input! Your program will always see every character because it gets them by an interrupt. MTR-89 is continually testing if a character is available, and it will never see some of the characters that you enter.

ADVANCED CONTROL

One of the advanced features of MTR-89 is its provisions allowing sophisticated users to augment or replace MTR-89's functions. This is usually done in conjunction with assembly language programs, although it is sometimes possible to use these features in BASIC using the PEEK and POKE commands.

The following discussion refers to symbols and locations in MTR-89. In order to make the most of this information, you should refer to the listing of MTR-89 that is in Appendix A. Note that at the end of the listing the definitions of RAM locations from 40.000 to 40.077 and 41.120 to 41.125 are given. Following these is a symbol reference table that will help you find where symbols are used in the program.

The Tick Counter (TICCNT)

MTR-89 maintains in memory a 16-bit (2 byte) tick counter named TICCNT. This counter is incremented when the clock interrupts occur. As long as interrupts are enabled, this will occur every 2 ms. You may set TICCNT to any value and change it as often as you like. The low-order byte of TICCNT is in location 40.033 (8219 decimal) and the high-order byte is in 40.034.

Using Interrupts

All Z89 interrupts cause control to be transferred into the lowest 64 bytes of memory. Since MTR-89 occupies this area, it processes all interrupts first. Except for level zero interrupts (RESET function), you can supply a routine to process interrupts yourself.

Control is passed out of MTR-89 through the UIVECs (user interrupt vector) that are located at 40.037 and following. Each vector is three bytes long, and contains a JMP instruction to an interrupt processing routine. MTR-89 calls or jumps to the appropriate UIVEC, and control is passed to the processing routine. The exit from an interrupt processing routine should be the return instruction, RET.

I/O Interrupts

Interrupts numbered 3 through 7 are I/O interrupts of devices that you connect to your Z89. MTR-89 does not process these interrupts, but simply passes them on to a program in RAM by jumping to the appropriate UIVEC.

Zenith Data Systems software (except MTR-89) use interrupt 3 for input and output to and from the keyboard and screen. Additionally, interrupts 4 and 7 are reserved for certain applications. These programs set UIVEC themselves. If you want to use interrupts, your program has to place the appropriate jump in the appropriate UIVEC.

Clock Interrupts

The level one interrupt is generated by hardware in your Z89 every 2 ms. MTR-89 always processes these interrupts, but you can force it to pass control to your routine once it is done.

To do this, set the appropriate jump in the first UIVEC locations. Then set the UO.CLK bit (001) in .MFLAG (40.010). MTR-89 will then pass each clock interrupt to your routine when it finishes its own processing.

Single Instructions and Breakpoint Interrupts

Level two interrupts are generated by the single-instruction hardware contained in the Z89. When a single-instruction interrupt occurs, MTR-89 processes it, and jumps to the location specified by the second UIVEC.


If you have set up UIVEC for level two interrupts, you can use RST-2 as a breakpoint instruction. Control will be returned to the location specified by the second UIVEC.


FLOPPY BOOT

MTR-89 contains the code necessary to boot-up an operating system from a floppy disk. Two forms of "Boot" let you select the device (5-1/4" or Z47) and drive number (0-2 or 0-3). "Boot Primary" refers to the device that you will use most often. "Boot Secondary" provides you with a convenient way to boot from your alternate device, if you have one.

BOOT PRIMARY

The primary boot device is selected by switch SW501 sections 4, 1, and 0 on the CPU Logic Circuit Board. This switch is preset for 5-1/4" primary device. You may change the switch sections to select Z47 primary device.

H: Boot  Enter "B" and "RETURN"

H: Bootd  5-1/4" drive primary:


Enter "B"
and d(drive) = 0, 1, or 2
followed by "RETURN"


OR

Z47 primary:

Enter "B"
and d(drive) = 0, 1, 2, or 3
followed by "RETURN"

BOOT SECONDARY

H:Boot SD  Enter "B", "S", and "RETURN"

H:Boot SDd  5-1/4" secondary:

Enter "B" and "S"
and d(drive) = 0, 1, or 2
followed by "RETURN"

OR

Z47 secondary:

Enter "B" and "S"
and d(drive) = 0, 1, 2, or 3
followed by "RETURN"

Use the "DELETE" key to abort the boot command and return to the monitor.

ERRORS

The console will display a "?" if any of the following conditions occur:

1. The boot device does not respond within 15 seconds.
2. The "DELETE" key is pressed.
3. Switch SW501 section 2 is set to "0".
4. A disk error occurs.

SWITCH SW501

The sections of SW501 (on the Z89 CPU logic circuit board) have been redefined as follows:

SWITCH SECTION	DESCRIPTION
<u>7 6 5 4 3 2 1 0</u>	<u> </u>
X X X X X X 0 0	Port 174/177 = 5-1/4" drive
X X X X X X 0 1	Port 174/177 = Z47
X X X X 0 0 X X	Port 170/173 = unused
X X X X 0 1 X X	Port 170/173 = Z47
X X X 0 X X X X	Boot primary from port 174/177
X X X 1 X X X X	Boot primary from port 170/173
X X 0 X X X X X	Memory test
X X 1 X X X X X	Normal
X 0 X X X X X X	Baud = 9600
0 X X X X X X X	Normal

APPENDIX A

MTR-89 LISTING

This appendix contains a listing of MTR-89. It contains all the control for primitive keyboard input and screen output. MTR-89 needs RAM locations available in locations 40.000 to 40.077 and 41.120 to 41.125, and it also needs 80 bytes of stack area in high memory.

The first few pages of the listing show definitions that are used. The last portion of the listing contains references to the symbols that are used in MTR-89. Just before this cross reference listing is the definition of RAM locations in 40.000 through 40.077.

To allow compatibility with other hardware, the MTR-89 code is segmented throughout memory. The Memory Test entry point is 7.375 and the Floppy Speed Test (5-1/4" drive) entry point is 7.372.

MTR89 - H89 MONITOR #09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
 GE 1 15:27:17 28-MAY-80
 INTRODUCTION.

ISSUE 09.01.00

MTR89 - H89 MONITOR

MTR89 IS A MODIFICATION OF MTR88 BY REX CHEN IN MAY, 1980.
 MTR89 IS IDENTICAL TO THE MTR88 IN THAT ALL ENTRY POINTS TO
 THE CURRENT ROUTINES REMAIN UNCHANGED AND ALL ROUTINES
 REMAIN UNALTERED WITH THE FOLLOWING EXCEPTIONS:

- (1). ALL CODE WHICH SUPPORTS THE CASSETTE IS REMOVED.
 THIS INCLUDES THE LOAD ('L') AND DUMP ('D') COMMANDS
 AS WELL AS ALL OF THE DEVICE DRIVERS.
- (2). TYPE SPACES TO DETERMINE BAUD RATE. MESSAGE IS REMOVED.
- (3). THE BOOTSTRAP FOR THE Z-47 IS INSTALLED.
- (4). 15 SECONDS TIME OUT FOR Z-87, OR H-17 AND Z-47 IS INSERTED.
- (5). <DELETE> KEY SERVES AS AN ABORT-BOOT KEY.
- (6). ALLOWS BOOT FROM SELECT DEVICE AND UNIT.

MTR88 IS AN ADAPTATION OF PAM/8 ORIGINALLY WRITTEN FOR THE
 HEATH H8 COMPUTER BY J. G. LETWIN IN 1976 AND MODIFIED BY
 R. N. BORCHARDT IN 1979 FOR USE IN THE HEATH H88/H89
 COMPUTERS.

MTR88 PROVIDES COMPATIBILITY WITH PAM/8 SUCH THAT ALL ROUTINES
 HAVE RETAINED PREVIOUSLY DESCRIBED ENTRY POINTS AND ENTRY AND
 EXIT CONDITIONS. ROUTINES WHICH ARE NOT APPLICABLE SUCH AS
 THOSE PERTAINING TO THE FRONT PANEL DISPLAY HAVE BEEN DELETED.

COPYRIGHT 05/1976, WINTIEK CORPORATION
 902 N. 9TH ST.
 LAFAYETTE, IND.

COPYRIGHT 01/1979, HEATH COMPANY
 BENTON HARBOR, MI.

COPYRIGHT 05/1980, ZENITH DATA SYSTEMS INC.
 ST. JOSEPH, MI.

```

MTR89 - H89 MONITOR #09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
GE 2
INTRODUCTION. 15:27:17 28-MAY-80

000,001 42 .RAM, EQU 1
000,001 43
000,001 44 IF .RAM,
000,001 54 ENDIF

56 *** MTR88 - H88/H89 MONITOR.
57 *
58 * THIS PROGRAM RESIDES (IN ROM) IN THE LOW 2048 BYTES OF THE HEATH
59 * H88/H89 COMPUTERS.

61 *** INTERRUPTS.
62 *
63 * MTR88 IS THE PRIMARY PROCESSOR FOR ALL INTERRUPTS.
64 * THEY ARE PROCESSED AS FOLLOWS:
65 *
66 * RST USE
67 *
68 * 0 MASTER CLEAR. (NEVER USED FOR I/O OR RST)
69 *
70 * 1 CLOCK INTERRUPT. NORMALLY TAKEN BY MTR88,
71 * SETTING BIT #00,CLK* IN BYTE *,MFLAG* ALLOWS
72 * USER PROCESSING (VIA A JUMP THROUGH *UIVEEC*).
73 * UPON ENTRY OF THE USER ROUTINE, THE STACK
74 * CONTAINS:
75 * (STACK+0) = RETURN ADDRESS (TO MTR88)
76 * (STACK+2) = (STACKPTR+14)
77 * (STACK+4) = (AF)
78 * (STACK+6) = (BC)
79 * (STACK+8) = (DE)
80 * (STACK+10) = (HL)
81 * (STACK+12) = (PC)
82 * THE USER'S ROUTINE SHOULD RETURN TO MTR88 VIA
83 * A *RET* WITHOUT ENABLING INTERRUPTS.
84 *
85 * 2 SINGLE STEP INTERRUPTS RECEIVED WHEN IN
86 * USER MODE CAUSES A JUMP THROUGH *UIVEEC*+3.
87 * STACK UPON USER ROUTINE ENTRY:
88 * (STACK+0) = (STACKPTR+12)
89 * (STACK+2) = (AF)
90 * (STACK+4) = (BC)
91 * (STACK+6) = (DE)
92 * (STACK+8) = (HL)
93 * (STACK+10) = (PC)
94 * THE USER'S ROUTINE SHOULD HANDLE IT'S OWN RETURN
95 * FROM THE INTERRUPT.
96 *
97 *
98 * THE FOLLOWING INTERRUPTS ARE VECTORED DIRECTLY THROUGH *UIVEEC*.
99 * THE USER ROUTINE MUST HAVE SETUP A JUMP IN *UIVEEC* BEFORE ANY
100 * OF THESE INTERRUPTS MAY OCCUR.
101 *

```

MTR89 - H89 MONITOR *09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
05.....3.....
INTRODUCTION. 15:27:17 28-MAY-80

102 * 3 I/O 3. CAUSES A DIRECT JUMP THROUGH *UIVED*+6
103 *
104 * 4 I/O 4. CAUSES A DIRECT JUMP THROUGH *UIVED*+9
105 *
106 * 5 I/O 5. CAUSES A DIRECT JUMP THROUGH *UIVED*+12
107 *
108 * 6 I/O 6. CAUSES A DIRECT JUMP THROUGH *UIVED*+15
109 *
110 * 7 I/O 7. CAUSES A DIRECT JUMP THROUGH *UIVED*+18

112 ** ASSEMBLY CONSTANTS

114XTEXT.....MTR88.....DEFINE MTR88 OLD EQUATES

.....000,000.....

MT889 - H89 MONITOR #09.01.00.
 GE
 EQUATES FOR MTR88

Zenith Data Systems UNIX H8/H89 Cross Assembler PA
 15:27:18 28-MAY-80

```

117X **      IO PORTS
118X
119X ***      ALL REFERENCES TO THE H8 FRONT PANEL PORTS ARE TRAPPED BY THE
120X *      Z80 NMI OF THE H88/H89.  OP.CTL WILL STILL PERFORM AS IN AN H8
121X *      IN RESPECT TO THE CLOCK AND SINGLE STEP CONTROL.  FOR MORE
122X *      INFORMATION SEE THE NMI ROUTINE.
123X
000.360      124X IP.PAD EQU 360Q      PAD INPUT PORT
000.360      125X OP.CTL EQU 360Q      CONTROL OUTPUT PORT
000.360      126X OP.DIG EQU 360Q      DIGIT SELECT OUTPUT PORT
000.361      127X OP.SEG EQU 361Q      SEGMENT SELECT OUTPUT PORT
128X
129X *      H88/H89 CONTROL PORT
130X H88.CTL EQU 362Q
131X H88B.CK EQU 00000010B      H88/H89 PORT FOR CLOCK AND SINGLE STEP
132X H88B.SS EQU 00000001B      ZMS CLOCK ENABLE/DISABLE
                                SINGLE STEP ENABLE/DISABLE
133X
000.362      134X H88.SW EQU 362Q      8 POSITION DIP SWITCH
000.200      135X H88S.AT EQU 10000000B      AUTO ROOT SWITCH
000.100      136X H88S.BR EQU 01000000B      BAUD RATE SWITCH      **/RNC/**
000.040      137X H88S.M EQU 00100000B      MEMORY TEST/NORMAL OPERATION SWITCH
000.020      138X H88S.DV EQU 00010000B      = 0, ROOT FROM DEVICE AT 174-177Q
                                = 1, ROOT FROM DEVICE AT 170-173Q
                                = 00, NO DEVICE INSTALLED AT 170-173Q
                                = 01, DEVICE AT 170-173Q = 247
140X H88S.0 EQU 00001100B      = 00, DEVICE AT 174-177Q = H17
141X *      142X H88S.4 EQU 00000011B      = 01, DEVICE AT 174-177Q = 247
143X *
145X **      CASSETTE PORTS
146X
000.371      147X IP.TFC EQU 371Q      TAPE CONTROL IN
000.371      148X OP.TFC EQU 371Q      TAPE CONTROL OUT
000.370      149X IP.TFD EQU 370Q      TAPE DATA IN
000.370      150X OP.TFD EQU 370Q      TAPE DATA OUT
152X **      ASCII CHARACTERS.
153X
000.024      154X A.SYN EQU 024Q      SYNC CHARACTER
000.002      155X A.STX EQU 002Q      STX CHARACTER
000.007      156X A.BEL EQU 007Q      BELL CHARACTER
000.010      157X A.BKS EQU 010Q      BACKSPACE CHARACTER
000.012      158X A.LF EQU 012Q      LINE FEED CHARACTER
000.015      159X A.CR EQU 015Q      CARRIAGE RETURN CHARACTER
000.033      160X A.ESC EQU 033Q      ESCAPE CHARACTER
000.177      161X A.DEL EQU 177Q      DELETE OR RUBOUT CHARACTER

```

```

MTR89 - H89 MONITOR #09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
GE 5 15:27:18 28-MAY-80
EQUATES FOR MTR88

```

```

163X ** FRONT PANEL HARDWARE CONTROL BITS.
164X
000.020 165X CB.SSI EQU 00010000B SINGLE STEP INTERRUPT
000.040 166X CB.MTL EQU 00100000B MONITOR LIGHT
000.100 167X CB.CLI EQU 01000000B CLOCK INTERRUPT ENABLE
000.200 168X CB.SPK EQU 10000000B SPEAKER ENABLE

```

```

170X ** DISPLAY MODE FLAGS (IN *DSPMOD*)

```

```

171X
000.000 172X DM.MR EQU 0 MEMORY READ
000.001 173X DM.MW EQU 1 MEMORY WRITE
000.002 174X DM.RR EQU 2 REGISTER READ
000.003 175X DM.RW EQU 3 REGISTER WRITE

```

```

177X ** MACHINE INSTRUCTIONS.

```

```

178X
000.166 179X MI.HLT EQU 01101101B HALT
000.311 180X MI.RET EQU 11001001B RETURN
000.333 181X MI.IN EQU 11011011B INPUT
000.323 182X MI.OUT EQU 11010011B OUTPUT
000.072 183X MI.LDA EQU 00111010B LDA
000.346 184X MI.ANI EQU 11100110B ANI
000.021 185X MI.LXI.D EQU 00010001B LXI D
000.303 186X MI.JMP EQU 11000011B JMP
000.335 187X MI.LDXA EQU 11011101B LD IX, (BYTE A)
000.041 188X MI.LDXB EQU 00100001B LD IX, (BYTE B)
000.375 189X MI.LDVA EQU 11111101B LD IY, (BYTE A)
000.041 190X MI.LDVB EQU 00100001B LD IY, (BYTE B)
000.010 191X MI.EXAF EQU 00001000B EX AF,AF
000.335 192X MI.JIXA EQU 11011101B JP (IX) (BYTE A)
000.351 193X MI.JIXB EQU 11101001B JP (IX) (BYTE B)
000.375 194X MI.JIVA EQU 11111101B JP (IY) (BYTE A)
000.351 195X MI.JIVB EQU 11101001B JP (IY) (BYTE B)

```

```

197X ** USER OPTION BITS.

```

```

198X * THESE BITS ARE SET IN CELL .MFLAG.
199X *
200X
000.200 201X UO.HLT EQU 10000000B DISABLE HALT PROCESSING
000.100 202X UO.NFR EQU 00000000B NO REFRESH OF FRONT PANEL
000.002 203X UO.DDU EQU 00000010B DISABLE DISPLAY UPDATE
000.001 204X UO.CLK EQU 00000001B ALLOW PRIVATE INTERRUPT PROCESSING
000.000 205 XTEXT 247DEF DEFINE 247 EQUATES

```

MTK89 - HB9 MONITOR *09.01.00. Zenith Data Systems UNIX HB/H89 Cross Assembler PA
 GE EQUATES FOR Z47 15:27:19 28-MAY-80

```

208X *      DISK INTERFACE CONSTANTS
209X **
210X *
211X D.STA EQU 1700      INTERFACE STATUS PORT
212X D.DAT EQU D.STA+1  INTERFACE DATA PORT
213X *
214X S.ERR EQU 00000001B ERROR BIT
215X S.DON EQU 00100000B DONE
216X S.DTR EQU 10000000B DATA TRANSFER REQUEST
217X *
218X W.RES EQU 00000010B RESET COMMAND
219X *
220X **      CONTROLLER STATUS REGISTER
221X *
222X CS.UNR EQU 10000000B UNIT NOT READY
223X CS.WPD EQU 01000000B WRITE PROTECTED DRIVE
224X *
225X **      AUXILIARY STATUS REGISTER
226X *
227X AS.OID EQU 01000000B TRACK 0 DOUBLE DENSITY
228X AS.IID EQU 00100000B TRACK 1 - 76 DOUBLE DENSITY
229X AS.S1A EQU 00010000B SIDE 1 AVAILABLE
230X AS.S1W EQU 00000010B SECTOR LENGTH MASK
231X *
232X **      DISK COMMANDS
233X *
234X IC.BOOT EQU 0      BOOT
235X IC.KST EQU 1      READ CONTROLLER STATUS
236X IC.RAS EQU 2      READ AUX. STATUS
237X IC.LSC EQU 3      LOAD SECTOR COUNT
238X IC.RAD EQU 4      READ ADDR. OF LAST SECTOR ACCESSED
239X IC.REA EQU 5      READ SECTORS
240X IC.WRI EQU 6      WRITE SECTORS
241X IC.REAR EQU 7      READ SECTORS BUFFERED
242X IC.WRIE EQU 8      WRITE SECTORS BUFFERED
243X IC.WRD EQU 9      WRITE SECTORS & DELETE
244X IC.WRUB EQU 10     WRITE SECTORS BUFFERED & DELETE
245X IC.CPY EQU 11     COPY
246X IC.FRM0 EQU 12     FORMAT IBM SD
247X IC.FRM1 EQU 13     FORMAT IBM SD
248X IC.FRM2 EQU 14     FORMAT IBM DD
249X IC.FRM3 EQU 15     FORMAT IBM DD

```

MTR89 - H89 MONITOR #09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
GE 7 EQUATES FOR Z47 15:27:19 28-MAY-80

251X ** USEFUL FLAGS

252X *
000,000 UNIT 0 EQU 00000000B
000,040 UNIT 1 EQU 00100000B
000,100 UNIT 2 EQU 01000000B
000,140 UNIT 3 EQU 01100000B

257X *
001,000 SECTOR SIZE = 256 BYTES
000,200 SECTOR SIZE
000,000 EQUATES FOR H17 BOOT ROM

MTR89 - H89 MONITOR #09:01:00.
 GE 8
 H17 CONTROL INFORMATION

Zenith Data Systems UNIX H8/H89 Cross Assembler PA
 15:27:20 28-MAY-80

```

..... 263X **..... H17 CONTROL INFORMATION.....
264X .....
265X DP,DC EQU ..... Q7FH ..... DISK CONTROL PORT.....
266X .....
267X DF,HD EQU ..... 00000001B ..... HOLE DETECT.....
268X DF,TO EQU ..... 00000010B ..... TRACK 0 DETECT.....
269X DF,WF EQU ..... 00000100B ..... WRITE PROTECT.....
270X DF,SD EQU ..... 00001000B ..... SYNC DETECT.....
271X .....
272X DF,WG EQU ..... 00000001B ..... WRITE GATE ENABLE.....
273X DF,DS0 EQU ..... 00000010B ..... DRIVE SELECT 0.....
274X DF,DS1 EQU ..... 00000100B ..... DRIVE SELECT 1.....
275X DF,DS2 EQU ..... 00001000B ..... DRIVE SELECT 2.....
276X DF,MO EQU ..... 00010000B ..... MOTOR ON (BOTH DRIVES).....
277X DF,DI EQU ..... 00100000B ..... DIRECTION (0=OUT).....
278X DF,ST EQU ..... 01000000B ..... STEP COMMAND (ACTIVE HIGH).....
279X DF,WR EQU ..... 10000000B ..... WRITE ENABLE RAM.....
280X .....
281X .....
282X .....
283X **..... DISK UART PORTS AND CONTROL FLAGS.....
284X .....
285X UF,DF EQU ..... 07CH ..... DATA PORT.....
286X UF,FC EQU ..... 07DH ..... FILL CHARACTER.....
287X UF,ST EQU ..... 07EH ..... STATUS FLAGS.....
288X UF,SC EQU ..... 07EH ..... SYN CHARACTER (OUTPUT).....
289X UF,SR EQU ..... 07EH ..... SYNC RESET (INPUT).....
290X .....
291X UF,RDA EQU ..... 00000001B ..... RECEIVE DATA AVAILABLE.....
292X UF,ROR EQU ..... 00000010B ..... RECEIVER OVERRUN.....
293X UF,RPE EQU ..... 00000100B ..... RECEIVER PARITY ERROR.....
294X UF,FCT EQU ..... 01000000B ..... FILL CHAR TRANSMITTED.....
295X UF,TEH EQU ..... 10000000B ..... TRANSMITTER BUFFER EMPTY.....
296X .....
297X .....
298X .....
299X **..... CHARACTER DEFINITIONS.....
300X .....
301X C,PSYN EQU ..... 0F0H ..... PREFIX SYNC CHARACTER.....
302 XTEXT HOSEQ ..... HIOS EQUATES.....

```

MYR89 - HB9 MONITOR *09.01.00. Zenith Data Systems UNIX HB/HB9 Cross Assembler PA
 GE.....
 HDOS SYSTEM EQUATES 15:27:21 28-MAY-80

	305X **	HDOS SYSTEM EQUIVALENCES.
024.000	306X *	
025.000	307X	SYSTEM AREA FOR GRT0
026.000	308X S.GRT EQU	24000A
030.000	309X S.GRT1 EQU	25000A
	310X SECSCR EQU	26000A
	311X ROMROOT EQU	30000A
	312X	ROM ROOT ENTRY
040.100	313X	ORG 40100A
	314X	FREE SPACE FROM FAM-8
040.100	315X	JUMP TO SYSTEM EXIT
040.110	316X D.CON DS	8
040.130	317X SYDD EQU	16
040.130	318X D.VEC DS	24*3
040.240	319X D.RAM DS	31
040.277	320X S.VAL DS	36
040.343	321X S.INT DS	115
041.126	322X DS	16
041.146	323X S.SOVR DS	2
041.150	324X DS	42200A-*
001.032	325X STACKL EQU	*-S.SOVR
	326X	STACK SIZE
042.200	327X STACK EQU	* LWAT1 SYSTEM STACK
042.200	328X USERFWA EQU	* USER FWA
042.200	329	MISCELLANEOUS EQUATES FOR H17 ROOT ROM

```

MTRB9 - HB9 MONITOR #09.01.00.
GE 10
MISCELLANEOUS EQUATES FORM H17 ROM CODE
Zenith Data Systems UNIX HB/HB9 Cross Assembler PA
15:27:22 28-MAY-80

036.235
036.271
000.130
037.132
030.252
000.037
031.212
041.061
040.037
034.031
033.366
034.077
040.206
036.073
034.027
000.012
040.264
042.200

332X ** MISCELLANEOUS EQUATES FROM H17 BOOT ROM.
333X * REFER TO H17 BOOT ROM IF MORE INFORMATION DESIRED
334X WHD EQU 36235A
335X WNH EQU 36271A
337X
338X BOOTAL EQU 130A
339X BOOTB EQU 37132A
340X $MOVE EQU 30252A
341X D.RAML EQU 370
342X $ZERO EQU 31212A
343X AIO.UNI EQU 41061A
344X .UIVEC EQU 40037A
345X CLOCK17 EQU 34031A
346X R.ABORT EQU 33666A
347X R.READ EQU 34077A
348X D.SUP EQU 40206A
349X SUP3 EQU 36073A
350X EXIT EQU 34027A
351X ERPTCNT EQU 120
352X D.DECNT EQU 40264A
353
DEFINE 8251 USART BITS

```

MTR89 - H89 MONITOR #09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
 GE 11 15:27:23 28-MAY-80
 B251 USART BIT DEFINITIONS.

```

356X **      8251 USART BIT DEFINITIONS.
357X *
358X
359X **      PORT ADDRESSES
360X
000.000      EQU 0      DATA REGISTER IS EVEN
000.001      EQU 1      STATUS REGISTER IS NEXT
000.372      EQU 372R    CONSOLE USART ADDRESS (IFF 8251)
364X
365X
366X
367X **      MODE INSTRUCTION CONTROL BITS.
368X
000.100      EQU 01000000B 1 STOP BIT
000.200      EQU 10000000B 1 1/2 STOP BITS
000.300      EQU 11000000B 2 STOP BITS
000.040      EQU 00100000B EVEN PARITY
000.020      EQU 00010000B USE PARITY
000.000      EQU 00000000B 5 BIT CHARACTERS
000.004      EQU 00000100B 6 BIT CHARACTERS
000.010      EQU 00000100B 7 BIT CHARACTERS
000.014      EQU 00000100B 8 BIT CHARACTERS
000.001      EQU 00000001B CLOCK X 1
000.002      EQU 00000010B CLOCK X 16
000.003      EQU 00000011B CLOCK X 64
381X
382X **      COMMAND INSTRUCTION BITS.
383X
000.100      EQU 01000000B INTERNAL RESET
000.040      EQU 00100000B READER-ON CONTROL FLAG
000.020      EQU 00010000B ERROR RESET
000.004      EQU 00000100B RECEIVE ENABLE
000.002      EQU 00000010B ENABLE INTERRUPTS FLAG
000.001      EQU 00000001B TRANSMIT ENABLE
390X
391X **      STATUS READ COMMAND BITS.
392X
000.040      EQU 00100000B FRAMING ERROR
000.020      EQU 00010000B OVERRUN ERROR
000.010      EQU 00001000B PARITY ERROR
000.004      EQU 00000100B TRANSMITTER EMPTY
000.002      EQU 00000010B RECEIVER READY
000.001      EQU 00000001B TRANSMITTER READY
042.200      XTEXT  U8250
  
```

MT6889 - H89 MONITOR \$09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
 GE 12
 8250 UART CONTROL BITS 15:27:24 28-MAY-80

```

000.350 402X **      8250 UART CONTROL AND BIT DEFINITIONS.
000.156 403X
000.000 404X SC.ACE EQU 350R      SYSTEM CONSOLE PORT. IF 8250 ACE
000.000 405X AC.DLY EQU 110     220 MIL. SEC. DELAY FOR 8250
000.000 406X
000.000 407X UR.RBR EQU 0       RECEIVER BUFFER REGISTER (READ ONLY)
000.000 408X
000.000 409X UR.THR EQU 0       TRANSMITTER HOLDING REGISTER (WRITE ONLY)
000.000 410X
000.000 411X UR.DLL EQU 0       DIVISOR LATCH (LEAST SIGNIFICANT)
000.001 412X
000.001 413X UR.DLM EQU 1       DIVISOR LATCH (MOST SIGNIFICANT)
000.001 414X
000.001 415X UR.IER EQU 1       INTERRUPT ENABLE REGISTER
000.002 416X UC.EDIA EQU 00000001B  ENABLE RECEIVED DATA AVAILABLE INTERRUPT
000.004 417X UC.TRE EQU 00000100B  ENABLE TRANSMIT HOLD REGISTER EMPTY INTERRUPT
000.004 418X UC.RSI EQU 00000100B  ENABLE RECEIVE STATUS INTERRUPT
000.010 419X UC.MSI EQU 00001000B  ENABLE MODEM STATUS INTERRUPT
000.002 420X
000.001 421X UR.IIR EQU 2       INTERRUPT IDENTIFICATION REGISTER
000.006 422X UC.IIF EQU 00000001B  INVERTED INTERRUPT PENDING (0 MEANS PENDING)
000.006 423X UC.IID EQU 00000110B  INTERRUPT ID
000.003 424X
000.000 425X UR.LCK EQU 3       LINE CONTROL REGISTER
000.000 426X UC.5BW EQU 00000000B  5 BIT WORDS
000.001 427X UC.6BW EQU 00000001B  6 BIT WORDS
000.002 428X UC.7BW EQU 00000010B  7 BIT WORDS
000.003 429X UC.8BW EQU 00000011B  8 BIT WORDS
000.004 430X UC.2SR EQU 00000100B  TWO STOP BITS SELECTED
000.010 431X UC.PEN EQU 00001000B  PARITY COMPUTATION ENABLED
000.020 432X UC.EPS EQU 00010000B  EVEN PARITY SELECT
000.040 433X UC.SKP EQU 00100000B  STICK PARITY
000.100 434X UC.SB EQU 01000000B  SET BREAK
000.200 435X UC.DLA EQU 10000000B  DIVISOR LATCH ACCESS
000.004 436X
000.001 437X UR.MCR EQU 4       MODEM CONTROL REGISTER
000.002 438X UC.ITS EQU 00000001B  DATA TERMINAL READY
000.004 439X UC.RTS EQU 00000010B  REQUEST TO SEND
000.010 440X UC.OU1 EQU 00000100B  OUT 1
000.020 441X UC.OU2 EQU 00001000B  OUT 2
000.020 442X UC.LOO EQU 00010000B  LOOP
000.005 443X
000.001 444X UR.LSR EQU 5       LINE STATUS REGISTER
000.002 445X UC.DR EQU 00000001B  DATA READY
000.004 446X UC.OR EQU 00000010B  OVERRUN
000.010 447X UC.FE EQU 00000100B  PARITY ERROR
000.020 448X UC.FR EQU 00001000B  FRAMING ERROR
000.040 449X UC.BI EQU 00010000B  BREAK INTERRUPT
000.100 450X UC.THE EQU 00100000B  TRANSMITTER HOLDING REGISTER EMPTY
000.100 451X UC.TSE EQU 01000000B  TRANSMITTER SHIFT REGISTER EMPTY
000.006 452X
000.001 453X UR.MSR EQU 6       MODEM STATUS REGISTER
000.002 454X UC.PCS EQU 00000001B  DELTA CLEAR TO SEND
000.004 455X UC.DDR EQU 00000010B  DELTA DATA SET READY
000.004 456X UC.TER EQU 00000100B  TRAILING EDGE OF RING
000.010 457X UC.DRL EQU 00001000B  DELTA RECEIVE LINE SIGNAL DETECT

```

MTB89 - HB9 MONITOR #09:01:00: Zenith Data Systems UNIX HB/HB9 Cross Assembler PA
GE 13
8250 UART CONTROL BITS 15:27:25 28-MAY-80

000.020	458X UC.CTS	000100000B	CLEAR TO SEND
000.040	459X UC.DSR	001000000B	DATA SET READY
000.100	460X UC.RI	010000000B	RING INDICATOR
000.200	461X UC.RLS	100000000B	RECEIVED LINE SIGNAL DETECT

```

MTR89 - H89 MONITOR 09.01.00.
GE 14
HARDWARE INTERRUPT VECTORS
Zenith Data Systems UNIX H8/H89 Cross Assembler PA
15:27:25 28-MAY-80

```

```

464 *** INTERRUPT VECTORS.
465 *
466

```

```

468 ** LEVEL 0 - RESET
469 *
470 * THIS 'INTERRUPT' MAY NOT BE PROCESSED BY A USER PROGRAM.
471

```

```

472 IF ,RAM,
484 ELSE
485 ORG 00A
486 ENDIF

```

```

487 INIT0 JMP INIT0X DO H88 EXTENSION OF INITIALIZATION
488 INIT0.0 LXI H88RAM+FRSL-1 (HL) = RAM DESTINATION FOR CODE
489 INIT
490

```

```

491 IF ,RAM,
492 ELSE
493 ERRPL INIT-1000A BYTE IN WORD 10A MUST BE 0
494
495 ENDIF
496

```

```

498 ** LEVEL 1 - CLOCK
499
500 IF ,RAM,

```

```

502 ELSE
503 INT1 EQU 100 INTERRUPT ENTRY POINT
504
505 ERRNZ *-110 INTO TAKES UP ONE BYTE
506 ENDIF
507

```

```

508 CALL SAVALL SAVE USER REGISTERS
509 MVI D+0
510 JMP CLOCK PROCESS CLOCK INTERRUPT
511 IF ,RAM,
512 ELSE
513 ERRPL CLOCK-1000A EXTRA BYTE MUST BE 0
514 ENDIF

```

```

516 ** LEVEL 2 - SINGLE STEP
517 *

```

```

518 * IF THIS INTERRUPT IS RECEIVED WHEN NOT IN MONITOR MODE,
519 * THEN IT IS ASSUMED TO BE GENERATED BY A USER PROGRAM.
520 * (SINGLE STEPPING OR BREAKPOINTING). IN SUCH CASE, THE
521 * USER PROGRAM IS ENTERED THROUGH (U1VEC+3)
522

```

```

523 IF ,RAM,
525 ELSE
526 INT2 EQU 20A LEVEL 2 ENTRY

```

```

MTR89 - H89 MONITOR #09.01.00.      Zenith Data Systems UNIX H8/H89 Cross Assembler  PA
GE 15                                15:27:26 28-MAY-80
HARDWARE INTERRUPT VECTORS

```

DEFINITION 4.2. (HARDWARE INTERRUPT VECTORS)

527	000.000	ERNZ	*-21A	INTI TAKES EXTRA BYTE
528		ENDIF		
529				
530				
531	000.021	CALL	SAVALL	SAVE REGISTERS
532	000.024	LDAX		(A) = (CTLFLG)
533	040.011	SET	CTLFLG	
534	000.025	JMP	STPTRN	STEP RETURN

```

536 ***      I/O INTERRUPT VECTORS.
537 *
538 *      INTERRUPTS 3 THROUGH 7 ARE AVAILABLE FOR GENERAL I/O USE.
539 *
540 *      THESE INTERRUPTS ARE NOT SUPPORTED BY MTR88, AND SHOULD
541 *      NEVER OCCUR UNLESS THE USER HAS SUPPLIED HANDLER ROUTINES.
542 *      (THROUGH UIVEC)

```

```

543 .....
544 ..... IF ,RAM.
545 ..... ELSE
546 ..... ORG 30A
547 ..... ENDIF
548 .....
549 ..... JUMP TO USER ROUTINE
550 .....
551 ..... DB '44440'
552 ..... HEALTH.PART.NUMBER.444-40

```

```

553.....
554      IF          ,RAM,
555      ELSE
556      ORG         40A
557      ENDIF
558
559      JMF         UIVECT?      JUMP TO USER ROUTINE
560
561      DB          44Q,122Q,116Q,102R,44Q... SUPPORT CODE

```

```

563.....
564.....          IF          .RAM.
565.....          ELSE
566.....          ORG          50A
567.....          ENDIF
568.....
569.....          JMP          UIVECH12      JUMP TO USER ROUTINE
570.....
571.....
572.....          DLY - DELAY TIME INTERVAL.
573.....
574.....          ENTRY      (A) = MILLISECOND DELAY COUNT/2
575.....          EXIT
576.....          USES      A,F

```

NTR89 - H89 MONITOR #09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
 GE 16
 HARDWARE INTERRUPT VECTORS 15:27:27 28-MAY-80

```

000.001      577      IF      .RAM.
              578      ELSE
000.000      579      ERNZ      *-53A
              580      ENDIF
              581
000.053      582      DLY      PSW      SAVE COUNT
000.054      583      XRA      A      DONT SOUND HORN
000.055      584      JMP      HRNO      PROCESS AS HORN
              585
              586
              587
000.001      587      IF      .RAM.
              588      ELSE
000.060      589      ORG      60A
              590      ENDIF
              591
000.060      592      INT6      JMP      UIVECT+15      JUMP TO USER ROUTINE
              593
000.063      594      GO.      MVI      A,CB.SSI+CB.CLI+CB.SPK OFF MONITOR MODE LIGHT
000.065      595      JMP      SSI1      RETURN TO USER PROGRAM
              596
              597
              598
000.001      599      IF      .RAM.
              600      ELSE
000.070      601      ORG      70A
              602      ENDIF
              603
000.070      604      INT7      JMP      UIVECT+18      JUMP TO USER ROUTINE
              605
              606
              607
              608
              609
              610
              611
              612
              613
              614
              615
              616
              617
              618
              619
              620
              621
              622
              623
              624
              625
              626
              627
              628
              629
              630
              631
              632
              633
              634
              635
              636
              637
              638
              639
              640
              641
              642
              643
              644
              645
              646
              647
              648
              649
              650
              651
              652
              653
              654
              655
              656
              657
              658
              659
              660
              661
              662
              663
              664
              665
              666
              667
              668
              669
              670
              671
              672
              673
              674
              675
              676
              677
              678
              679
              680
              681
              682
              683
              684
              685
              686
              687
              688
              689
              690
              691
              692
              693
              694
              695
              696
              697
              698
              699
              700
              701
              702
              703
              704
              705
              706
              707
              708
              709
              710
              711
              712
              713
              714
              715
              716
              717
              718
              719
              720
              721
              722
              723
              724
              725
              726
              727
              728
              729
              730
              731
              732
              733
              734
              735
              736
              737
              738
              739
              740
              741
              742
              743
              744
              745
              746
              747
              748
              749
              750
              751
              752
              753
              754
              755
              756
              757
              758
              759
              760
              761
              762
              763
              764
              765
              766
              767
              768
              769
              770
              771
              772
              773
              774
              775
              776
              777
              778
              779
              780
              781
              782
              783
              784
              785
              786
              787
              788
              789
              790
              791
              792
              793
              794
              795
              796
              797
              798
              799
              800
              801
              802
              803
              804
              805
              806
              807
              808
              809
              810
              811
              812
              813
              814
              815
              816
              817
              818
              819
              820
              821
              822
              823
              824
              825
              826
              827
              828
              829
              830
              831
              832
              833
              834
              835
              836
              837
              838
              839
              840
              841
              842
              843
              844
              845
              846
              847
              848
              849
              850
              851
              852
              853
              854
              855
              856
              857
              858
              859
              860
              861
              862
              863
              864
              865
              866
              867
              868
              869
              870
              871
              872
              873
              874
              875
              876
              877
              878
              879
              880
              881
              882
              883
              884
              885
              886
              887
              888
              889
              890
              891
              892
              893
              894
              895
              896
              897

```

MTR89 - H89 MONITOR #09.01.00. Zenith Data Systems UNIX H8/H89 Cross Assembler PA
 GE 17 15:27:27 28-MAY-80
 MASTER CLEAR PROCESSING

```

608 **      INIT - INITIALIZE SYSTEM
609 *
610 *      INIT IS CALLED WHENEVER A HARDWARE MASTER-CLEAR IS INITIATED.
611 *
612 *      SETUP MTR88 CONTROL CELLS IN RAM,
613 *      DECODE HOW MUCH MEMORY EXISTS, SETUP STACKPOINTER, AND
614 *      ENTER THE MONITOR LOOP.
615 *
616 *      ENTRY FROM MASTER CLEAR
617 *      EXIT INTO MTR88 MAIN LOOP
618
000.001      IF .RAM,
619
620      ELSE
621      ERRNZ *-73Q
622      ENDIF
623
000.073 032      INIT
000.074 167      MOV M,A
000.075 053      DCX H
000.076 034      INR E
000.077 302 073 000      JNZ INIT
628
629      EQU 4000A      SEARCH INCREMENT
630
004.000
631
000.102 026 004      MVI D,SINCR/256      (DE) = SEARCH INCREMENT
000.104 041 000 034      LXI H,START-SINCR      (HL) = FIRST RAM - SEARCH INCREMENT
634
635 *      DETERMINE MEMORY LIMIT.
636
000.107 167      MOV M,A      RESTORE VALUE READ
000.110 031      DAD D      INCREMENT TRIAL ADDRESS
000.111 176      MOV A,M      (A) = CURRENT MEMORY VALUE
000.112 065      DCR M      TRY TO CHANGE IT
000.113 276      CNP M      IF MEMORY CHANGED
000.114 302 107 000      JNE INIT1
643
000.117 053      INIT2 DCX H
644
000.001      IF .RAM,
646
000.120 371      ELSE
649      SPHL      SET STACKPOINTER = MEMORY LIMIT -1
650      ENDIF
651
000.121 345      PUSH H      SET *PC* VALUE ON STACK
000.122 041 322 000      LXI H,ERROR
000.125 345      PUSH H      SET RETURN ADDRESS
656
657 *      CONFIGURE LOAD/DUMP UART
658
000.126 076 116      MVI A,UMI.1B+UMI.1B+UMI.16X
000.130 323 371      OUT OP.TPC      SET 8 BIT, NO PARITY, 1 STOP, X16
660

```

```

MTRB9 - HB9 MONITOR *09.01.00.
GE 18
INTERRUPT TIME SUBROUTINES
Zenith Data Systems UNIX HB/HB9 Cross Assembler PA
15:27:28 28-MAY-80

663 ** SAVALL - SAVE ALL REGISTERS ON STACK.
664 *
665 * SAVALL IS CALLED WHEN AN INTERRUPT IS ACCEPTED. IN ORDER TO
666 * SAVE THE CONTENTS OF THE REGISTERS ON THE STACK.
667 *
668 * ENTRY CALLED DIRECTLY FROM INTERRUPT ROUTINE.
669 * EXIT ALL REGISTERS PUSHED ON STACK.
670 * IF NOT YET IN MONITOR MODE, REGPTR = ADDRESS OF REGISTERS
671 * ON STACK.
672 * (DE) = ADDRESS OF CTLFLG
673
674 IF .RAM.
675 ELSE
676 ERRNZ *-132A
677 ENDIF
678
679 SAVALL XTHL SET H,L ON STACK TOP
680 PUSH D
681 PUSH B
682 PUSH PSW
683 XCHG (D,E) = RETURN ADDRESS
684 LXI H,10 (H,L) = ADDRESS OF USERS SP
685 DAD SP
686
687 ** REPLACE THESE INSTRUCTIONS WITH A JUMP AROUND THE NMI VECTOR JUMP
688 *
689 * PUSH H SET ON STACK AS 'REGISTER'
690 * PUSH D SET RETURN ADDRESS
691 * LXI D,CTLFLG
692 * LDAX D (A) = CTLFLG
693
694 JMP SAVALLX GO TO SAVALL EXTENSION
695
696 IF .RAM.
697 ELSE
698 ** ENTRY POINT FOR THE Z80 NMI
699 *
700
701 ERRNZ *-66H Z80 NMI ADDRESS
702
703 ENDIF
704
705 NMIENT JMP NMI
706
707 IF .RAM.
708 ELSE
709 ERRNZ SAVALLR-151A DO NOT CHANGE ORGANIZATION
710 ENDIF
711
712 SAVALLR EQU * SAVALL EXTENSION RETURN ADDRESS
713
714 CMA
715 ANI CB,MTL+CB,SSI SAVE REGISTER ADDR IF USER OR SINGLE-STEP
716 RZ RETURN IF WAS INTERRUPT OF MONITOR LOOP
717 LXI H,2
718 DAD SP (H,L) = ADDRESS OF 'STACKPTR' ON STACK
719
000.132 343
000.133 325
000.134 305
000.135 345
000.136 353
000.137 041 012 000
000.142 071
000.143 303 105 004
000.001
000.000
000.146 303 116 004
000.001
000.000
000.151
000.151 057
000.152 344 060
000.154 310
000.155 041 002 000
000.160 071

```

```

MTR89 - H89 MONITOR *09.01.00. Zenith Data Systems UNIX H8/HB9 Cross Assembler PA
GE 19
INTERRUPT TIME SUBROUTINES 15:27:28 28-MAY-80

000.161 042 035 040 719 SHLD REGPTR
000.164 311 720 RET

000.001
000.000

000.001
000.000

040.010
000.165 012
000.000
000.166 017
000.167 334 037 040

000.001
000.000

000.172 361
000.173 361
000.174 301
000.175 321
000.176 341
000.177 373
000.200 311

722 ** CUI - CHECK FOR USER INTERRUPT PROCESSING.
723 *
724 * CUI IS CALLED TO SEE IF THE USER HAS SPECIFIED PROCESSING
725 * FOR THE CLOCK INTERRUPT.
726
727 IF .RAM.
728 ELSE
729 ERNZ *-165A
730 ENDF
731
732 SET .MFLAG REFERENCE TO MFLAG
733 CUI1 LDAX B (A) = .MFLAG
734 ERNZ UO.CLK-1 CODE ASSUMED = 01
735 RRC
736 CC JIVEC IF SPECIFIED, TRANSFER TO USER
737
738 * RETURN TO PROGRAM FROM INTERRUPT.
739
740 IF .RAM.
741 ELSE
742 ERNZ *-172A
743 ENDF
744
745 INTXIT POP PSW REMOVE FAKE 'STACK REGISTER'
746 POP PSW
747 POP B
748 POP D
749 POP H
750 EI
751 RET

```

NTR89 - H89 MONITOR \$09.01.00.
GE
PROCESS CLOCK INTERRUPTS

Zenith Data Systems UNIX H8/H89 Cross Assembler PA
15:27:29 28-MAY-80

```

754 ***      CLOCK - PROCESS CLOCK INTERRUPT.
755 *
756 *      CLOCK IS ENTERED WHENEVER A MILLISECOND CLOCK INTERRUPT IS
757 *      PROCESSED.
758 *
759 *      TICCNT IS INCREMENTED EVERY INTERRUPT.
760
000.001      IF      .RAM.
761
762      ELSE
763      ERRNZ      *-201A
764      ENDIF
765
000.201      LHL    TICCNT
000.204      INX    H
000.205      SHLD   TICCNT      INCREMENT TICCOUNT
769
000.210      LDA    CTLFLG      CLEAR CLOCK INTERRUPT FLIP-FLOP
000.213      OUT    OP CTL
771
772 *      EXIT CLOCK INTERRUPT.
773 *
774
000.215      LXI    B,CTLFLG      (A) = CTLFLG
000.220      LDAX   B
776
000.221      ANI    CB.MTL
777
000.223      JNZ    INTXIT      IF IN MONITOR MODE
778
000.226      DCX    B
779
000.000      ERRNZ   CTLFLG-MFLAG-1
780
000.227      LDAX   B      (A) = MFLAG
781
000.000      ERRNZ   UO.HLT-200Q      ASSUME HIGH-ORDER
782
000.230      RAL
783
000.231      JC     CLN4      SKIP IT
784
785 *      NOT IN MONITOR MODE, CHECK FOR HALT
786
787
000.234      MVI    A,LO      (A) = INDEX OF *P* REG
788
000.236      CALL   LRA,      LOCATE REGISTER ADDRESS
789
000.241      MOV    E,M
790
000.242      INX    H
791
000.243      MOV    D,M      (D,E) = PC CONTENTS
792
000.244      DCX    D
793
000.245      LDAX   D
794
000.246      CPI    MI.HLT      CHECK FOR HALT
795
000.250      JNZ    CUI1
796
000.253      MVI    A,A,BEL      DING BELL
797
000.255      CALL   WCC
798
000.260      MVI    A,H'      'H' FOR HALT
799
000.262      CALL   WCC
800
000.265      JMP    ERROR
801
802 ***
803      JE      ERROR      IF HALT, BE IN MONITOR MODE
804
805 *      NONE OF THE ABOVE, SO ALLOW USER PROCESSING OF CLOCK INTERRUPT
806
000.270      EQU    CLK4      *
000.270      JMP    CUI1      ALLOW USER PROCESSING OF CLOCK

```

```

MTR89 - HB89 MONITOR #09:01:00.
GE 21
MEMORY TEST
Zenith Data Systems UNIX HB/H89 Cross Assembler PA
15:27:29 28-MAY-80

```

```

811 ** THIS IS ONLY A PORTION OF THE DYNAMIC RAM TEST!!
812 *
813 * WAIT BEFORE MAKING ANOTHER LOOP
814
000.273 041 000 000 815 DYNEM6 LXI H,0
000.276 053 816 DYNEM7 DCX H
000.277 174 817 MOV A,H
000.300 265 818 ORA L
000.301 302 276 000 819 JNZ DYNEM7 IF (B,C) NOT ZERO
820
000.304 303 207 007 821 JMP DYNEM4 TRY AGAIN BY INCREMENTING ONCE MORE
822
823 ** HAVE A FAILURE PRIOR TO REACHING END OF MEMORY!
824 *
825 DYNEM9 XCHG
000.307 353 826 LXI H,MSG.ERR DISPLAY ERROR MESSAGE
000.310 041 047 001 827
828 * IX,DY9.3 RETURN ADDRESS
000.313 335 041 829 DB MI.LDXA:MI.LDXB
000.315 315 003 830 DW DY9.3
831
000.317 303 306 007 832 JMP DYNMSG

```