



H19 ROM

H-19-1

595-2465-01

Copyright © 1980 by the Heath Company, a subsidiary of Zenith Radio Corporation.

Reproduction of this software, except with the written consent of the Heath Company, is prohibited.

Heath Company disclaims all warranties with regard to this material, including all implied warranties of merchantability and fitness for a special purpose.

09:15:20 30-MAY-80

```

2 *** H19 TERMINAL FIRMWARE
3 *
4 *
5 * COPYRIGHT 1978 BY HEATH COMPANY
6 *
7 * WRITTEN BY R. N. BORCHARDT AUGUST 1, 1978

```

```

9 * ASCII CHARACTER EQUIVALENCES

```

Address	Symbol	Equation	Hex Value	Description
000.000	11 NULL	EQU	00000000B	NULL
000.007	12 BELL	EQU	00000111B	BELL
000.010	13 BS	EQU	00001000B	BACKSPACE
000.011	14 HT	EQU	00001001B	HORIZONTAL TAB
000.012	15 LF	EQU	00001010B	LINE FEED
000.015	16 CR	EQU	00001101B	CARRIAGE RETURN
000.021	17 XON	EQU	00010001B	DC1 (X-ON)
000.023	18 XOFF	EQU	00010011B	DC3 (X-OFF)
000.030	19 CAN	EQU	00011000B	CANCEL
000.033	20 ESC	EQU	00011011B	ESCAPE
000.177	21 RUBOUT	EQU	01111111B	RUBOUT/DELETE

```

23 ** I/O PORT EQUIVALENCES

```

```

24 *

```

```

26 * 8250 ACE PORTS

```

Address	Symbol	Equation	Hex Value	Description
000.100	28 AP.RBR	EQU	1000	RECEIVER BUFFER REGISTER PORT
000.100	30 AP.THR	EQU	1000	TRANSMITTER HOLDING REGISTER PORT
000.101	32 AP.IER	EQU	1010	INTERRUPT ENABLE REGISTER PORT
000.001	33 AB.ERDA	EQU	00000001B	ENABLE RECEIVED DATA AVAILABLE INTERRUPT
000.002	34 AB.ETRE	EQU	00000010B	ENABLE TRANSMITTER HOLDING REGISTER EMPTY
000.004	35 AB.ERLS	EQU	00000100B	ENABLE RECEIVER LINE STATUS INTERRUPT
000.010	36 AB.EMS	EQU	00001000B	ENABLE MODEM STATUS INTERRUPT
000.102	38 AP.IIR	EQU	1020	RECEIVED DATA AVAILABLE INTERRUPT
000.004	39 AB.RDAI	EQU	100B	TRANSMITTER REGISTER EMPTY INTERRUPT
000.002	40 AB.TREI	EQU	010B	INVERTED INTERRUPT PENDING
000.001	41 AB.IIP	EQU	00000001B	INTERRUPT IDENTIFICATION BITS
000.006	42 AB.IID	EQU	00000110B	
000.103	44 AP.LCR	EQU	1030	LINE CONTROL REGISTER PORT
000.000	45 AB.5BW	EQU	00000000B	FIVE BIT WORD
000.001	46 AB.6BW	EQU	00000001B	SIX BIT WORD
000.002	47 AB.7BW	EQU	00000010B	SEVEN BIT WORD
000.003	48 AB.8BW	EQU	00000011B	EIGHT BIT WORD
000.004	49 AB.2SB	EQU	00000100B	TWO STOP BITS

APOINTS

09:15:21 30-MAY-80

000.010	50	AB.PEN	EQU	00001000B	PARITY ENABLE
000.020	51	AB.EPS	EQU	00010000B	EVEN PARITY SELECT
000.040	52	AB.SP	EQU	00100000B	STICK PARITY
000.100	53	AB.SBRK	EQU	01000000B	SET BREAK
000.200	54	AB.DLAB	EQU	10000000B	DIVISOR LATCH ACCESS BIT
	55				
000.104	56	AP.MCR	EQU	1040	MODEM CONTROL REGISTER PORT
000.001	57	AB.DTR	EQU	00000001B	DATA TERMINAL READY
000.002	58	AB.RTS	EQU	00000010B	REQUEST TO SEND
000.004	59	AB.OUT1	EQU	00000100B	OUTPUT #1
000.010	60	AB.OUT2	EQU	00001000B	OUTPUT #2
000.020	61	AB.LOOP	EQU	00010000B	LOOP
	62				
000.105	63	AP.LSR	EQU	1050	LINE STATUS REGISTER PORT
000.001	64	AB.DR	EQU	00000001B	DATA READY
000.002	65	AB.OR	EQU	00000010B	OVERRUN ERROR
000.004	66	AB.PE	EQU	00000100B	PARITY ERROR
000.010	67	AB.FE	EQU	00001000B	FRAMING ERROR
000.020	68	AB.BI	EQU	00010000B	BREAK INTERRUPT
000.040	69	AB.THRE	EQU	00100000B	TRANSMITTER HOLDING REGISTER EMPTY
000.100	70	AB.TSRE	EQU	01000000B	TRANSMITTER SHIFT REGISTER EMPTY
	71				
000.104	72	AP.MSR	EQU	1060	MODEM STATUS REGISTER PORT
000.001	73	AB.DCTS	EQU	00000001B	DELTA CLEAR TO SEND
000.002	74	AB.DDSR	EQU	00000010B	DELTA DATA SET READY
000.010	75	AB.DRLS	EQU	00001000B	DELTA RECEIVE LINE SIGNAL DETECT
000.020	76	AB.CTS	EQU	00010000B	CLEAR TO SEND
000.040	77	AB.DSR	EQU	00100000B	DATA SET READY
000.200	78	AB.RLSD	EQU	10000000B	RECEIVED LINE SIGNAL DETECT
	79				
000.100	80	AP.DLL	EQU	1000	DIVISOR LATCH LSB
	81				
000.101	82	AP.DLM	EQU	1010	DIVISOR LATCH MSB
	84	*			CRT VIDEO CONTROLLER PORTS
	85	*			
000.140	86	VP.AR	EQU	1400	VIDEO ADDRESS REGISTER OUTPUT PORT
000.001	87	VA.HD	EQU	1	HORIZONTAL DISPLAYED REGISTER
000.002	88	VA.HSP	EQU	2	HORIZONTAL SYNC POSITION REGISTER
000.003	89	VA.HSW	EQU	3	HORIZONTAL SYNC WIDTH REGISTER
000.004	90	VA.VT	EQU	4	VERTICAL TOTAL REGISTER
000.005	91	VA.VTA	EQU	5	VERTICAL TOTAL ADJUST REGISTER
000.006	92	VA.VD	EQU	6	VERTICAL DISPLAYED REGISTER
000.007	93	VA.VSP	EQU	7	VERTICAL SYNC POSITION REGISTER
000.010	94	VA.IM	EQU	8	INTERLACE MODE REGISTER
000.011	95	VA.MSLA	EQU	9	MAXIMUM SCAN LINE ADDRESS REGISTER
000.012	96	VA.CS	EQU	10	CURSOR START REGISTER
000.100	97	VB.CRE	EQU	01000000B	CURSOR BLINK ENABLE
000.040	98	VB.CBPS	EQU	00100000B	CURSOR BLINK PERIOD SLOW
000.040	99	VB.CND	EQU	00100000B	CURSOR NOT DISPLAYED
000.013	100	VA.CE	EQU	11	CURSOR END REGISTER
000.014	101	VA.SAM	EQU	12	START ADDRESS (MSB) REGISTER
000.015	102	VA.SAL	EQU	13	START ADDRESS (LSB) REGISTER
000.016	103	VA.CAM	EQU	14	CURSOR ADDRESS (MSB) REGISTER

09:15:21 30-MAY-80

000.017	104	VA.CAL	EQU	15	CURSOR ADDRESS (LSB) REGISTER
000.020	105	VA.LPM	EQU	16	LIGHT PEN ADDRESS (MSB) REGISTER
000.021	106	VA.LPL	EQU	17	LIGHT PEN ADDRESS (LSB) REGISTER
	107				
000.141	108	VP.REGO	EQU	141Q	VIDEO REGISTER OUTPUT PORT
	109				
000.143	110	VP.REGI	EQU	143Q	VIDEO REGISTER INPUT PORT
000.010	111	VB.RBD	EQU	00001000B	REVERSE VIDEO DISABLE (WHEN ADDED TO CRTC PORT#)
000.004	112	VB.NMI	EQU	00000100B	CAUSE NMI (MUST BE ADDED TO CRTC PORT#)

114 * KEYBOARD PORTS

	115	*			
000.200	116	KP.1	EQU	200Q	KEYBOARD PORT #1
000.177	117	KB.CHAR	EQU	01111111B	KEY VALUE
000.200	118	KB.CTL	EQU	10000000B	CONTROL KEY
000.013	119	KB.EX1	EQU	00001011B	EXTRA ENCODED KEY #1
000.014	120	KB.EX2	EQU	00001100B	EXTRA ENCODED KEY #2
	121				
000.240	122	KP.2	EQU	240Q	KEYBOARD PORT #2
000.001	123	KB.SHFT	EQU	00000001B	SHIFT KEY(S)
000.002	124	KB.CPLK	EQU	00000010B	CAPS LOCK KEY
000.004	125	KB.BRK	EQU	00000100B	BREAK KEY
000.010	126	KB.ONLN	EQU	00001000B	ON-LINE KEY
000.100	127	KB.RPT	EQU	01000000B	REPEAT KEY
000.200	128	KB.STB	EQU	10000000B	KEYBOARD STROBE

130 * MISC. I/O PORTS

	131	*			
000.300	132	MP.TICK	EQU	300Q	TICK PORT
	133				
000.340	134	MP.BELL	EQU	340Q	BELL PORT
	135				
000.000	136	MP.PUP1	EQU	000Q	POWER UP CONFIGURATION PORT #1
000.017	137	P1.BR	EQU	00001111B	BAUD RATE SELECTION SWITCHES
000.020	138	P1.PEN	EQU	00010000B	PARITY ENABLE SWITCH
000.040	139	P1.EPS	EQU	00100000B	EVEN PARITY SELECT SWITCH
000.100	140	P1.SPS	EQU	01000000B	STICK PARITY SELECT SWITCH
000.200	141	P1.FDX	EQU	10000000B	FULL DUPLEX SELECT SWITCH
	142				
000.040	143	MP.PUP2	EQU	040Q	POWER UP CONFIGURATION PORT #2
000.001	144	P2.CBLK	EQU	00000001B	CURSOR = BLOCK
000.002	145	P2.NOTK	EQU	00000010B	NO TICK ON KEYBOARD STRIKES
000.004	146	P2.WRAP	EQU	00000100B	WRAP AROUND TO BEGINNING OF NEXT LINE
000.010	147	P2.ALF	EQU	00001000B	AUTO LINE FEED ON CARRIAGE RETURN
000.020	148	P2.NOSC	EQU	00010000B	SCROLL KEY = NO SCROLL (EX HOLD SCREEN MODE)
000.040	149	P2.VT52	EQU	00100000B	VT52 MODE
000.100	150	P2.KPDS	EQU	01000000B	KEYPAD SHIFTED
000.200	151	P2.50HZ	EQU	10000000B	50 HERTZ LINE FREQUENCY

INSTRU

09:15:22 30-MAY-80

	153	**	INSTRUCTION EQUIVALENCES		
	154	*			
000.313	155	I.BITA EQU	11001011B	BIT B,R (BYTE A)	
000.100	156	I.BITB EQU	01000000B	BIT B,R (BYTE B) LESS BIT AND REGISTER	
000.313	157	I.BITHA EQU	11001011B	BIT B,(HL) (BYTE A)	
000.106	158	I.BITHB EQU	01000110B	BIT B,(HL) (BYTE B)	
000.355	159	I.IM1A EQU	11101101B	IM1 (BYTE A)	
000.126	160	I.IM1B EQU	01010110B	IM1 (BYTE B)	
000.355	161	I.NEGA EQU	11101101B	NEG (BYTE A)	
000.104	162	I.NEGB EQU	01000100B	NEG (BYTE B)	
000.313	163	I.SETA EQU	11001011B	SET B,R (BYTE A)	
000.300	164	I.SETB EQU	11000000B	SET B,R (BYTE B)	
000.313	165	I.SETHA EQU	11001011B	SET B,(HL) (BYTE A)	
000.306	166	I.SETHB EQU	11000110B	SET B,(HL) (BYTE B)	
000.355	167	I.SHDA EQU	11101101B	SBC HL,DE (BYTE A)	
000.122	168	I.SHDB EQU	01010010B	SBC HL,DE (BYTE B)	
000.313	169	I.RESA EQU	11001011B	RES B,R (BYTE A)	
000.200	170	I.RESB EQU	10000000B	RES B,R (BYTE B)	
000.313	171	I.RESHA EQU	11001011B	RES B,(HL) (BYTE A)	
000.206	172	I.RESHB EQU	10000110B	RES B,(HL) (BYTE B)	
000.010	173	I.EXAF EQU	00001000B	EX AF,AF	
000.331	174	I.EXX EQU	11011001B	EXX	
000.355	175	I.LDEDA EQU	11101101B	LD DE,(NN) (BYTE A)	
000.133	176	I.LDEDB EQU	01011011B	LD DE,(NN) (BYTE B)	
000.355	177	I.LDDA EQU	11101101B	LDD (BYTE A)	
000.250	178	I.Lddb EQU	10101000B	LDD (BYTE B)	
000.355	179	I.LDDRA EQU	11101101B	LDDR (BYTE A)	
000.270	180	I.LDDRB EQU	10111000B	LDDR (BYTE B)	
000.355	181	I.LDIA EQU	11101101B	LDI (BYTE A)	
000.240	182	I.LDIB EQU	10100000B	LDI (BYTE B)	
000.355	183	I.LDIRA EQU	11101101B	LDIR (BYTE A)	
000.260	184	I.LDIRB EQU	10110000B	LDIR (BYTE B)	
000.323	185	I.OUT EQU	11010011B	OUTPUT	
000.311	186	I.RET EQU	11001001B	RETURN	
000.303	187	I.JMP EQU	11000011B	JUMP	
000.355	188	I.RETNA EQU	11101101B	RETURN FROM NMI (BYTE A)	
000.105	189	I.RETNB EQU	01000101B	RETURN FROM NMI (BYTE B)	

	191	*	BIT INSTRUCTION BIT AND REGISTER DEFINITIONS		
	192	*			
	193	*	BYTE B OF BIT AND SET OPERATIONS ARE XXBBBRRR, WHERE XX IS		
	194	*	DEFINED BY THE INSTRUCTION, BBB DEFINES THE BIT, AND RRR DEFINES		
	195	*	THE REGISTER		
	196	*			
000.010	197	IB.CPLK EQU	1*8	CAPS LOCK = BIT 1	
000.070	198	IB.ESCF EQU	7*8	ESCAPE CODE FLAG = BIT 7	
000.010	199	IB.ETRE EQU	1*8	ENABLE TRANSMITTER REGISTER EMPTY INTERRUPT	
000.070	200	IB.IFF EQU	7*8	INPUT FIFO FLAG = BIT 7	
000.070	201	IB.KCB EQU	7*8	KEYBOARD CONTROL KEY BIT = BIT 7	
000.000	202	IB.KSB EQU	0*8	KEYBOARD SHIFT KEY BIT = BIT 0	
000.000	203	IB.HSM EQU	0*8	HOLD SCREEN MODE = BIT 7	
000.070	204	IB.RV EQU	7*8	REVERSE VIDEO MODE = BIT 7	
000.060	205	IB.ICM EQU	6*8	INSERT CHARACTER MODE = BIT 6	
000.070	206	IB.KPDA EQU	7*8	KEYPAD ALTERNATE MODE = BIT 5	

I,BIT

09:15:22 30-MAY-80

000.060	207	IB.KPDS	EQU	6*8	KEYPAD SHIFTED MODE = BIT 4
000.030	208	IB.ONLN	EQU	3*8	TERMINAL ON LINE FLAG = BIT 3
000.020	209	IB.BRK	EQU	2*8	BREAK KEY ON = BIT 2
000.010	210	IB.GRPH	EQU	1*8	TERMINAL IN GRAPHICS MODE = BIT 1
000.000	211	IB.PWE	EQU	0*8	PREVIOUS CHARACTER WAS AN ESCAPE = BIT 0
000.040	212	IB.XOFF	EQU	4*8	XOFF SENT TO HOST = BIT 4
000.010	213	IB.XMTG	EQU	1*8	TRANSMIT MODE = GRAPHICS = BIT 1
000.020	214	IB.XMTR	EQU	2*8	TRANSMIT MODE = REVERSE VIDEO = BIT 2
	215				
000.007	216	IR.A	EQU	111B	REGISTER = A
000.000	217	IR.B	EQU	000B	REGISTER = B
000.001	218	IR.C	EQU	001B	REGISTER = C
000.002	219	IR.D	EQU	010B	REGISTER = D
000.003	220	IR.E	EQU	011B	REGISTER = E
000.004	221	IR.H	EQU	100B	REGISTER = H
000.005	222	IR.L	EQU	101B	REGISTER = L

224 ** LABEL EQUIVALENCES

225 *

000.200	226	IFF	EQU	10000000B	INPUT FIFO FLAG
000.200	227	ESCF	EQU	10000000B	ESCAPE FLAG
000.037	228	SCRL	EQU	00011111B	KEYBOARD VALUE FOR SCROLL KEY

```
231 *** INITIALIZE SYSTEM
232 *
233 * JUMP TO THE ROUTINE WHICH SETS UP ALL PORTS, RAM, AND THE CRT
234
000.000 235 ORG 0
236
000.000 003 001 013 237 START JMP INIT
000.003 313 238 DB 43H+41H+47H ENGINEERING CODE

240 *** MAIN - MAIN CONTROL LOOP
241 *
242 * *MAIN* SETS ITSELF UP AS THE FINAL RETURN ADDRESS FOR ALL ROUTINES
243 * AND IS IN CHARGE OF GIVING CONTROL TO THE PROPER ROUTINE WHENEVER
244 * THERE IS A CHARACTER PRESENT IN ONE OF THE FIFOS
245 *
246 * THE ORDER OF PRIORITY OF SERVICE IS IN THE ORDER IN WHICH THE
247 * FIFOS ARE TESTED (KEYBOARD FIFO = #1, INPUT FIFO = #2, OUTPUT
248 * FIFO = #3)
249 *
250 *
251 * ENTRY NONE
252 *
253 * EXIT NONE
254 *
255 * USES A,B,C,D,E,H,L,F
256
000.004 041 004 000 258 MAIN LXI H,MAIN SET SELF AS RETURN ADDRESS ON STACK
000.007 345 259 MAIN PUSH H
260
000.010 315 367 011 261 CALL FCIF FETCH CHARACTER FROM INPUT FIFO
000.013 322 120 003 262 JNC IFCP IF PRESENT, PRECESS IT
263
000.016 315 107 012 264 MAIN.N CALL FVKF FETCH VALUES FROM KEYBOARD FIFO
000.021 322 117 001 265 JNC KCE IF CHARACTER PRESENT, ENCODE IT
266
000.024 315 111 016 267 CALL UCP UPDATE CURSOR POSITION
268
000.027 072 307 100 269 LDA MODEA GET MODE FLAGS
000.032 346 040 270 ANI MA.BRK HAS BREAK BEEN SET?
000.034 304 070 000 271 CNZ AKI IF BREAK IS SET, SEE IF WE CAN TURN IT OFF
272
000.037 072 311 100 273 MAIN1 LDA MODEI GET CURRENT MODE FLAGS
000.042 346 010 274 ANI MI.ONLN IS TERMINAL ON-LINE?
000.044 310 275 RZ IF NOT ON LINE
276
277 * ALTERNATE ENTRY POINT FOR SETTING THE XMIT INTERRUPT ONLY
278 *
000.045 363 279 MAINA DI ELSE, LOCK OUT INTERRUPTS
000.046 072 243 100 280 LDA OFC SEE IF OUTPUT FIFO HAS ANY CHARACTERS
000.051 267 281 ORA A
000.052 050 012 282 JR Z,MAIN2 IF NO CHARACTERS TO OUTPUT
283
```

MAIN CONTROL LOOP

09:15:23 30-MAY-80

```
000.054 333 101      284      IN      AP.IER      IF CHARACTERS PRESENT, SEE IF XMIT INT. IS ON
                                285 *      BIT      IB.ETRE,A
000.056 313 117      286      DB      I.BITA,I.BITB:IB.ETRE:IR.A
000.060 040 004      287      JR      NZ,MAIN2      IF INTERRUPT IS ENABLED
                                288
000.062 366 002      289      ORI      AB.ETRE      ELSE, ENABLE INTERRUPT SO OUTPUT CAN BEGIN
000.064 323 101      290      OUT      AP.IER
000.066 373          291 MAIN2    EI      ENABLE INTERRUPTS
000.067 311          292      RET
                                293
```

```

296 *** AKI - ACE/KEYBOARD INTERRUPT
297 *
298 * *AKI* IS ACCESSED WHENEVER AN INTERRUPT IS RECEIVED FROM EITHER
299 * THE ACE, THE KEYBOARD ENCODER, OR THE KEYBOARD BREAK KEY. ALL
300 * VALID INTERRUPT SOURCES ARE SAMPLED TO INSURE THAT NO FALSE
301 * INTERRUPTS ARE SERVICED.
302 *
303 *
304 * ENTRY NONE
305 *
306 * EXIT NONE
307 *
308 * USES A,B,C,D,E,H,L,F
309
000.000 310 ERRNZ *-700 Z80 MODE ONE INTERRUPT ADDRESS
311 *AKI EX AF,AF' EXCHANGE ALL REGISTERS
000.070 010 312 AKI DB I.EXAF
313 * EXX
000.071 331 314 DB I.EXX
315
000.072 333 240 316 AKI1 IN KP.2 READ KEYBOARD PORT #2
000.074 356 366 317 XRI 11110110B INVERT SWITCHES (EXCEPT OFF-LINE)
000.076 127 318 MOV D,A SAVE SWITCH VALUES
000.077 346 010 319 ANI KB.ONLN MASK FOR ON-LINE ACTIVE
000.101 117 320 MOV C,A SAVE RESULT
000.102 072 311 100 321 LDA MODEI GET CURRENT MODE
000.105 346 367 322 ANI 377Q-MI.ONLN CLEAR PREVIOUS ON-LINE STATUS
000.107 261 323 ORA C REPLACE WITH NEW STATUS
000.000 324 ERRNZ KB.ONLN-MI.ONLN SWITCH AND MODE FLAG MUST BE THE SAME
000.110 062 311 100 325 STA MODEI UPDATE *MODE*
000.113 172 326 MOV A,D GET SWITCH VALUES
000.114 346 004 327 ANI KB.BRK MASK FOR BREAK SWITCH
000.116 072 307 100 328 LDA MODEA GET MODE FLAGS
000.121 312 264 000 329 JZ AKI1.5 IF NO BREAK KEY
330
000.124 107 331 MOV B,A SAVE MODE A
000.125 072 311 100 332 LDA MODEI GET MODE I
000.130 346 004 333 ANI MI.KID SEE IF KEYBOARD IS DISABLED
000.132 170 334 MOV A,B (A) = MODE A
000.133 302 264 000 335 JNZ AKI1.5 IF CAN'T RESPOND TO BREAK
336
000.136 366 040 337 ORI MA.BRK SET BREAK FLAG
000.140 062 307 100 338 STA MODEA
000.143 303 254 000 339 JMP AKI1.3 CONTINUE PAST NMI ROUTINE
340

```



```

343 *** NMI - NON MASKABLE INTERRUPT USED FOR CRTC HOME POSITION UPDATE
344 *
345 * NMI OUTPUTS THE CURRENT DISPLAY INFORMATION TO THE CRTC WHEN
346 * CAUSED BY VERT SYNC.
347 *
348 *
349 * ENTRY NONE
350 *
351 * EXIT NONE
352 *
353 * USES NONE
354 *
000.000 355 ERRNZ *-146A
356 *
000.146 365 357 NMI PUSH PSW SAVE REGISTERS
000.147 305 358 PUSH B
000.150 325 359 PUSH D
000.151 345 360 PUSH H
361 *
362 * UPDATE VERTICAL DISPLAYED REGISTER
363 *
000.152 076 006 364 MVI A,VA,VD SET VERTICAL DISPLAYED ADDRESS
000.154 323 140 365 OUT VP,AR
000.156 072 276 100 366 LDA VI,VD GET CURRENT # OF LINES TO DISPLAY
000.161 323 141 367 OUT VP,REGO
368 *
369 * UPDATE CURSOR TYPE REGISTERS
370 *
000.163 052 277 100 371 LHLD VI,CSE GET CURSOR START AND END PARAMETERS
000.166 076 012 372 MVI A,VA,CS SET CRTC CURSOR START ADDRESS
000.170 323 140 373 OUT VP,AR
000.172 174 374 MOV A,H OUTPUT CURSOR START INFO
000.173 323 141 375 OUT VP,REGO
000.175 076 013 376 MVI A,VA,CE SET CURSOR END ADDRESS
000.177 323 140 377 OUT VP,AR
000.201 175 378 MOV A,L OUTPUT CURSOR END INFO
000.202 323 141 379 OUT VP,REGO
380 *
381 * UPDATE VIDEO HOME ADDRESS
382 *
000.204 052 301 100 383 LHLD VI,SA GET START ADDRESS
000.207 076 014 384 MVI A,VA,SAM START ADDRESS MSB
000.211 323 140 385 OUT VP,AR
000.213 174 386 MOV A,H OUTPUT ADDRESS MSB
000.214 323 141 387 OUT VP,REGO
000.216 076 015 388 MVI A,VA,SAL START ADDRESS LSB
000.220 323 140 389 OUT VP,AR
000.222 175 390 MOV A,L OUTPUT ADDRESS LSB
000.223 323 141 391 OUT VP,REGO
392 *
393 * UPDATE CURSOR ADDRESS
394 *
000.225 052 303 100 395 LHLD VI,CA GET CURSOR ADDRESS
000.230 076 014 396 MVI A,VA,CAM CURSOR ADDRESS MSB
000.232 323 140 397 OUT VP,AR
000.234 174 398 MOV A,H CURSOR MSB

```

AKI - ACE/KEYBOARD INTERRUPT

NMI

09:15:26 30-MAY-80

```

000.235 323 141 399 OUT VP,REGO
000.237 076 017 400 MVI A,VA,CAL CURSOR ADDRESS LSR
000.241 323 140 401 OUT VP,AR
000.243 175 402 MOV A,L CURSOR LSR
000.244 323 141 403 OUT VP,REGO
404
405 * ALLOW NEXT NMI
406 *
000.246 341 407 POP H RESTORE ALL REGISTERS
000.247 321 408 POP D
000.250 301 409 POP B
000.251 361 410 POP PSW
411
412 * RETN RETURN FROM NMI
000.252 355 105 413 DB I,RETNA,I,RETNB

000.254 333 103 415 AKI1.3 IN AP,LCR SET BREAK SIGNAL
000.256 366 100 416 ORI AB,SBRK
000.260 323 103 417 OUT AP,LCR
000.262 030 013 418 JR AKI1.7 CONTINUE
419
000.264 346 337 420 AKI1.5 ANI 377Q-MA,BRK MAKE SURE BREAK FLAG IS OFF
000.266 062 307 100 421 STA MODEA
000.271 333 103 422 IN AP,LCR CLEAR ANY BREAK
000.273 346 277 423 ANI 377Q-AB,SBRK
000.275 323 103 424 OUT AP,LCR
425
000.277 333 102 426 AKI1.7 IN AP,IIR SEE IF ACE WAS SOURCE OF INTERRUPT
000.301 376 004 427 CPI AB,RDAI SEE IF THERE IS RECEIVED DATA AVAILABLE
000.303 040 055 428 JR NZ,AKI2 IF NOT A DATA AVAILABLE INTERRUPT
429
430 * INTERRUPT CAUSED BY DATA AVAILABLE IN ACE RECEIVER BUFFER
431 *
000.305 333 100 432 IN AP,RBR INPUT DATA
000.307 346 177 433 ANI 01111111B TOSS PARITY BIT
000.311 312 113 001 434 JZ AKI6 IF CHARACTER WAS A NULL, EXIT
435
436
437 * BIT IB,ONLN,C SEE IF TERMINAL IS ON-LINE
000.314 313 131 438 DB I,BITB,I,BITB,IB,ONLN,IIR,C
000.316 050 173 439 JR Z,AKI6 IF OFF LINE, EXIT
440
000.320 127 441 MOV D,A SAVE INPUT CHARACTER
000.321 072 241 100 442 LDA IFC GET INPUT FIFO COUNTER
000.324 376 160 443 CPI IFMAX-16 SEE IF WITHIN 16 BYTES OF OVERFLOW
000.326 070 022 444 JR C,AKI1.8 IF NOT < 16 BYTES LEFT
445
000.330 333 105 446 AKI1.75 IN AP,LSR SEE IF UART CAN TAKE A CHARACTER TO OUTPUT
000.332 346 040 447 ANI AB,THRE
000.334 050 372 448 JR Z,AKI1.75 IF HOLDING REGISTER NOT EMPTY
449
000.336 076 023 450 MVI A,XOFF ELSE, SEND CTL-S
000.340 323 100 451 OUT AP,THR

```


AKI - ACE/KEYBOARD INTERRUPT

AKI

09:15:27 30-MAY-80

```

000.342 072 311 100 452 LDA MODEI GET MODE FLAGS
000.345 366 020 453 ORI M1,XOFF SET XOFF SENT
000.347 062 311 100 454 STA MODEI
455
000.352 172 456 AKI1.8 MOV A,D GET INPUT CHARACTER
000.353 315 251 013 457 CALL PCIF ELSE, PUT CHARACTER IN INPUT FIFO
000.356 070 131 458 JR C,AKI5 IF FIFO IS FULL, TOSS CHARACTER AND DING BELL
000.360 030 131 459 JR AKI6 IF FIFO NOT FULL, EXIT WITHOUT BELL
460
461
000.362 376 002 462 AKI2 CPI AB,TREI SEE IF INTERRUPT WAS FROM XMIT BUFFER EMPTY
000.364 040 025 463 JR NZ,AKI4 IF NOT FROM ACE TRANSMITTER
464
465 * INTERRUPT CAUSED BY ACE TRANSMITTER HOLDING REGISTER EMPTY
466 *
467 * BIT IB,ONLN,C SEE IF ON-LINE
000.366 313 131 468 DB I.BITA,I.BITB,IB,ONLN,IR,C
000.370 050 011 469 JR Z,AKI3 IF OFF-LINE, DON'T OUTPUT CHARACTER
470
000.372 315 032 012 471 CALL FCOF ELSE, FETCH A CHARACTER FROM THE OUTPUT FIFO
000.375 070 004 472 JR C,AKI3 IF NO CHARACTER IN FIFO
473
000.377 323 100 474 OUT AP,THR OUTPUT CHARACTER TO ACE
001.001 030 110 475 JR AKI6 EXIT
476
001.003 333 101 477 AKI3 IN AP,IER INPUT ACE INTERRUPT ENABLE REGISTER
001.005 346 375 478 ANI 3770-AB,ETRE CLEAR TRANSMITTER REGISTER EMPTY INTERRUPT
001.007 323 101 479 OUT AP,IER
001.011 030 100 480 JR AKI6 EXIT
481
001.013 333 240 482 AKI4 IN KP.2 READ SECOND KEYBOARD PORT
001.015 356 366 483 XRI 11110110B INVERT SWITCHES (EXCEPT OFF-LINE)
001.017 107 484 MOV B,A SAVE INPUT
001.020 346 200 485 ANI KB,STB IS A KEYBOARD STROBE PRESENT?
001.022 050 067 486 JR Z,AKI6 IF NO STROBE
487
488 * INTERRUPT CAUSED BY A KEY STRIKE ON THE KEYBOARD
489 *
001.024 333 200 490 IN KP.1 INPUT KEY VALUE
001.026 107 491 MOV B,A
001.027 333 240 492 IN KP.2 INPUT SECOND PORT
001.031 356 366 493 XRI 11110110B INVERT SWITCHES (EXCEPT OFF LINE)
001.033 117 494 MOV C,A
495
496 * SEE IF CHARACTER IS FROM EXTRA KEY #1. IF SO, INVERT KEYBOARD DISABLE
497 *
001.034 170 498 MOV A,B GET KEY VALUE
001.035 376 213 499 CPI KB,CTL+KB,EX1 MUST BE CTL-EX1
001.037 072 311 100 500 LDA MODEI GET MODE FLAGS
001.042 040 007 501 JR NZ,AKI4.3 IF NOT CONTROL AND EX1
502
001.044 356 004 503 XRI MI,KID INVERT KEYBOARD DISABLE FLAG
001.046 062 311 100 504 STA MODEI UPDATE FLAGS
001.051 030 004 505 JR AKI4.4 SEE IF TO TICK-ET
506
507 * SEE IF KEYBOARD IS DISABLED

```

AKI - ACE/KEYBOARD INTERRUPT

AKI

09:15:28 30-MAY-80

```
001.053 346 004 508 *
001.055 040 034 509 AKI4.3 ANI MI,KID MASK FOR KEYBOARD INPUT DISABLED FLAG
510 JR NZ,AKI6 IF DISABLED, EXIT
511
512 * SEE IF TO TICK UPON KEYBOARD INPUT
513 *
001.057 072 310 100 514 AKI4.4 LDA MODEB GET PROPER FLAGS
001.062 346 002 515 ANI MB,NOTK NO TICK?
001.064 040 002 516 JR NZ,AKI4.8 IF NOT TO MAKE NOISE
517
001.066 323 300 518 OUT MP,TICK TICK TICKER TO INDICATE KEY STRIKE
519
520 * CAN PUT CHARACTER IN FIFO TO BE PROCESSED BY KCE
521 *
001.070 052 264 100 522 AKI4.8 LHLD KBDFF GET KEYBOARD FIFO POINTER
001.073 175 523 MOV A,L GET POINTER LSB
001.074 376 264 524 CPI KBDFMAX&3770 SEE IF ROOM IN FIFO
001.076 050 011 525 JR Z,AKI5 IF NO ROOM, DING BELL
526
001.100 160 527 MOV M,B PLACE IN FIFO
001.101 043 528 INX H
001.102 161 529 MOV M,C PLACE IN FIFO
001.103 043 530 INX H
001.104 042 264 100 531 SHLD KBDFF UPDATE FIFO POINTER
001.107 030 002 532 JR AKI6 EXIT
533
001.111 323 340 534 AKI5 OUT MP,BELL DING THE DANG BELL
535
536 *AKI6 EX AF,AF' EXCHANGE ALL REGISTERS
001.113 010 537 AKI6 DB I,EXAF
538 * EXX
001.114 331 539 DB I,EXX
001.115 373 540 EI ENABLE NEW INTERRUPTS
001.116 311 541 RET
```

```

544 ***      KCE - KEYBOARD CHARACTER ENCODER
545 *
546 *      *KCE* IS RESPONSIBLE FOR TAKING THE VALUE SUPPLIED BY THE HARDWARE
547 *      KEYBOARD ENCODER AND DETERMINING IF THE VALUE IS A LEGITIMATE ASCII
548 *      VALUE. IF THE VALUE DOES NOT REPRESENT THE ACTUAL ASCII VALUE FOR
549 *      THE KEY STRUCK, *KCE* FORMS THE CORRECT VALUE.
550 *
551 *      THE HARDWARE ENCODER ALSO SIGNALS WHETHER THE *CONTROL* OR *SHIFT*
552 *      KEY WAS PRESSED. IF THE HARDWARE ENCODER DOES NOT REFLECT THE
553 *      CONTROL OR SHIFT VALUE FOR THE KEY, *KCE* SETS THE CORRECT VALUE
554 *      PRIOR TO EXITING.
555 *
556 *      *KCE* ALSO PLACES THE ENCODED ASCII VALUE OF THE KEY INTO EITHER
557 *      THE INPUT OR OUTPUT FIFO. IF THE KEY STRUCK IS A FUNCTION KEY
558 *      RATHER THAN AN ALPHABETICAL OR NUMERICAL KEY AND THE CONTROL KEY
559 *      WAS ALSO STRUCK, THE ENCODED VALUE IS PLACED IN THE INPUT FIFO.
560 *      ALL OTHER VALUES ARE PLACED IN THE OUTPUT FIFO.
561 *
562 *
563 *      ENTRY      (D,E) = VALUE OF KEY SUPPLIED BY THE HARDWARE ENCODER
564 *      EXIT      NONE
565 *      USES      A,B,C,D,E,H,L
566
567
568 KCE      MOV      A,D          PLACE KEY VALUE IN ACC
569          ANI      01111111B    MASK OFF ANY CONTROL BIT
570
571 *      ENCODE KEY VALUES 000Q THRU 017Q AND 033Q
572 *
573          CPI      033Q        CHECK FOR 'ESC' KEY
574          JR      Z,KCE3      IF KEY WAS THE 'ESC' KEY
575
576          CPI      020Q        KEY < 020Q ?
577          JNC     KCE6        IF KEY > 017Q
578
579 KCE1     PUSH     D          SAVE KEYBOARD VALUES
580          LXI      H,KAE1     POINT TO ASCII EQUIV. TABLE #1
581          MVI      D,KAE1L    (D) = LENGTH OF TABLE
582          MVI      E,KAE1W    (E) = WIDTH OF TABLE IN BYTES
583          CALL     STAB       SEARCH TABLE
584          POP      D          (D,E) = KEYBOARD VALUES
585          JR      C,KCE1.5    IF NO ENTRY WAS FOUND
586
587          CPI      ESCF+'J'    WAS IT THE ERASE KEY?
588          JR      NZ,KCE2     IF NOT
589
590 *      ELSE, SEE IF SHIFT KEY ALSO
591          DB      I.BITA,I.BITB!IB.KSB!IR.E
592          JR      Z,KCE2      IF NO SHIFT KEY, JUST SEND AN ERM
593
594          LDA      MODEB      GET MODE FLAGS
595          ANI      MB.ANSI    IN ANSI MODE?
596          JR      Z,KCE1.4    IF NOT IN ANSI MODE
597
598 *      SEE IF CONTROL KEY WAS DOWN
599          DB      I.BITA,I.BITB!IB.KCB!IR.D

```

```

001.172 050 010      600      JR      Z,KCE1.2      IF NO CONTROL KEY
001.174 315 051 015  601
001.174 315 051 015  602      CALL     PSIF      CONTROL DOWN, PUT STRING IN INPUT FIFO
001.177 033 133 062  603      DB      ESC,'E','2','J'+2000
001.203 311          604      RET
001.204 315 100 015  605
001.204 315 100 015  606 KCE1.2 CALL     PSOF      NO CONTROL, PUT STRING IN OUTPUT FIFO
001.207 033 133 062  607      DB      ESC,'E','2','J'+2000
001.213 311          608      RET
001.214 076 305      609
001.214 076 305      610 KCE1.4 MVI      A,ESCF+'E'      ELSE, SEND A CLR
001.216 030 006      611      JR      KCE2
001.220 172          612
001.220 172          613 KCE1.5 MOV      A,D      ELSE, PLACE ORIGINAL VALUE BACK IN ACC
001.221 346 177      614      ANI      377Q-KB.CTL      NO CONTROL = INPUT FIFO ON CONTROL CODES HERE
001.223 127          615      MOV      D,A      UPDATE (D)
001.224 030 051      616      JR      KCE3      GO PLACE ASCII VALUE IN APPROPRIATE FIFO
001.226 313 177      617
001.230 050 045      618
001.232 346 177      619 *      PLACE ASCII VALUE(S) IN THE APPROPRIATE FIFO
001.234 365          620 *      IF BIT 7 IS SET IN VALUE, FIRST PLACE AN 'ESC' FOLLOWED BY THE SEVEN LSB
001.235 076 033      621 *
001.237 313 172      622 *KCE2 BIT      IB,ESCF,A      SEE IF 'ESC' TO BE SENT BEFORE ALPHA CHARACTER
001.241 050 046      623 KCE2 DB      I,BIT A,I,BIT B!IB,ESCF!IR,A
001.243 363          624      JR      Z,KCE3      IF NO 'ESC' IS TO BE SENT
001.247 373          625
001.250 072 310 100 626      ANI      377Q-ESCF      REMOVE ESCAPE FLAG
001.253 346 040      627      PUSH     PSW      ELSE, SAVE VALUE FROM TABLE
001.255 050 017      628      MVI      A,ESC      SET (A) = 'ESC'
001.257 361          629
001.260 365          630 *      CHECK FOR 'CONTROL' KEY, IF STRUCK, PLACE CHARACTERS IN INPUT FIFO
001.261 376 120      631 *
001.263 076 133      632 *      BIT      IB,KCB,D      SEE IF CONTROL KEY WAS STRUCK ON KEYBOARD
001.265 070 002      633 DB      I,BIT A,I,BIT B!IB,KCB!IR,D
001.267 076 117      634      JR      Z,KCE4      IF CONTROL KEY NOT STRUCK
001.271 363          635
001.272 315 251 013 636      DI      LOCK OUT OTHER INPUTS (*AKI*)
001.275 373          637      CALL     PCIF      PUT CHARACTER IN FIFO
001.276 361          638      EI      ALLOW INPUTS FROM *AKI*
001.277 313 172      639      LDA      MODER      GET MODE FLAGS
001.278 373          640      ANI      MB.ANSI      SEE IF IN ANSI MODE
001.279 361          641      JR      Z,KCE2.7      IF HEATH MODE IS SELECTED
001.280 373          642
001.281 361          643      POP      PSW      GET CHARACTER
001.282 373          644      PUSH     PSW
001.283 373          645      CPI      'P'      SEE IF CHAR < P
001.284 373          646      MVI      A,'E'      IF < P, OUTPUT A 'E'
001.285 373          647      JR      C,KCE2.3
001.286 373          648
001.287 373          649      MVI      A,'0'      ELSE, OUTPUT AN '0'
001.288 373          650 KCE2.3 DI
001.289 373          651      CALL     PCIF
001.290 373          652      EI
001.291 373          653 KCE2.7 POP      PSW      GET ASCII VALUE
001.292 373          654 *KCE3 BIT      IB,KCB,D      TEST CONTROL KEY FOR PLACEMENT OF THIS CHARACTER
001.293 373          655 KCE3 DB      I,BIT A,I,BIT B!IB,KCB!IR,D

```

```

001.301 050 036      656      JR      Z,KCE5      IF CONTROL KEY NOT STRUCK
                        657
001.303 363          658      DI              LOCK OUT OTHER INPUTS
001.304 315 251 013  659      CALL     PCIF      PLACE CHARACTER IN INPUT FIFO
001.307 373          660      EI              ALLOW *AKI* INPUTS
001.310 311          661      RET
                        662
001.311 315 375 013  663 KCE4  CALL     PCOFT      PLACE CHARACTER IN OUTPUT FIFO
001.314 072 310 100  664      LDA      MODEB      GET MODE FLAGS
001.317 346 040      665      ANI      MB,ANSI     SEE IF IN ANSI MODE
001.321 050 015      666      JR      Z,KCE4.7     IF IN HEATH MODE
                        667
001.323 361          668      POP      PSW      GET CHARACTER
001.324 365          669      PUSH     PSW
001.325 376 120      670      CPI      'P'        SEE IF < P
001.327 076 133      671      MVI      A,'C'        IF < P, OUTPUT A 'C'
001.331 070 002      672      JR      C,KCE4.3     IF < P
                        673
001.333 076 117      674      MVI      A,'0'        ELSE, OUTPUT AN '0'
001.335 315 375 013  675 KCE4.3 CALL     PCOFT
                        676
001.340 361          677 KCE4.7 POP      PSW      GET ASCII CHARACTER
001.341 303 375 013  678 KCE5  JMP      PCOFT      PLACE CHARACTER IN OUTPUT FIFO
                        679
001.344 376 035      680 *          ENCODE KEY VALUES 020Q THRU 034Q (EXCEPT 033Q)
001.346 322 246 002  681 *          THESE VALUES ARE FROM THE 12 KEY NUMERIC PAD
                        682 *
001.344 376 035      683 KCE6  CPI      035Q      KEY < 35Q ?
001.346 322 246 002  684      JNC      KCE12      IF KEY > 34Q
                        685
001.351 325          686      PUSH     D          SAVE KEYBOARD VALUES
001.352 041 372 002  687      LXI      H,KAE2      POINT TO SECOND ASCII EQUIVALENCE TABLE
001.355 026 014      688      MVI      D,KAE2L      GET TABLE LENGTH
001.357 036 005      689      MVI      E,KAE2W      GET TABLE WIDTH
001.361 315 363 015  690      CALL     STAB      SEARCH TABLE
001.364 321          691      POP      D          (D,E) = KEYBOARD VALUES
                        692
001.365 313 103      693 *          CHECK FOR SHIFT KEY AND/OR KEYPAD SHIFT MODE
001.367 072 310 100  694 *
001.372 050 006      695 *          BIT      IB,KSBE      SHIFT KEY DOWN?
                        696      DB      I.BITA,I.BITB!IB,KSBI!IR,E
001.374 313 167      697      LDA      MODEB      GET MODE FLAGS
001.376 040 007      698      JR      Z,KCE7      IF NO SHIFT KEY
002.000 030 004      699
                        700 *          BIT      IB,KPDS,A      TEST FOR KEYPAD SHIFT MODE
001.374 313 167      701      DB      I.BITA,I.BITB!IB,KPDS!IR,A
001.376 040 007      702      JR      NZ,KCE9      IF SHIFT KEY & SHIFT MODE, DON'T SHIFT!
002.000 030 004      703      JR      KCE8      ELSE SHIFT KEY & NO SHIFT MODE, SO SHIFT
                        704
                        705
002.002 313 167      706 *KCE7  BIT      IB,KPDS,A      TEST FOR KEYPAD SHIFT MODE
002.004 050 001      707 KCE7  DB      I.BITA,I.BITB!IB,KPDS!IR,A
                        708      JR      Z,KCE9      NO SHIFT KEY & NO SHIFT MODE
                        709
002.006 043          710 KCE8  INX      H          POINT TO SHIFTED BYTE IN TABLE
                        711

```



```

002.007 346 200      712 KCE9  ANI    MB.KPDA    TEST FOR KEYPAD IN ALTERNATE MODE
002.011 050 002      713      JR      Z,KCE10    IF NOT IN ALT MODE
                                714
002.013 043          715          INX    H        ELSE, POINT TO ALT MODE BYTE
002.014 043          716          INX    H
002.015 257          717 KCE10  XRA     A        CLEAR ACC AND GET BYTE FROM TABLE (SET FLAGS)
002.016 206          718          ADD    M
002.017 362 277 001  719          JP      KCE3    IF NOT AN ESC FUNCTION, GO PUT IN FIFO
                                720
002.022 376 315      721          CPI    ESCF+'M'  CHECK FOR ESC-M (COULD BE ESC-M OR ESC-?-M)
002.024 050 155      722          JR      Z,KCE10.5  IF ESC-M
                                723
002.026 376 340      724          CPI    11100000B CHECK FOR LOWER CASE WITH 'ESC' (ALT MODE CHAR)
002.030 060 162      725          JR      NC,KCE11  IF NOT A CURSOR FUNCTION
                                726
002.032 376 316      727          CPI    ESCF+'N'  SEE IF DELETE CHARACTER
002.034 040 033      728          JR      NZ,KE10.07 IF NOT THE DC KEY
                                729
002.036 107          730          MOV    B,A      ELSE, SAVE CHARACTER
002.037 072 310 100  731          LDA    MODEB    GET MODE FLAGS
002.042 346 040      732          ANI    MB.ANSI  SEE IF IN ANSI MODE
002.044 170          733          MOV    A,B      (A) = CHARACTER
002.045 050 022      734          JR      Z,KE10.07 IF NOT IN ANSI MODE
                                735
002.047 313 172      736 *      BIT    IB.KCB,D    SEE IF CONTROL KEY PRESSED
                                737          DB      I,BITB,I,BITB!IB.KCB!IR.D
002.051 050 007      738          JR      Z,KE10.03  IF NO CONTROL KEY
                                739
002.053 315 051 015  740          CALL   PSIF    ELSE, PUT IN INPUT FIFO
002.056 033 133 320  741          DB      ESC,'[', 'P'+200Q
002.061 311          742          RET
                                743
002.062 315 100 015  744 KE10.03 CALL   PSOF    PUT STRING IN OUTPUT FIFO
002.065 033 133 320  745          DB      ESC,'[', 'P'+200Q
002.070 311          746          RET
                                747
002.071 376 300      748 KE10.07 CPI    ESCF+'@'  CHECK FOR INSERT CHARACTER CODE
002.073 302 226 001  749          JNZ    KCE2    IF NOT INSERT CHARACTER KEY
                                750
002.076 072 310 100  751          LDA    MODEB    GET MODE FLAGS
002.101 346 040      752          ANI    MB.ANSI  SEE IF IN ANSI MODE
002.103 050 057      753          JR      Z,KCE10.4  IF IN HEATH MODE
                                754
002.105 072 307 100  755          LDA    MODEA    ELSE, GET MODEA FLAGS
002.110 346 100      756          ANI    MA.ICM    SEE IF IN ICM
002.112 050 024      757          JR      Z,KCE10.2  IF NOT ALREADY IN INSERT MODE
                                758
002.114 313 172      759 *      BIT    IB.KCB,D    SEE IF CONTROL KEY WAS DOWN
                                760          DB      I,BITB,I,BITB!IB.KCB!IR.D
002.116 050 010      761          JR      Z,KCE10.1  IF NO CONTROL KEY
                                762
002.120 315 051 015  763          CALL   PSIF    ELSE, PUT STRING IN INPUT FIFO
002.123 033 133 064  764          DB      ESC,'[', '4', '1'+200Q
002.127 311          765          RET
                                766
002.130 315 100 015  767 KCE10.1 CALL   PSOF    PUT STRING IN OUTPUT FIFO

```

KCE - KEYBOARD CHARACTER ENCODER

09:15:32 30-MAY-80

```

002.133 033 133 064 768 DB ESC,'L','4','1'+200Q
002.137 311 769 RET
770
771 *KCE10.2 BIT IB,KCB,D CHECK FOR CONTROL KEY
002.140 313 172 772 KCE10.2 DB I.BITA,I.BITB!IB,KCB!IR,D
002.142 050 010 773 JR Z,KCE10.3 IF NO CONTROL KEY
774
002.144 315 051 015 775 CALL PSIF ELSE, PUT STRING IN INPUT FIFO
002.147 033 133 064 776 DB ESC,'L','4','h'+200Q
002.153 311 777 RET
778
002.154 315 100 015 779 KCE10.3 CALL PSOF PUT STRIN IN OUTPUT FIFO
002.157 033 133 064 780 DB ESC,'L','4','h'+200Q
002.163 311 781 RET
782
002.164 072 307 100 783 KCE10.4 LDA MODEA GET MODE FLAGS
002.167 346 100 784 ANI MA.ICM SEE IF ALREADY IN INSERT MODE
002.171 076 300 785 MVI A,EICSEQ+ESCF ENTER INSERT MODE
002.173 312 226 001 786 JZ KCE2 IF NOT ALREADY IN INSERT MODE
787
002.176 076 317 788 MVI A,XICSEQ+ESCF ELSE, EXIT INSERT MODE
002.200 303 226 001 789 JMP KCE2
790
002.203 172 791 KCE10.5 MOV A,D WAS 'M', SEE IF FROM THE 3 KEY (DELETE LINE)
002.204 346 177 792 ANI 01111111B TOSS CONTROL BIT
002.206 376 023 793 CPI 023Q 3 KEY?
002.210 176 794 MOV A,M REPLACE TABLE VALUE IN A
002.211 312 226 001 795 JZ KCE2 IF FROM 3 KEY GO PLACE 'ESC','M' IN FIFO
796
797 * HAVE A "KEYPAD ALTERNATE MODE" CHARACTER
798 * PLACE AN 'ESC' A '?' (OR '0' IF IN ANSI MODE) AND 7 LSB
799 * FROM TABLE IN FIFO
800 *
002.214 365 801 KCE11 PUSH PSW SAVE TABLE CHARACTER
002.215 076 033 802 MVI A,ESC PLACE 'ESC' IN FIFO
002.217 315 375 013 803 CALL PCOFT
002.222 072 310 100 804 LDA MODEB GET MODE FLAGS
002.225 346 040 805 ANI MB,ANSI IN ANSI MODE?
002.227 076 077 806 MVI A,'?' FOR HEATH
002.231 050 002 807 JR Z,KCE11.5 IF IN HEATH MODE
808
002.233 076 117 809 MVI A,'0' FOR ANSI
002.235 315 375 013 810 KCE11.5 CALL PCOFT PLACE IN FIFO
002.240 361 811 POP PSW GET TABLE VALUE BACK
002.241 346 177 812 ANI 01111111B TOSS ESC BIT
002.243 303 375 013 813 JMP PCOFT PLACE LAST CHARACTER IN FIFO
814
815 * ENCODE KEY VALUES FOR THE SCROLL KEY (037Q)
816 *
002.246 376 037 817 KCE12 CPI 037Q WAS IT THE SCROLL KEY?
002.250 040 014 818 JR NZ,KCE13 IF NOT THE SCROLL KEY
819
002.252 041 313 100 820 LXI H,HSMC ELSE, POINT TO THE HSM LINE COUNTER
821 * BIT IB,KSBE SEE IF SHIFTED SCROLL
002.255 313 103 822 DB I.BITA,I.BITB!IB,KSBE
002.257 040 002 823 JR NZ,KCE12.5 IF SHIFTED

```



```

      824
002.261 064      825      INR      M      INCREMENT LINE COUNTER FOR ONE MORE LINE
002.262 311      826      RET      EXIT
      827
002.263 066 030  828 KCE12.5 MVI      M,24      SET LINE COUNTER TO 24 LINES
002.265 311      829      RET      EXIT
      830
      831 *      AT LAST! SIMPLE ASCII KEYS!!!
      832 *      ENCODE KEY VALUES FOR 0400 THRU 1770
      833 *
      834 *KCE13 BIT      IB.KSB,E      SHIFT KEY STRUCK?
002.266 313 103  835 KCE13 DB      I.BITA,I.BITB,IB.KSB,IR.E
002.270 050 014  836 JR      Z,KCE13.5      IF NO SHIFT
      837
      838      PUSH      D      SAVE KEYBOARD VALUES
002.272 325      839      LXI      H,KAE3      ELSE POINT TO EQUIV TABLE #3 FOR SPEC SHIFTS
002.273 041 066 003
002.276 026 015  840      MVI      D,KAE3L      SET TABLE LENGTH
002.300 036 002  841      MVI      E,KAE3W      SET TABLE WIDTH
002.302 315 363 015  842      CALL      STAB      SEARCH TABLE
002.305 321      843      POP      D      (D,E) = KEYBOARD VALUES
      844
      845 *KCE13.5 BIT      IB.CPLK,E      TEST FOR 'CAPS LOCK' ON
002.306 313 113  846 KCE13.5 DB      I.BITA,I.BITB,IB.CPLK,IR.E
002.310 050 012  847 JR      Z,KCE14      IF CAPS LOCK NOT ON
      848
      849      CPI      'a'      TEST FOR < LOWER CASE A
002.312 376 141  850 JR      C,KCE14      IF LESS THAN A LOWER CASE CHARACTER
002.314 070 006
      851
      852      CPI      '{'      TEST FOR < LEFT BRACE
002.316 376 173  853 JR      NC,KCE14      IF GREATER THAN A LOWER CASE CHARACTER
002.320 060 002
      854
      855      ANI      11011111B      IS LOWER CASE, MAKE IT UPPER CASE
002.322 346 337  856
      857 *KCE14 BIT      IB.KCB,D      TEST FOR 'CONTROL' KEY
002.324 313 172  858 KCE14 DB      I.BITA,I.BITB,IB.KCB,IR.D
002.326 312 375 013  859 JZ      PCOFT      IF CONTROL NOT STRUCK
      860
      861      CPI      '@'      NO CONTROL CODES IF < 1000
002.331 376 100  862 JC      PCOFT      IF < 1000
002.333 332 375 013
      863
      864      CPI      '{'      NO CONTROL CODES IF > 1720
002.336 376 173  865 JNC      PCOFT      IF > 1720
002.340 322 375 013
      866
      867      ANI      00011111B      ELSE FORM CONTROL CODE
002.343 346 037  868 JMP      PCOFT      GO PLACE CODE IN FIFO
002.345 303 375 013

```

```

870 **      KEYBOARD TO ASCII EQUIVALENCE TABLES
871 *

```

873 * *KAE1* IS A LOOK UP TABLE FOR FUNCTION KEY VALUES

874 *

875 * TABLE ENTRIES ARE: KEY VALUE FOLLOWED BY ASCII VALUE. *ESCF* IS USED

876 * TO SIGNAL THAT AN ESCAPE CODE IS TO PRECEED THE SEVEN BIT ASCII VALUE

877

878

002.350

879 KAE1

EQU

*

002.350 000 323

880

DB

0,ESCF+'S'

KEY VALUE 0 = ESC-S

002.352 001 324

881

DB

1,ESCF+'T'

KEY VALUE 1 = ESC-T

002.354 002 325

882

DB

2,ESCF+'U'

KEY VALUE 2 = ESC-U

002.356 003 326

883

DB

3,ESCF+'V'

KEY VALUE 3 = ESC-V

002.360 004 327

884

DB

4,ESCF+'W'

KEY VALUE 4 = ESC-W

002.362 005 312

885

DB

5,ESCF+'J'

KEY VALUE 5 = ESC-J

002.364 006 320

886

DB

6,ESCF+'P'

KEY VALUE 6 = ESC-P

002.366 007 321

887

DB

7,ESCF+'Q'

KEY VALUE 7 = ESC-Q

002.370 016 322

888

DB

16Q,ESCF+'R'

KEY VALUE 13Q = ESC-R

000.002

889 KAE1W

EQU

2

TABLE IS TWO BYTES WIDE

000.011

890 KAE1L

EQU

*-KAE1/KAE1W

892 * KAE2 CONTAINS THE ASCII VALUES FOR THE VARIOUS MODES OF

893 * THE 12 KEY NUMERIC KEY PAD. TABLE ENTRIES ARE: KEY VALUE,

894 * UNSHIFTED ASCII, SHIFTED ASCII, KEYPAD ALTERNATE MODE ASCII,

895 * AND KEYPAD ALTERNATE MODE SHIFTED ASCII.

896 *

002.372

897 KAE2

EQU

*

002.372 020 060 060

898

DB

20Q,'0','0',ESCF+'P',ESCF+'P'

P = LOWER CASE P

002.377 021 061 314

899

DB

21Q,'1',ESCF+'L',ESCF+'a',ESCF+'L'

a = LOWER CASE Q

003.004 022 062 302

900

DB

22Q,'2',ESCF+'B',ESCF+'r',ESCF+'B'

r = LOWER CASE R

003.011 023 063 315

901

DB

23Q,'3',ESCF+'M',ESCF+'s',ESCF+'M'

s = LOWER CASE S

003.016 024 064 304

902

DB

24Q,'4',ESCF+'D',ESCF+'t',ESCF+'D'

t = LOWER CASE T

003.023 025 065 310

903

DB

25Q,'5',ESCF+'H',ESCF+'u',ESCF+'H'

u = LOWER CASE U

003.030 026 066 303

904

DB

26Q,'6',ESCF+'C',ESCF+'v',ESCF+'C'

v = LOWER CASE V

003.035 027 067 300

905

DB

27Q,'7',ESCF+'@',ESCF+'w',ESCF+'@'

w = LOWER CASE W

003.042 030 070 301

906

DB

30Q,'8',ESCF+'A',ESCF+'x',ESCF+'A'

x = LOWER CASE X

003.047 031 071 316

907

DB

31Q,'9',ESCF+'N',ESCF+'y',ESCF+'N'

y = LOWER CASE Y

003.054 032 056 056

908

DB

32Q,'.',',',',',ESCF+'n',ESCF+'n'

n = LOWER CASE N

003.061 034 015 015

909

DB

34Q,CR,CR,ESCF+'M',ESCF+'M'

000.005

910 KAE2W

EQU

5

TABLE WIDTH = FIVE BYTES

000.014

911 KAE2L

EQU

*-KAE2/KAE2W

913 * *KAE3* CONTAINS SHIFT VALUES FOR KEYS WHERE THE SHIFTED VALUE OF THE

914 * KEY CANNOT BE FORMED BY A NORMAL ASCII BIT MASK SHIFT

915 *

916 * TABLE ENTRIES ARE: UNSHIFTED VALUE FOLLOWED BY THE SHIFTED VALUE

917

918

003.066

919 KAE3

EQU

*

003.066 047 042

920

DB

''',',',',

003.070 055 137

921

DB

'-',',',-

003.072 060 051

922

DB

'0',',',')

003.074 062 100

923

DB

'2',',',@'

003.076 066 136

924

DB

'6',',',^'

KCE - KEYBOARD CHARACTER ENCODER

KAE3

09:15:37 30-MAY-80

003.100	067 046	925	DB	'7','8'
003.102	070 052	926	DB	'8','*'
003.104	071 050	927	DB	'9','('
003.106	073 072	928	DB	';','!'
003.110	075 053	929	DB	'=','+'
003.112	133 135	930	DB	'['','']'
003.114	140 176	931	DB	'\','~'
003.116	173 175	932	DB	'{'','}'
000.002		933 KAE3W	EQU	2
000.015		934 KAE3L	EQU	*-KAE3/KAE3W

TABLE WIDTH = 2 BYTES

```

937 ***      IFCP - INPUT FIFO CHARACTER PROCESSOR
938 *
939 *      *IFCP* INTERPRETS THE CHARACTER WHICH HAS BEEN RECEIVED (OR STRUCK
940 *      ON THE KEYBOARD IF OFF-LINE OR KEYED AS A LOCAL FUNCTION) TO SEE IF
941 *      IT IS THE SECOND CHARACTER IN AN ESCAPE SEQUENCE, A CONTROL CHARACTER
942 *      OR A CHARACTER TO BE DISPLAYED. IF THE CHARACTER IS PART OF AN
943 *      ESCAPE SEQUENCE WHICH CANNOT BE FOUND IN *ESCTAB* THE ESCAPE SEQUENCE
944 *      FLAG IS CLEARED AND THE CHARACTER IS DISPLAYED. IF THE CHARACTER IS
945 *      A CONTROL CHARACTER, AND CANNOT BE FOUND IN *CTLTAB*, THE CHARACTER IS
946 *      DISCARDED. IF THE CHARACTER IS FOUND IN THE APPROPRIATE TABLE, THE
947 *      PROGRAM COUNTER IS SET TO THE ASSOCIATED ADDRESS.
948 *
949 *
950 *      ENTRY      (A) = CHARACTER FROM INPUT FIFO
951 *
952 *      EXIT      NONE
953 *
954 *      USES      A,B,C,D,E,H,L,F
955 *
956 *
003.120 127      957 IFCP      MOV      D,A          SAVE CHARACTER
003.121 072 311 100 958      LDA      MODEI        GET MODE FLAGS
959 *      BIT      IB,XOFF,A      SEE IF XOFF SENT
003.124 313 147      960      DB      I,BIT A,I,BIT B!IB,XOFF!IR,A
003.126 050 025      961      JR      Z,IFCP0.5      IF NO XOFF HAS BEEN SENT
962 *
003.130 137      963      MOV      E,A          SAVE MODE FLAGS
003.131 072 241 100 964      LDA      IFC          GET INPUT FIFO COUNTER
003.134 376 140      965      CPI      IFMAX-32      SEE IF AT LEAST 32 BYTES ARE FREE
003.136 173      966      MOV      A,E          GET MODE FLAGS BACK
003.137 060 014      967      JR      NC,IFCP0.5      IF NOT ENOUGH BYTES OPEN
968 *
003.141 346 357      969      ANI      255-MI,XOFF      RESET XOFF FLAG
003.143 062 311 100 970      STA      MODEI
003.146 137      971      MOV      E,A
003.147 076 021      972      MVI      A,XON          SEND XON TO HOST
003.151 315 375 013 973      CALL     PCOFT
003.154 173      974      MOV      A,E          GET MODE FLAGS BACK
975 *
976 *IFCP0.5 BIT      IB,PWE,A          SEE IF PREVIOUS CHARACTER WAS AN ESCAPE CODE
003.155 313 107      977 IFCP0.5 DB      I,BIT A,I,BIT B!IB,PWE!IR,A
003.157 172      978      MOV      A,D          (A) = CHARACTER
003.160 050 046      979      JR      Z,IFCP1          IF CHARACTER IS NOT PART OF AN ESCAPE SEQ.
980 *
981 *      CHARACTER IS PART OF AN ESCAPE SEQUENCE
982 *
003.162 072 311 100 983      LDA      MODEI          GET MODE AGAIN
003.165 346 376      984      ANI      377Q-MI,PWE      CLEAR *PREVIOUS WAS AN ESCPAE* FLAG
003.167 062 311 100 985      STA      MODEI
003.172 072 310 100 986      LDA      MODEB          GET MODE B FLAGS
003.175 346 040      987      ANI      MB,ANSI          SEE IF IN ANSI MODE
003.177 172      988      MOV      A,D          (A) = CHARACTER
003.200 050 011      989      JR      Z,IFCP0.7      IF NOT IN ANSI MODE
990 *
003.202 041 340 004 991      LXI      H,AESCT          (H,L) = ANSI ESCAPE TABLE
003.205 026 004      992      MVI      D,AESCTL          (D) = TABLE LENGTH

```

IFCP - INPUT FIFO CHARACTER PROCESSOR

09:15:38 30-MAY-80

```

003,207 036 003 993 MVI E,AESCTW (E) = TABLE WIDTH
003,211 030 007 994 JR IFCP0.9 SEARCH TABLE
995
003,213 041 134 004 996 IFCP0.7 LXI H,ESCTAB (H,L) = HEATH ESCAPE SEQUENCE TABLE
003,216 026 054 997 MVI D,ESCTABL (D) = TABLE LENGTH
003,220 036 003 998 MVI E,ESCTABW (E) = TABLE WIDTH
999
003,222 315 363 015 1000 IFCP0.9 CALL STAB SEARCH TABLE
003,225 060 160 1001 JR NC,IFCP3 IF A MATCH WAS FOUND IN THE TABLE
1002
003,227 311 1003 RET ELSE, FORGET ABOUT THIS CHARACTER AND EXIT
1004
003,230 376 012 1005 IFCP1 CPI LF IS CHARACTER A LINE FEED?
003,232 040 130 1006 JR NZ,IFCP1.9 IF NOT A LINE FEED
1007
1008 * CHARACTER IS A LINE FEED, CHECK FOR HOLD SCREEN MODE
1009 *
003,234 072 307 100 1010 LDA MODEA GET MODEA FLAGS
003,237 346 001 1011 ANI MA,HSM
003,241 312 112 007 1012 JZ PLFCR IF NOT IN HOLD SCREEN MODE, GO DO LINE FEED
1013
1014 * CHARACTER IS A LINE FEED AND TERMINAL IS IN THE HOLD SCREEN MODE,
1015 * THE TERMINAL OPERATION WILL NOT CHANGE UNLESS OR UNTIL THE 24TH
1016 * LINE IS REACHED. A *SCROLL* KEY FROM THE KEYBOARD WILL CAUSE ONE
1017 * MORE LINE TO BE DISPLAYED. A SHIFTED *SCROLL* KEY WILL CAUSE 24
1018 * LINES TO BE INPUT AND DISPLAYED. IF THE INPUT FIFO IS FULL, THE
1019 * CONTENTS WILL BE DISPLAYED AND ALL CHARACTERS UP TO THE NEXT LINE
1020 * FEED WILL BE DISPLAYED.
1021 *
003,244 072 273 100 1022 LDA CURVP GET VERTICAL POSITION
003,247 376 027 1023 CPI 23 SEE IF ON LAST LINE
003,251 302 112 007 1024 JNZ PLFCR IF NOT LAST LINE, DON'T HOLD YET
1025
003,254 041 313 100 1026 LXI H,HSMCLC POINT TO HOLD SCREEN MODE LINE COUNTER
003,257 065 1027 DCR M DECREMENT COUNTER
003,260 302 112 007 1028 JNZ PLFCR IF NOT ZERO, DO THIS LF AND WAIT FOR NEXT
1029
003,263 076 023 1030 MVI A,XOFF SEND CTL-S TO HOST
003,265 315 375 013 1031 CALL PCOFT PLACE IN OUTPUT FIFO
003,270 315 045 000 1032 CALL MAINA TURN ON XMIT INTERRUPT
1033
003,273 315 107 012 1034 IFCP1.1 CALL FVKE GET NEXT VALUE FROM KEYBOARD FIFO
003,276 060 022 1035 JR NC,IFCP1.5 IF A KEY WAS STRUCK
1036
003,300 315 111 016 1037 CALL UCP UPDATE CURSOR
003,303 072 241 100 1038 IFCP1.3 LDA IFC SEE IF INPUT FIFO IS FULL
003,306 376 200 1039 CPI IFMAX
003,310 040 361 1040 JR NZ,IFCP1.1 IF NOT FULL, CHECK ON KEYBOARD AGAIN
1041
003,312 076 001 1042 MVI A,1 ELSE, SET COUNTER TO INPUT ONE MORE LINE
003,314 062 313 100 1043 STA HSMCLC
003,317 303 112 007 1044 JMP PLFCR DO THE LINE FEED AND EMPTY THE FIFO
1045
003,322 172 1046 IFCP1.5 MOV A,D GET KEY VALUE
003,323 346 177 1047 ANI 01111111B TOSS THE CONTROL BIT
003,325 376 037 1048 CPI SCRL WAS KEY THE SCROLL KEY?

```



```

003.327 050 010      1049      JR      Z,IFCP1.7      IF SCROLL KEY
                                1050
003.331 315 117 001  1051      CALL     KCE          ELSE ENCODE THE ASCII VALUE
003.334 315 045 000  1052      CALL     MAINA        SEE IF THERE IS A CHARACTER TO OUTPUT
003.337 030 342      1053      JR      IFCP1.3        SEE IF KEYSTRIKE FILLED THE INPUT FIFO
                                1054
003.341      1055      IFCP1.7 EQU      *
                                1056      *      BIT      IB,KSB,E      SEE IF THIS WAS A SHIFTED SCROLL KEY
003.341 313 103      1057      DB      I.BITA,I.BITB!IB.KSB!IR.E
003.343 076 001      1058      MVI      A,1          SET LINE COUNTER TO ONE
003.345 050 002      1059      JR      Z,IFCP1.8      IF SCROLL KEY WAS NOT SHIFTED
                                1060
003.347 076 030      1061      MVI      A,24          ELSE, SET LINE COUNTER TO 24
003.351 062 313 100  1062      IFCP1.8 STA     HSMCLC
003.354 315 112 007  1063      CALL     PLFCR          DO THE LINE FEED
003.357 076 021      1064      MVI      A,XON        SEND CTL-Q TO HOST FOR MORE CHARACTERS
003.361 303 375 013  1065      JMP      PCOFT
                                1066
003.364 376 177      1067      IFCP1.9 CPI      RUBOUT   CHECK FOR RUBOUT AND OTHER CONTROL CODES
003.366 050 004      1068      JR      Z,IFCP2        IF RUBOUT, SEE IF THERE IS A HANDLER
                                1069
003.370 376 040      1070      CPI      ' '          CHECK FOR OTHER CONTROL CODES
003.372 060 026      1071      JR      NC,IFCP4       IF NOT A CONTROL CODE
                                1072
                                1073      *      CHARACTER IS A CONTROL CHARACTER
                                1074      *
003.374 041 354 004  1075      IFCP2  LXI      H,CTLTAB   (H,L) = CONTROL CHARACTER TABLE
003.377 026 006      1076      MVI      D,CTLTABL   (B) = TABLE LENGTH
004.001 036 003      1077      MVI      E,CTLTABW   (C) = TABLE WIDTH
004.003 315 363 015  1078      CALL     STAB        SEARCH TABLE
004.006 330          1079      RC          IF NOT IN TABLE, TOSS IT AND EXIT
                                1080
                                1081      *      CHARACTER FOUND IN TABLE, GO TO ASSOCIATED ADDRESS
                                1082      *
004.007 137          1083      IFCP3  MOV      E,A          (E) = ADDRESS LSB
004.010 043          1084      INX      H
004.011 126          1085      MOV      D,M          (D) = ADDRESS MSB
004.012 353          1086      XCHG          (H,L) = ADDRESS OF SPECIAL ROUTINE
004.013 001 310 100  1087      LXI      B,MODEB   (B,C) = MODEB IN CASE OF A CHANGE
004.016 021 307 100  1088      LXI      D,MODEA   (D,E) = MODEA IN CASE OF A CHANGE
004.021 351          1089      PCHL          (PC) = ROUTINE
                                1090
004.022 072 307 100  1091      IFCP4  LDA      MODEA   GET MODE FLAGS
004.025 346 002      1092      ANI      MA,GRPH   SEE IF IN GRAPHICS MODE
004.027 172          1093      MOV      A,D          (A) = CHARACTER
004.030 050 015      1094      JR      Z,IFCP6      IF NOT IN GRAPHICS MODE
                                1095
004.032 376 136      1096      CPI      136Q       IS CHARACTER IN THE GRAPHICS RANGE?
004.034 332 047 004  1097      JC      IFCP6      IF NOT IN GRAPHIC RANGE
                                1098
004.037 040 004      1099      JR      NZ,IFCP5     IF CHARACTER IS NOT 136Q
                                1100
004.041 076 177      1101      MVI      A,177Q      ELSE MAKE 136Q A 177Q
004.043 030 002      1102      JR      IFCP6      DISPLAY IT
                                1103
004.045 346 037      1104      IFCP5  ANI      00011111B  MAKE CHARACTER INTO A GRAPHICS DISPLAY CHAR.

```



```

1105
1106 * CHARACTER IS A DISPLAYABLE CHARACTER
1107 *
004.047 127 1108 IFCP6 MOV D,A SAVE CHARACTER IN D
004.050 072 307 100 1109 LDA MODEA GET MODE FLAGS
004.053 346 200 1110 ANI MA,RV MASK FOR REVERSE VIDEO FLAG
004.055 262 1111 ORA D ADD FLAG STATUS TO CHARACTER
000.000 1112 ERRNZ MA,RV-10000000B M,RV MUST BE BIT 7
004.056 365 1113 PUSH PSW SAVE CHARACTER
004.057 072 307 100 1114 LDA MODEA GET MODE AGAIN
004.062 346 100 1115 ANI MA,ICH CHECK FOR INSERT CHARACTER MODE
004.064 304 165 014 1116 CNZ PIC IF SELECTED, DO AN INSERT CHARACTER
1117
004.067 361 1118 POP PSW ELSE, GET CHARACTER AND DISPLAY IT
004.070 052 274 100 1119 LHLD CURAD GET CURSOR ADDRESS
004.073 167 1120 MOV M,A PUT CHARACTER AT CURSOR
004.074 043 1121 INX H POINT TO NEXT COLUMN
004.075 174 1122 MOV A,H STAY IN VIDEO RAM
004.076 366 370 1123 ORI VRAMS/256
004.100 147 1124 MOV H,A
004.101 072 272 100 1125 LDA CURHP GET CURRENT HORIZONTAL POSITION
004.104 376 117 1126 CPI 79 AT END OF LINE?
004.106 040 014 1127 JR NZ,IFCP7 IF NOT AT END OF LINE
1128
004.110 072 310 100 1129 LDA MODER ELSE, GET MODE FLAGS
004.113 346 004 1130 ANI MB,WRAP SEE IF TO WRAP AROUND
1131
004.115 310 1132 RZ IF NO WRAP
1133
1134 * LDA CURVP GET LINE NUMBER
1135 * CPI 23 < 22?
1136 * RNC IF ON LAST LINE(S)
1137
004.116 315 354 006 1138 CALL PLF ELSE, LFCR
004.121 303 013 014 1139 JMP FCR
1140
004.124 074 1141 IFCP7 INR A ELSE, POINT TO NEXT COLUMN
004.125 062 272 100 1142 STA CURHP
004.130 042 274 100 1143 SHLD CURAD UPDATE CURAD
1144
004.133 311 1145 RET EXIT

```

```

1147 ** ESCTAB - ESCAPE SEQUENCE TABLE
1148 *
1149 * *ESCTAB* CONTAINS THE SECOND CHARACTER OF ALL ESCAPE SEQUENCES
1150 * THE H19 WILL RESPOND TO,
1151 *
1152 * TABLE ENTRIES ARE: THE SECOND CHARACTER OF THE ESCAPE SEQUENCE,
1153 * FOLLOWED BY THE ADDRESS OF THE ROUTINE WHICH PERFORMS THE
1154 * REQUESTED OPERATION
1155
1156
004.134 1157 ESCTAB EQU - *

```

004.134	074	1158			
004.135	310 010	1159	DB	'<'	ESC <
		1160	DW	EAM	ENTER ANSI MODE
		1161			
004.137	033	1162	DB	ESC	ESC ESC
004.140	005 016	1163	DW	SPWE	SET PREVIOUS WAS AN ESCAPE AGAIN
		1164			
004.142	075	1165	DB	'='	ESC =
004.143	113 011	1166	DW	EKAM	ENTER KEYPAD ALTERNATE MODE
		1167			
004.145	076	1168	DB	'>'	ESC >
004.146	311 016	1169	DW	XKAM	EXIT KEYPAD ALTERNATE MODE
		1170			
004.150	043	1171	DB	'#'	ESC #
004.151	252 017	1172	DW	XMTF	TRANSMIT PAGE
		1173			
000.100		1174	EICSEQ	EQU	ENTER INSERT CHARACTER MODE SEQUENCE
004.153	100	1175	DB	EICSEQ	ESC @
004.154	107 011	1176	DW	EICH	SET INSERT CHARACTER MODE
		1177			
004.156	101	1178	DB	'A'	ESC A
004.157	227 007	1179	DW	CUP	CURSOR UP
		1180			
004.161	102	1181	DB	'B'	ESC B
004.162	346 006	1182	DW	CDN	CURSOR DOWN
		1183			
004.164	103	1184	DB	'C'	ESC C
004.165	201 007	1185	DW	CRT	CURSOR RIGHT
		1186			
004.167	104	1187	DB	'D'	ESC D
004.170	126 007	1188	DW	CLFT	CURSOR LEFT
		1189			
004.172	105	1190	DB	'E'	ESC E
004.173	020 010	1191	DW	CLR	CLEAR DISPLAY
		1192			
004.175	106	1193	DB	'F'	ESC F
004.176	061 011	1194	DW	EGM	ENTER GRAPHICS MODE
		1195			
004.200	107	1196	DB	'G'	ESC G
004.201	275 016	1197	DW	XGM	EXIT GRAPHICS MODE
		1198			
004.203	110	1199	DB	'H'	ESC H
004.204	271 015	1200	DW	SCH	PERFORM CURSOR HOME
		1201			
004.206	111	1202	DB	'I'	ESC I
004.207	234 007	1203	DW	PRLF	PERFORM REVERSE LINE FEED
		1204			
004.211	112	1205	DB	'J'	ESC J
004.212	317 011	1206	DW	ERM	ERASE TO END OF MEMORY (PAGE)
		1207			
004.214	113	1208	DB	'K'	ESC K
004.215	277 011	1209	DW	EOL	ERASE TO END OF LINE
		1210			
004.217	114	1211	DB	'L'	ESC L
004.220	234 014	1212	DW	PIL	PERFORM INSERT LINE
		1213			

IFCP - INPUT FIFO CHARACTER PROCESSOR

ESCTAB

09:15:44 30-MAY-80

004.222	115	1214	DB	'M'	ESC M
004.223	075 014	1215	DW	PDL	PERFORM DELETE LINE
		1216			
004.225	116	1217	DB	'N'	ESC N
004.226	027 014	1218	DW	PDC	PERFORM DELETE CHARACTER
		1219			
000.117		1220	XICSEQ	EQU	EXIT INSERT CHARACTER MODE SEQUENCE
004.230	117	1221	DB	XICSEQ	ESC O
004.231	305 016	1222	DW	XICH	EXIT INSERT CHARACTER MODE
		1223			
004.233	131	1224	DB	'Y'	ESC Y
004.234	162 013	1225	DW	PCA	PERFORM CURSOR ADDRESSING
		1226			
004.236	132	1227	DB	'Z'	ESC Z
004.237	366 012	1228	DW	IDT	IDENTIFY TERMINAL
		1229			
004.241	133	1230	DB	'C'	ESC C
004.242	076 011	1231	DW	EHSN	ENTER HOLD SCREEN MODE
		1232			
004.244	134	1233	DB	'\'	ESC \
004.245	301 016	1234	DW	XHSM	EXIT HOLD SCREEN MODE
		1235			
004.247	135	1236	DB	'J'	ESC J
004.250	326 016	1237	DW	XMT25	TRANSMIT 25TH LINE (IF ENABLED)
		1238			
004.252	142	1239	DB	'b'	ESC b (LOWER CASE B)
004.253	315 010	1240	DW	EBD	ERASE BEGINNING OF DISPLAY
		1241			
		1242			
004.255	152	1243	DB	'j'	ESC j (LOWER CASE J)
004.256	132 015	1244	DW	SCP	SAVE CURSOR POSITION
		1245			
004.260	153	1246	DB	'k'	ESC k (LOWER CASE K)
004.261	314 015	1247	DW	USCP	UNSAVE CURSOR POSITION
		1248			
004.263	154	1249	DB	'l'	ESC l (LOWER CASE L)
004.264	051 011	1250	DW	EEL	ERASE ENTIRE LINE
		1251			
004.266	156	1252	DB	'n'	ESC n (LOWER CASE N)
004.267	153 007	1253	DW	CPR	CURSOR POSITION REPORT
		1254			
004.271	157	1255	DB	'o'	ESC o (LOWER CASE O)
004.272	352 010	1256	DW	EBL	ERASE BEGINNING OF LINE
		1257			
004.274	160	1258	DB	'p'	ESC p (LOWER CASE P)
004.275	361 011	1259	DW	ERVH	ENTER REVERSE VIDEO MODE
		1260			
004.277	161	1261	DB	'q'	ESC q (LOWER CASE Q)
004.300	325 017	1262	DW	XRVM	EXIT REVERSE VIDEO MODE
		1263			
004.302	162	1264	DB	'r'	ESC r (LOWER CASE R)
004.303	157 012	1265	DW	SBR	SET BAUD RATE
		1266			
		1267			
004.305	164	1268	DB	't'	ESC t (LOWER CASE T)
004.306	136 011	1269	DW	EKSM	ENTER KEYPAD SHIFTED MODE

IFCP - INPUT FIFO CHARACTER PROCESSOR

ESCTAB

09:15:45 30-MAY-80

	1270				
004.310 165	1271	DB	'u'	ESC u (LOWER CASE U)	
004.311 316 016	1272	DW	XKSM	EXIT KEYPAD SHIFTED MODE	
	1273				
004.313 166	1274	DB	'v'	ESC v (LOWER CASE V)	
004.314 153 016	1275	DW	WEOL	WRAP AROUND AT END OF LINE	
	1276				
004.316 167	1277	DB	'w'	ESC w (LOWER CASE W)	
004.317 216 010	1278	DW	DEOL	DISCARD AT END OF LINE	
	1279				
004.321 170	1280	DB	'x'	ESC x (LOWER CASE X)	
004.322 141 015	1281	DW	SMS	HEATH SET MODE	
	1282				
004.324 171	1283	DB	'y'	ESC y (LOWER CASE Y)	
004.325 122 015	1284	DW	RMS	HEATH RESET MODE	
	1285				
004.327 172	1286	DB	'z'	ESC z (LOWER CASE Z)	
004.330 000 013	1287	DW	RAMP	RESET ALL MODES TO POWER UP CONFIGURATION	
	1288				
004.332 173	1289	DB	'{'	ESC { (LEFT BRACE)	
004.333 125 011	1290	DW	EKI	ENABLE KEYBOARD INPUT	
	1291				
004.335 175	1292	DB	'}'	ESC } (RIGHT BRACE)	
004.336 226 010	1293	DW	DKI	DISABLE KEYBOARD INPUT	
	1294				
000.003	1295	ESCTABW EQU	3	TABLE IS THREE BYTES WIDE	
000.054	1296	ESCTABL EQU	*-ESCTAB/ESCTABW		

	1298	*	AESCT - ANSI ESCAPE TABLE		
	1299	*			
	1300	*	*AESCT* CONTAINS THE SECOND CHARACTER OF THE ANSI ESCAPE TABLES		
	1301	*			
	1302	*	TABLE ENTRYS ARE THE SECOND CHARACTER FOLLOWED BY THE ADDRESS		
	1303	*	OF THE ROUTINE FOR THE REQUESTED FUNCTION		
	1304				
004.340	1305	AESCT EQU	*		
	1306				
004.340 075	1307	DB	'='	ESC =	
004.341 113 011	1308	DW	EKAM	ENTER KEYPAD ALTERNATE MODE	
	1309				
004.343 076	1310	DB	'>'	ESC >	
004.344 311 016	1311	DW	XKAM	EXIT KEYPAD ALTERNATE MODE	
	1312				
004.346 115	1313	DB	'M'	ESC M	
004.347 234 007	1314	DW	PRLF	REVERSE INDEX (REVERSE LINE FEED)	
	1315				
004.351 133	1316	DB	'['	ESC [	
004.352 143 011	1317	DW	ELB	ESCAPE LEFT BRACKET	
	1318				
000.003	1319	AESCTW EQU	3	TABLE IS THREE BYTES WIDE	
000.004	1320	AESCTL EQU	*-AESCT/AESCTW		

```
1322 * CTLTAB - CONTROL CHARACTER TABLE
1323 *
1324 * *CTLTAB* CONTAINS ALL CONTROL CODES WHICH THE H19 WILL RESPOND TO
1325 *
1326 * TABLE ENTRYS ARE: THE CONTROL CHARACTER FOLLOWED BY THE ADDRESS
1327 * OF THE ROUTINE WHICH PERFORM THE REQUESTED FUNCTION
1328
1329
004.354 1330 CTLTAB EQU *
004.354 007 1331 DB BELL BELL
004.355 223 010 1332 DW DING DING THE BELL
1333
004.357 010 1334 DB BS BACKSPACE
004.360 126 007 1335 DW PBS PERFORM A BACKSPACE
1336
004.362 011 1337 DB HT HORIZONTAL TABULATION
004.363 036 016 1338 DW TAB TAB TO NEXT EIGHTH COLUMN
1339
004.365 012 1340 DB LF LINE FEED
004.366 112 007 1341 DW PLFCR PERFORM LINE FEED AND/OR CARRIAGE RETURN
1342
004.370 015 1343 DB CR CARRIAGE RETURN
004.371 003 014 1344 DW PCRLF PERFORM CARRIAGE RETURN AND/OR LINE FEED
1345
004.373 033 1346 DB ESC ESCAPE
004.374 005 016 1347 DW SPWE SET PREVIOUS WAS AN ESCAPE FLAG
000.003 1348 CTLTABW EQU 3 TABLE IS THREE BYTES WIDE
000.006 1349 CTLTABL EQU *-CTLTAB/CTLTABW
```

1352 *** GENERAL USE SUBROUTINES

1354 ** A1M - ANSI MODE #1

1355 *

1356 * *A1M* INPUTS THE PARAMETER STRING AND FINAL CHARACTER FOR THE

1357 * ESC [? SEQUENCE

1358 *

1359 *

1360 * ENTRY (B) = ZERO IF NO PN WAS INPUT

1361 * (D,E) = PSDW

1362 *

1363 * EXIT (A) = FINAL CHARACTER

1364 * (B) = ZERO IF NO PN WAS INPUT

1365 * (D,E) = PSDW

1366 *

1367 * USES A,B,C,H,L,F

1368

1369

004.376 170

1370 A1M MOV A,B SEE IF PN WAS INPUT

004.377 267

1371 ORA A

005.000 300

1372 RNZ IF PN ALREADY INPUT, ILLEGAL, EXIT

1373

005.001 315 346 014

1374 CALL PSD INPUT PARAMETER STRING NOW

1375

1376 * FINAL CHARACTER MUST BE A LOWER CASE H OR A LOWER CASE L

1377 *

005.004 376 150

1378 CPI 'h' FINAL = LOWER CASE H?

005.006 050 005

1379 JR Z,A1SM IF H, IS SET MODE SEQUENCE

1380

005.010 376 154

1381 CPI 'l' FINAL = LOWER CASE L?

005.012 050 033

1382 JR Z,A1RM IF L, IS RESET MODE SEQUENCE

1383

005.014 311

1384 RET IF NEITHER, EXIT

1386 * A1SM - ANSI MODE #1 SET MODE SEQUENCE

1387 *

1388 * *A1SM* SET THE SPECIFIED MODE(S)

1389 *

1390 *

1391 * ENTRY (B) = ZERO IF NO PN WAS INPUT

1392 * (D,E) = PSDW

1393 *

1394 * EXIT NONE

1395 *

1396 * USES A,B,C,H,L,F

1397

1398

005.015 170

1399 A1SM MOV A,B SEE IF PN WAS INPUT

005.016 267

1400 ORA A

005.017 310

1401 RZ IF NO PN, EXIT

1402


```

005.020 353      1403      XCHG
005.021 001 310 100 1404      LXI      B,MODEB      (B,C) = MODEB
005.024 176      1405 A1SM1  MOV      A,M      GET PN
005.025 376 002      1406      CPI      2      PN = 2?
005.027 314 065 011 1407      CZ      EHM      IF 2, ENTER HEATH MODE
                                1408
005.032 176      1409      MOV      A,M      GET PN
005.033 376 007      1410      CPI      7      PN = 7?
005.035 314 153 016 1411      CZ      WEOL      IF 7, SET WRAP AROUND AT END OF LINE
                                1412
005.040 176      1413      MOV      A,M      GET PN
005.041 376 150      1414      CPI      'h'      PN = FINAL?
005.043 310      1415      RZ      IF FINAL CHARACTER, EXIT
                                1416
005.044 043      1417      INX      H      ELSE, POINT TO NEXT PN
005.045 030 355      1418      JR      A1SM1      DECODE IT

```

```

1420 *      A1RM - ANSI MODE #1 RESET MODE SEQUENCE
1421 *
1422 *      *A1RM* RESETS THE MODE(S) SPECIFIED BY PN
1423 *
1424 *
1425 *      ENTRY      (B) = ZERO IF NO PN WAS INPUT
1426 *      (D,E) = PSDW
1427 *
1428 *      EXIT      NONE
1429 *
1430 *      USES      A,B,C,H,L,F
1431 *
1432
005.047 170      1433 A1RM  MOV      A,B      SEE IF PN WAS INPUT
005.050 267      1434      ORA      A
005.051 310      1435      RZ      IF NO PN, EXIT
                                1436
005.052 353      1437      XCHG      (H,L) = PSDW
005.053 001 310 100 1438      LXI      B,MODEB
005.056 176      1439 A1RM1  MOV      A,M
005.057 376 007      1440      CPI      7      PN = 7?
005.061 314 216 010 1441      CZ      DEOL      IF 7, SET DISCARD PAST END OF LINE
                                1442
005.064 176      1443      MOV      A,M      GET PN
005.065 376 154      1444      CPI      '1'      PN = FINAL?
005.067 310      1445      RZ      IF FINAL, EXIT
                                1446
005.070 043      1447      INX      H      ELSE, POINT TO NEXT PN
005.071 030 363      1448      JR      A1RM1

```

```
1450 **      A2M - ANSI MODE #2
1451 *
1452 *      *A2M* INPUTS THE PARAMETER STRING AND THE FINAL CHARACTER FOR
1453 *      THE SEQUENCE ESC [ >
1454 *
1455 *
1456 *      ENTRY      (B) = ZERO IF NO PN WAS INPUT
1457 *                  (D,E) = PSDW
1458 *
1459 *      EXIT      (A) = FINAL CHARACTER
1460 *                  (B) = ZERO IF NO PN WAS INPUT
1461 *                  (D,E) = PSDW
1462 *
1463 *      USES      A,B,C,D,E,H,L,F
1464 *
1465 *
005.073 170 1466 A2M  MOV  A,B      SEE IF PN WAS INPUT
005.074 267 1467      ORA  A
005.075 300 1468      RNZ      IF ALREADY INPUT, ILLEGAL, EXIT
1469 *
005.076 315 346 014 1470      CALL  PSD      INPUT PARAMETER STRING
005.101 376 150 1471      CPI   'h'      FINAL = LOWER CASE H?
005.103 050 005 1472      JR    Z,A2SM    IF H, GO SET MODE
1473 *
005.105 376 154 1474      CPI   'l'      FINAL = LOWER CASE L?
005.107 050 023 1475      JR    Z,A2RM    IF L, GO RESET MODE
1476 *
005.111 311 1477      RET      ELSE, EXIT

1479 *      A2SM - ANSI MODE #2 SET MODE SEQUENCE
1480 *
1481 *      *A2SM* SETS THE MODE(S) SPECIFIED BY PN FOR THE SEQUENCE ESC [ >
1482 *
1483 *
1484 *      ENTRY      (B) = ZERO IF NO PN WAS INPUT
1485 *                  (D,E) = PSDW
1486 *
1487 *      EXIT      NONE
1488 *
1489 *      USES      A,B,C,D,E,H,L,F
1490 *
005.112 170 1491 A2SM  MOV  A,B      SEE IF PN WAS INPUT
005.113 267 1492      ORA  A
005.114 310 1493      RZ      IF NO PN, EXIT
1494 *
005.115 041 205 015 1495 A2SM1 LXI   H,SMST    (H,L) = SET MODE SEQUENCE TABLE
005.120 032 1496      LDAX  D      GET PN
005.121 376 012 1497      CPI   10      < 10?
005.123 320 1498      RNC      IF OUT OF RANGE OR FINAL
1499 *
005.124 325 1500      PUSH  D      SAVE PN POINTER
005.125 315 166 015 1501      CALL  SMSB    SET MODE
005.130 321 1502      POP   D
005.131 023 1503      INX   D      POINT TO NEXT PN
```

005.132 030 361 1504 JR A2SM1

1506 * A2RM - ANSI MODE #2 RESET MODE SEQUENCE

1507 *

1508 * *A2RM* RESETS THE MODE(S) SPECIFIED BY PN FOR THE SEQUENCE ESC [>

1509 *

1510 *

1511 * ENTRY (B) = ZERO IF NO PN WAS INPUT

1512 * (D,E) = PSDW

1513 *

1514 * EXIT NONE

1515 *

1516 * USES A,B,C,D,E,H,L,F

1517

1518

005.134 170 1519 A2RM MOV A,B SEE IF PN WAS INPUT

005.135 267 1520 ORA A

005.136 310 1521 RZ IF NO PN

1522

005.137 041 227 015 1523 A2RM1 LXI H,RMST (H,L) = RESET MODE SEQUENCE TABLE

005.142 032 1524 LDAX D GET PN

005.143 376 012 1525 CPI 10 <9?

005.145 320 1526 RNC IF OUT OF RANGE OR FINAL

1527

005.146 325 1528 PUSH D SAVE PN POINTER

005.147 315 166 015 1529 CALL SMSB RESET MODE

005.152 321 1530 POP D

005.153 023 1531 INX D POINT TO NEXT PN

005.154 030 361 1532 JR A2RM1

1534 ** ACDN - ANSI CURSOR DOWN

1535 *

1536 * *ACDN* MOVES THE CURSOR TOWARD BOTTOM OF THE DISPLAY THE SPECIFIED

1537 * NUMBER OF LINES

1538 *

1539 *

1540 * ENTRY (B) = ZERO IF NO PN WAS INPUT

1541 * (D,E) = PSDW

1542 *

1543 * EXIT NONE

1544 *

1545 * USES A,B,C,D,E,H,L,F

1546

1547

005.156 170 1548 ACDN MOV A,B SEE IF THERE WAS A PN INPUT

005.157 267 1549 ORA A

005.160 312 346 006 1550 JZ CDN IF NO PN, DO ONLY ONE LINE

1551

005.163 032 1552 LDAX D GET PN

005.164 267 1553 ORA A SEE IF ZERO

005.165 312 346 006 1554 JZ CDN IF ZERO, DEFAULT TO ONE

```

1555
005.170 365      1556 ACDN1 PUSH PSW      SAVE PN
005.171 315 346 006 1557 CALL CDN      MOVE CURSOR DOWN ONE LINE
005.174 361      1558 POP PSW
005.175 075      1559 DCR A          PN TIMES
005.176 040 370  1560 JR NZ,ACDN1    IF NOT DONE
1561
005.200 311      1562 RET

```

```

1564 **      ACLFT - ANSI CURSOR LEFT
1565 *
1566 *      *ACLFT* MOVES THE CURSOR TO THE BEGINNING OF THE LINE PN TIMES
1567 *
1568 *
1569 *      ENTRY (B) = ZERO IF NO PN WAS INPUT
1570 *            (D,E) = PSDW
1571 *
1572 *      EXIT NONE
1573 *
1574 *      USES A,B,D,E,H,L,F
1575
1576
005.201 170      1577 ACLFT MOV A,B      SEE IF HAD PN
005.202 267      1578 ORA A
005.203 312 126 007 1579 JZ CLFT      IF NONE, DEFAULT TO ONE
1580
005.206 032      1581 LDAX D          GET PN
005.207 267      1582 ORA A          SEE IF ZERO
005.210 312 126 007 1583 JZ CLFT      IF ZERO, DEFAULT TO ONE
1584
005.213 107      1585 MOV B,A          SAVE COUNT
005.214 315 126 007 1586 ACLFT1 CALL CLFT      CURSOR LEFT ONE COLUMN
005.217 005      1587 DCR B
005.220 040 372  1588 JR NZ,ACLFT1    TIL DONE
1589
005.222 311      1590 RET

```

```

1592 **      ACPR - ANSI CURSOR POSITION REPORT
1593 *
1594 *      *ACPR* OUTPUTS THE CURRENT CURSOR POSITION IN THE ANSI FORM
1595 *            ** ESC [ P1 ; Pc R **
1596 *
1597 *
1598 *      ENTRY NONE
1599 *
1600 *      EXIT NONE
1601 *
1602 *      USES A,B,C,D,E,H,L,F
1603
1604

```

005.223	170	1605	ACPR	MOV	A,B	SEE IF PN WAS INPUT
005.224	267	1606		ORA	A	
005.225	310	1607		RZ		IF NO PN, ILLEGAL, EXIT
		1608				
005.226	032	1609		LDAX	D	GET PN
005.227	376 006	1610		CPI	6	MUST BE 6 FOR ACPR
005.231	300	1611		RNZ		IF NOT SIX, ILLEGAL, EXIT
		1612				
005.232	315 100 015	1613		CALL	PSOF	OUTPUT FIRST PART OF STRING
005.235	033 333	1614		DB	ESC,'C'+200Q	ESC C
005.237	072 273 100	1615		LDA	CURVP	GET CURRENT LINE NUMBER
005.242	074	1616		INR	A	HOME LINE = 1 FOR ANSI
005.243	315 014 011	1617		CALL	EDD	ENCODE DECIMAL DIGITS
005.246	172	1618		MOV	A,D	GET TENS DIGIT
005.247	267	1619		ORA	A	SEE IF A LEADING ZERO
005.250	050 005	1620		JR	Z,ACPR1	IF ZERO DROP IT
		1621				
005.252	366 060	1622		ORI	00110000B	MAKE BCD INTO ASCII
005.254	315 375 013	1623		CALL	PCOFT	ELSE, PLACE IN FIFO
005.257	173	1624	ACPR1	MOV	A,E	GET ONES DIGIT
005.260	366 060	1625		ORI	00110000B	MAKE BCD INTO ASCII
005.262	315 375 013	1626		CALL	PCOFT	PUT IN FIFO
		1627				
005.265	315 100 015	1628		CALL	PSOF	SEPARATE LINE FROM COLUMN
005.270	273	1629		DB	'R'+200Q	
		1630				
005.271	072 272 100	1631		LDA	CURHP	GET CURRENT COLUMN POSITION
005.274	074	1632		INR	A	HOME COLUMN = 1 FOR ANSI
005.275	315 014 011	1633		CALL	EDD	ENCODE DIGITS
005.300	172	1634		MOV	A,D	GET TENS
005.301	267	1635		ORA	A	SEE IF ZERO
005.302	050 005	1636		JR	Z,ACPR2	IF TENS IS ZERO, FORGET IT
		1637				
005.304	366 060	1638		ORI	00110000B	MAKE BCD INTO ASCII
005.306	315 375 013	1639		CALL	PCOFT	OUTPUT TENS
005.311	173	1640	ACPR2	MOV	A,E	GET ONES DIGIT
005.312	366 060	1641		ORI	00110000B	MAKE BCD INTO ASCII
005.314	315 375 013	1642		CALL	PCOFT	OUTPUT ONES
005.317	315 100 015	1643		CALL	PSOF	OUTPUT FINAL
005.322	322	1644		DB	'R'+200Q	
005.323	311	1645		RET		

1647	**	ACRT - ANSI CURSOR RIGHT
1648	*	
1649	*	*ACRT* MOVES THE CURSOR ONE COLUMN TOWARD THE END OF THE LINE
1650	*	
1651	*	
1652	*	ENTRY (B) = ZERO IF NO PN WAS INPUT
1653	*	(D,E) = PSDW
1654	*	
1655	*	EXIT NONE
1656	*	
1657	*	USES A,B,D,E,H,L,F

```

1658
1659
005.324 170 1660 ACRT MOV A,B SEE IF PN WAS INPUT
005.325 267 1661 ORA A
005.326 312 201 007 1662 JZ CRT IF NO PN, DEFAULT TO ONE
1663
005.331 032 1664 LDAX D GET PN
005.332 267 1665 ORA A SEE IF ZERO
005.333 312 201 007 1666 JZ CRT IF ZERO, DEFAULT TO ONE
1667
005.336 107 1668 MOV B,A SAVE COUNT
005.337 315 201 007 1669 ACRT1 CALL CRT CURSOR RIGHT ONE COLUMN
005.342 005 1670 DCR B
005.343 040 372 1671 JR NZ,ACRT1 'TIL DONE
1672
005.345 311 1673 RET

```

```

1675 ** ACUP - ANSI CURSOR UP
1676 *
1677 * *ACUP* MOVES THE CURSOR TOWARD THE TOP OF THE SCREEN PN TIMES
1678 *
1679 *
1680 * ENTRY (B) = ZERO IF NO PN WAS INPUT
1681 * (D,E) = PSW
1682 *
1683 * EXIT NONE
1684 *
1685 * USES A,B,C,D,E,H,L,F
1686
1687
005.346 170 1688 ACUP MOV A,B SEE IF A PN WAS INPUT
005.347 267 1689 ORA A
005.350 312 227 007 1690 JZ CUP IF NONE, DEFAULT TO ONE
1691
005.353 032 1692 LDAX D GET PN
005.354 267 1693 ORA A ZERO?
005.355 312 227 007 1694 JZ CUP IF ZERO, DEFAULT TO ONE
1695
005.360 365 1696 ACUP1 PUSH PSW SAVE PSW
005.361 315 227 007 1697 CALL CUP CURSOR UP ONE LINE
005.364 361 1698 POP PSW
005.365 075 1699 DCR A COUNT - 1
005.366 040 370 1700 JR NZ,ACUP1 'TIL DONE
1701
005.370 311 1702 RET

```



```
1705 **      APCA - ANSI PERFORM CURSOR ADDRESSING
1706 *
1707 *      *APCA* CHECKS TO SEE THAT THE LINE AND COLUMN VALUES ARE LEGAL
1708 *      AND SETS THE CURSOR TO THE REQUESTED ADDRESS. IF THE VALUES
1709 *      ARE OUT OF RANGE, THE OLD LINE NUMBER REMAINS AND/OR THE CURSOR
1710 *      GOES TO THE LAST COLUMN ON THE LINE
1711 *
1712 *
1713 *      ENTRY (B) = ZERO IF NO PN WAS INPUT
1714 *      (D,E) = PSDW
1715 *
1716 *      EXIT NONE
1717 *
1718 *      USES A,B,C,D,E,H,L,F
1719
1720
005.371 170 1721 APCA MOV A,B SEE IF PS WAS INPUT
005.372 267 1722 ORA A
005.373 312 271 015 1723 JZ SCH IF NO ADDRESS SPECIFIED, PLACE CURSOR HOME
1724
005.376 353 1725 XCHG (H,L) = PS WORK AREA
005.377 176 1726 MOV A,M GET LINE NUMBER
006.000 267 1727 ORA A SEE IF ZERO
006.001 050 001 1728 JR Z,APCA1 IF ZERO, THIS IS FIRST LINE
1729
006.003 075 1730 DCR A ELSE, LINE = LINE#-1
006.004 376 030 1731 APCA1 CPI 24 LINE IN RANGE?
006.006 070 013 1732 JR C,APCA2 IF 0 TO 23
1733
006.010 040 014 1734 JR NZ,APCA3 IF NOT REQUESTING 25TH LINE
1735
006.012 107 1736 MOV B,A SAVE LINE NUMBER
006.013 072 311 100 1737 LDA MODEI GET MODE FLAGS
006.016 346 200 1738 ANI M1.25L 25TH LINE ENABLED?
006.020 050 004 1739 JR Z,APCA3 IF 25TH LINE IS OFF
1740
006.022 170 1741 MOV A,B
006.023 062 273 100 1742 APCA2 STA CURVP SET NEW LINE NUMBER
1743
006.026 043 1744 APCA3 INX H GET NEXT PN
006.027 176 1745 MOV A,M COLUMN NUMBER
006.030 267 1746 ORA A ZERO?
006.031 050 001 1747 JR Z,APCA4 IF ZERO
1748
006.033 075 1749 DCR A ELSE, COLUMN = COLUMN#-1
006.034 376 120 1750 APCA4 CPI 80 SEE IF IN RANGE
006.036 070 002 1751 JR C,APCA5 IF 0 TO 79
1752
006.040 076 117 1753 MVI A,79 ELSE, SET LAST COLUMN
006.042 062 272 100 1754 APCA5 STA CURHP SET COLUMN POSITION
006.045 303 322 015 1755 JMP SNCF SET NEW CURSOR POSITION
```

```

1757 **      APDC - ANSI PERFORM DELETE CHARACTER
1758 *
1759 *      *APDC* DELETES THE SPECIFIED NUMBER OF CHARACTERS FROM THE LINE
1760 *
1761 *
1762 *      ENTRY      (B) = ZERO IF NO PN WAS INPUT
1763 *                (D,E) = PSDW
1764 *
1765 *      EXIT      NONE
1766 *
1767 *      USES      A,B,C,D,E,H,L,F
1768 *
1769 *
006.050 170    1770 APDC  MOV     A,B          SEE IF INPUT PN
006.051 267    1771      ORA     A
006.052 312 027 014 1772      JZ     PDC          IF NO PN, DEFAULT TO ONE
1773 *
006.055 032    1774      LDAX    D          GET PN
006.056 267    1775      ORA     A          ZERO?
006.057 312 027 014 1776      JZ     PDC          IF ZERO, DEFAULT TO ONE
1777 *
006.062 365    1778 APDC1 PUSH    PSW          SAVE PN
006.063 315 027 014 1779      CALL   PDC
006.066 361    1780      POP     PSW
006.067 075    1781      DCR     A
006.070 040 370    1782      JR      NZ,APDC1      'TIL DONE
1783 *
006.072 311    1784      RET

```

```

1786 **      APDL - ANSI PERFORM DELETE LINE
1787 *
1788 *      *APDL* DELETES THE SPECIFIED NUMBER OF FOLLOWING LINES
1789 *
1790 *
1791 *      ENTRY      (B) = ZERO IF NO PN WAS INPUT
1792 *                (D,E) = PSDW
1793 *
1794 *      EXIT      NONE
1795 *
1796 *      USES      A,B,C,D,E,H,L,F
1797 *
1798 *
006.073 170    1799 APDL  MOV     A,B          SEE IF PN WAS INPUT
006.074 267    1800      ORA     A
006.075 312 075 014 1801      JZ     PDL          IF NO PN, DEFAULT TO ONE
1802 *
006.100 032    1803      LDAX    D          GET PN
006.101 267    1804      ORA     A          ZERO?
006.102 312 075 014 1805      JZ     PDL          IF ZERO, DEFAULT TO ONE
1806 *
006.105 365    1807 APDL1 PUSH    PSW          SAVE COUNT
006.106 315 075 014 1808      CALL   PDL          DELETE ONE LINE
006.111 361    1809      POP     PSW

```

```
006.112 075      1810      DCR      A      COUTN -1
006.113 040 370   1811      JR       NZ,APDL1  'TIL DONE
                  1812
006.115 311      1813      RET
```

```
                  1815 **      APIL - ANSI PERFORM INSERT LINE
                  1816 *
                  1817 *      *APIL* INSERTS THE SPECIFIED NUMBER OF LINES AT THE CURRENT LINE
                  1818 *      OF THE CURSOR POSITION
                  1819 *
                  1820 *
                  1821 *      ENTRY (B) = ZERO IF NO PN WAS INPUT
                  1822 *      (D,E) = PSDW
                  1823 *
                  1824 *      EXIT  NONE
                  1825 *
                  1826 *      USES  A,B,C,D,E,H,L,F
                  1827
                  1828
006.116 170      1829 APIL    MOV     A,B      SEE IF PN WAS INPUT
006.117 267      1830      ORA     A
006.120 312 234 014 1831      JZ     PIL      IF NO PN, INSERT ONE LINE
                  1832
006.123 032      1833      LDAX   D      GET PN
006.124 267      1834      ORA     A      ZERO?
006.125 312 234 014 1835      JZ     PIL      IF ZERO, DEFAULT TO ONE LINE
                  1836
006.130 365      1837 APIL1  PUSH   PSW      SAVE COUNT
006.131 315 234 014 1838      CALL  PIL      INSERT ONE LINE
006.134 361      1839      POP    PSW
006.135 075      1840      DCR     A
006.136 040 370   1841      JR      NZ,APIL1  'TIL DONE
                  1842
006.140 311      1843      RET
```

```
                  1845 **      ARM - ANSI RESET MODE
                  1846 *
                  1847 *      *ARM* RESETS THE MODE(S) SPECIFIED BY PN FOR THE SEQUENCE ESC [ Pn ]
                  1848 *
                  1849 *
                  1850 *      ENTRY (B) = ZERO IF NO PN WAS INPUT
                  1851 *      (D,E) = PSDW
                  1852 *
                  1853 *      EXIT  NONE
                  1854 *
                  1855 *      USES  A,B,C,D,E,H,L,F
                  1856
                  1857
006.141 170      1858 ARM    MOV     A,B      SEE IF PN WAS INPUT
006.142 267      1859      ORA     A
```

```
006.143 310      1860      RZ      IF NO PN, EXIT
                1861
006.144 353      1862      XCHG     (H,L) = PSDW
006.145 001 310 100 1863      LXI     B,MODEB (B,C) = MODEB
006.150 021 307 100 1864 ARM1    LXI     D,MODEA (D,E) = MODEA
006.153 176      1865      MOV      A,M     GET PN
006.154 376 002   1866      CPI      2      PN = 2?
006.156 314 125 011 1867      CZ      EKI    IF 2, ENABLE KEYBOARD INPUT
                1868
006.161 176      1869      MOV      A,M     GET PN
006.162 376 004   1870      CPI      4      PN = 4?
006.164 345      1871      PUSH     H      SAVE PN POINTER
006.165 314 305 016 1872      CZ      XICH   IF 4, EXIT INSERT CHARACTER MODE
006.170 341      1873      POP      H
                1874
006.171 176      1875      MOV      A,M     GET PN
006.172 376 024   1876      CPI      20     PN = 20?
006.174 314 263 016 1877      CZ      XACR   IF 20, EXIT AUTO CARRIAGE RETURN
                1878
006.177 176      1879      MOV      A,M     GET PN
006.200 376 154   1880      CPI      '1'    SEE IF PN = FINAL
006.202 310      1881      RZ      IF FINAL
                1882
006.203 043      1883      INX      H      ELSE, POINT TO NEXT PN
006.204 030 342   1884      JR      ARM1
```

```
1886 **      ASBR - ANSI SET BAUD RATE
1887 *
1888 *      *ASBR* SETS THE BAUD RATE TO THAT SPECIFIED BY PN
1889 *
1890 *
1891 *      ENTRY (B) = ZERO IF NO PN WAS INPUT
1892 *      (D,E) = PSDW
1893 *
1894 *      EXIT  NONE
1895 *
1896 *      USES  A,B,C,D,E,H,L,F
1897 *
1898
006.206 170      1899 ASBR    MOV      A,B     SEE IF PN WAS INPUT
006.207 267      1900      ORA      A
006.210 050 005   1901      JR      Z,ASBR1   IF NONE SPECIFIED, DEFAULT TO 110 BAUD
                1902
006.212 353      1903      XCHG     (H,L) = PSDW
006.213 176      1904      MOV      A,M     GET PN
006.214 376 016   1905      CPI      14     IN RANGE?
006.216 320      1906      RNC      IF NOT, EXIT
                1907
006.217 303 172 012 1908 ASBR1  JMP      SBR,
```

```
1910 **      ASGM - ANSI SET GRAPHICS MODE
1911 *
1912 *      *ASGM* SETS OR RESETS THE GRAPHICS MODE AND/OR THE REVERSE VIDEO MODE
1913 *
1914 *
1915 *      ENTRY  (B) = ZERO IF NO PN WAS INPUT
1916 *             (D,E) = PSDW
1917 *
1918 *      EXIT  NONE
1919 *
1920 *      USES   A,D,E,H,L,F
1921 *
1922 *
006.222 170   1923 ASGM  MOV   A,B      SEE IF PN WAS INPUT
006.223 267   1924      ORA   A
006.224 050 011 1925      JR    Z,ASGM1.5    IF NO PN, DEFAULT TO REVERSE VIDEO OFF
1926 *
006.226 325   1927      PUSH  D      SAVE PN POINTER
1928 *
006.227 321   1929 ASGM1 POP   D      GET PN POINTER
006.230 032   1930      LDAX  D      GET PN
006.231 023   1931      INX   D      POINT TO NEXT
006.232 325   1932      PUSH  D      SAVE FOR NEXT PASS(S)
006.233 041 227 006 1933      LXI   H,ASGM1    SET RETURN ADDRESS
006.236 345   1934      PUSH  H
1935 *
006.237 041 265 006 1936 ASGM1.5 LXI   H,ASGMT    (H,L) = GRAPHIC MODE TABLE ADDRESS
006.242 026 004   1937      MVI   D,ASGMTL    (D) = TABLE LENGTH
006.244 036 003   1938      MVI   E,ASGMTW    (E) = TABLE WIDTH
006.246 315 363 015 1939      CALL  STAB     SEARCH TABLE FOR PN VALUE
006.251 070 007   1940      JR    C,ASGM2    IF NOT IN TABLE, MUST BE BAD NO. OR FINAL
1941 *
006.253 043   1942      INX   H      ELSE, IN TABLE, GO TO ROUTINE
006.254 146   1943      MOV   H,M      GET MSB
006.255 157   1944      MOV   L,A      LSB
006.256 021 307 100 1945      LXI   D,MODEA    (D,E) = MODEA FOR ROUTINES
006.261 351   1946      PCHL      GO TO ADDRESS IN TABLE
1947 *
006.262 341   1948 ASGM2 POP   H      TOSS FORCED RETURN ADDRESS
006.263 321   1949      POP   D      EVEN STACK
006.264 311   1950      RET
```

```
1952 *      ASGMT - ANSI SET GRAPHICS MODE TABLE
1953 *
1954 *      *ASGMT* CONTAINS THE ADDRESS OF THE ROUTINES WHICH SET
1955 *      THE REQUESTED GRAPHIC OR REVERSE VIDEO MODE
1956 *
1957 *
006.265   1958 ASGMT  EQU    *
1959 *
006.265 000   1960      DB    0      ZERO
006.266 325 017 1961      DW    XRVM    EXIT REVERSE VIDEO MODE
1962 *
006.270 007   1963      DB    7      SEVEN
```

006.271	361 011	1964	DW	ERVM	ENTER REVERSE VIDEO MODE
		1965			
006.273	012	1966	DB	10	TEN
006.274	061 011	1967	DW	EGM	ENTER GRAPHICS MODE
		1968			
006.276	013	1969	DB	11	ELEVEN
006.277	275 016	1970	DW	XGM	EXIT GRAPHICS MODE
		1971			
000.003		1972	ASGMTW	ERU	3
000.004		1973	ASGMTL	ERU	*-ASGMT/ASGMTW
					TABLE IS THREE BYTES WIDE
					TABLE LENGTH
		1975	**		ASM - ANSI SET MODE
		1976	*		
		1977	*		*ASM* SETS THE MODE(S) SPECIFIED BY PN
		1978	*		
		1979	*		
		1980	*	ENTRY	(B) = ZERO IF NO PN WAS INPUT
		1981	*		(D,E) = PSDW
		1982	*		
		1983	*	EXIT	NONE
		1984	*		
		1985	*	USES	A,B,C,D,E,H,L,F
		1986			
		1987			
006.301	170	1988	ASM	MOV	A,B
006.302	267	1989		ORA	A
006.303	310	1990		RZ	
		1991			IF NO PN
006.304	353	1992		XCHG	(H,L) = PSDW
006.305	001 310 100	1993		LXI	B,MODEB
006.310	021 307 100	1994	ASM1	LXI	D,MODEA
006.313	176	1995		MOV	A,M
006.314	376 002	1996		CPI	2
006.316	314 226 010	1997		CZ	DKI
		1998			IF 2, DISABLE KEYBOARD INPUT
006.321	176	1999		MOV	A,M
006.322	345	2000		PUSH	H
006.323	376 004	2001		CPI	4
006.325	314 107 011	2002		CZ	EICH
006.330	341	2003		POP	H
		2004			
006.331	176	2005		MOV	A,M
006.332	376 024	2006		CPI	20
006.334	314 276 010	2007		CZ	EACR
		2008			IF 20, ENTER AUTO CARRIAGE RETURN
006.337	176	2009		MOV	A,M
006.340	376 150	2010		CPI	'h'
006.342	310	2011		RZ	
		2012			IF FINAL
006.343	043	2013		INX	H
006.344	030 342	2014		JR	ASM1
					ELSE, POINT TO NEXT PN


```
2017 **      CDN - CURSOR DOWN
2018 *
2019 *      *CDN* MOVES THE CURSOR DOWN ONE LINE ON THE DISPLAY, BUT DOES
2020 *      NOT CAUSE A SCROLL PAST THE LAST LINE
2021 *
2022 *
2023 *      ENTRY      NONE
2024 *
2025 *      EXIT      NONE
2026 *
2027 *      USES      A,B,C,D,E,H,L,F
2028 *
2029
006.346 072 273 100 2030 CDN      LDA      CURVP      GET CURRENT VERTICAL POSITION
006.351 376 027      2031          CPI      23          ON LAST LINE(S)?
006.353 320          2032          RNC          IF SO, EXIT
2033
2034 *      JMP      PLF          ELSE, DO A LINE FEED
000.000      2035      ERRNZ    *-PLF

2037 **      PLF - PERFORM LINE FEED
2038 *
2039 *      *PLF* MOVES THE CURSOR DOWN ONE LINE IN THE DISPLAY MEMORY. IF
2040 *      THE CURSOR WAS ON THE 23RD LINE, THE DISPLAYED VIDEO IS SCROLLED
2041 *      UP ONE LINE AND THE NEW LINE IS WRITTEN FULL OF SPACES.
2042 *
2043 *
2044 *      ENTRY      NONE
2045 *
2046 *      EXIT      NONE
2047 *
2048 *      USES      A,B,C,D,E,H,L,F
2049 *
2050
006.354 072 273 100 2051 PLF      LDA      CURVP      GET VERTICAL POSITION
006.357 376 030      2052          CPI      24          ON 25TH LINE?
006.361 310          2053          RZ          IF SO, EXIT WITHOUT ANY ACTION
2054
2055
006.362 021 120 000 2056 PLF0.2 LXI      D,80      LINES = 80 CHARACTERS
006.365 052 270 100 2057          LHLD     CLSA      GET CURRENT LINE STARTING ADDRESS
006.370 031          2058          DAB      D          ADD A LINE
006.371 174          2059          MOV     A,H          STAY IN VIDEO RAM
006.372 366 370      2060          ORI     VRAMS/256
006.374 147          2061          MOV     H,A
006.375 042 270 100 2062          SHLD     CLSA      SET NEW LINE VALUE
007.000 072 273 100 2063          LDA      CURVP      GET CURSOR VERTICAL POSITION
007.003 376 027      2064          CPI      23          ON LAST LINE?
007.005 040 061      2065          JR      NZ,PLF1      IF NOT ON LAST LINE
2066
2067 *      SCROLL VIDEO TO DISPLAY A NEW LINE
2068 *
007.007 072 311 100 2069          LDA      MODEI      GET MODE FLAGS
```

007.012	346 200	2070	ANI	M1,25L	SEE IF 25TH LINE IS ENABLED
007.014	050 016	2071	JR	Z,PLF0.5	IF NOT TO WORRY ABOUT 25TH LINE
		2072			
007.016	345	2073	PUSH	H	SAVE NEW LINE STARTING ADDRESS
007.017	021 120 000	2074	LXI	D,80	ADD 80 FOR BEGINNING OF 26TH LINE
007.022	031	2075	DAD	D	
007.023	353	2076	XCHG		(D,E) = BEGINNING OF 26TH LINE
007.024	341	2077	POP	H	(H,L) = BEGINNING OF 25TH LINE
007.025	345	2078	PUSH	H	SAVE AGAIN FOR LATER
007.026	006 005	2079	MVI	B,80/16	SET MOD 16 COUNT FOR ONE LINE
007.030	315 040 010	2080	CALL	CPH16	COPY LINE
007.033	341	2081	POP	H	(H,L) = BEGINNING OF 25TH LINE
		2082			
007.034	006 005	2083	PLF0.5 MVI	B,80/16	SET MOD-16 ERASE COUNT TO 5 (80 CHARACTERS)
007.036	315 212 016	2084	CALL	WSVA	WRITE 80 SPACES TO VIDEO TO BLANK THIS LINE
007.041	052 266 100	2085	LHLD	SHOME	GET OLD HOME POSITION
007.044	021 120 000	2086	LXI	D,80	ADD ONE LINE
007.047	031	2087	DAD	D	
007.050	174	2088	MOV	A,H	STAY IN VIDEO RAM
007.051	366 370	2089	ORI	VRAMS/256	
007.053	147	2090	MOV	H,A	
007.054	042 266 100	2091	SHLD	SHOME	UPDATE HOME POSITION
007.057	174	2092	MOV	A,H	SET VALUE OF HOME POSITION FOR CRT
007.060	346 007	2093	ANI	HOMAX/256	
007.062	147	2094	MOV	H,A	
007.063	042 301 100	2095	SHLD	VI,SA	
007.066	030 004	2096	JR	PLF2	UPDATE CURSOR ADDRESS
		2097			
007.070	074	2098	PLF1 INR	A	ADD ONE TO LINE COUNTER
007.071	062 273 100	2099	STA	CURVP	
		2100			
007.074	052 274 100	2101	PLF2 LHLD	CURAD	GET CURRENT CURSOR POSITION
007.077	031	2102	DAD	D	ADD ONE LINE
007.100	174	2103	MOV	A,H	STAY IN VIDEO RAM
007.101	366 370	2104	ORI	VRAMS/256	
007.103	147	2105	MOV	H,A	
007.104	042 274 100	2106	SHLD	CURAD	UPDATE CURSOR ADDRESS
		2107			
		2108			
007.107	303 146 016	2109	JMP	UCP.	CAUSE NMI TO UPDATE SCREEN IN CASE OF SCROLL

2111	**	PLFCR - PERFORM LINE FEED AND/OR CARRIAGE RETURN
2112	*	
2113	*	*PLFCR* PERFORMS A CARRIAGE RETURN PRIOR TO PERFORMING A LINE
2114	*	FEED IF THE AUTO CARRIAGE RETURN FUNCTION IS SELECTED
2115	*	
2116	*	
2117	*	ENTRY NONE
2118	*	
2119	*	EXIT NONE
2120	*	
2121	*	USES A,B,C,D,E,H,L,F
2122		

```

2123
007.112 315 354 006 2124 PLFCR CALL PLF DO LINE FEED
007.115 072 310 100 2125 LDA MODEB GET MODE FLAGS
007.120 346 020 2126 ANI MB,ACR SEE IF ACR SELECTED
007.122 302 013 014 2127 JNZ PCR IF SELECTED
2128
007.125 311 2129 RET ELSE, JUST RETURN

```

```

2131 ** PBS - PERFORM BACKSPACE
2132 *
2133 * CLFT - CURSOR LEFT
2134 *
2135 * *PBS*-CLFT* STEPS THE CURSOR ONE POSITION TO THE LEFT, BUT DOES NOT
2136 * WRAP AROUND TO THE PREVIOUS LINE AFTER REACHING COLUMN ZERO
2137 *
2138 *
2139 * ENTRY NONE
2140 *
2141 * EXIT NONE
2142 *
2143 * USES A,H,L,F
2144
2145
007.126 2146 PBS EQU *
007.126 2147 CLFT EQU *
007.126 072 272 100 2148 LDA CURHP GET CURRENT POSITION ON LINE
007.131 267 2149 ORA A SEE IF COLUMN ZERO
007.132 310 2150 RZ IF AT BEGINNING OF LINE
2151
007.133 075 2152 DCR A ELSE, DECREMENT CURSOR POSITION
007.134 062 272 100 2153 STA CURHP
007.137 052 274 100 2154 LHLD CURAD GET CURSOR ADDRESS
007.142 053 2155 DCX H DECREMENT ADDRESS
007.143 174 2156 PBS1 MOV A,H STAY IN VIDEO RAM
007.144 366 370 2157 ORI VRAMS/256
007.146 147 2158 MOV H,A
007.147 042 274 100 2159 SHLD CURAD
2160
007.152 311 2161
2162 RET EXIT WITH OR WITHOUT

```

```

2164 ** CPR - CURSOR POSITION REPORT
2165 *
2166 * *CPR* OUTPUTS THE CURSOR POSITION IN THE HEATH FORMAT
2167 * ** ESC Y P1 Pc **
2168 *
2169 *
2170 * ENTRY NONE
2171 *
2172 * EXIT NONE

```

```

2173 *
2174 *      USES      A,B,C,H,L,F
2175
2176
007.153 315 100 015 2177 CPR CALL PSOF      OUTPUT FIRST PART OF REPORT
007.156 033 331    2178 DB      ESC,'Y'+200Q  ESC Y
007.160 072 273 100 2179 LDA      CURVP      GET CURRENT LINE NUMBER
007.163 306 040    2180 ADI      40Q         MAKE ASCII
007.165 315 375 013 2181 CALL     PCOFT      PLACE LINE NUMBER IN FIFO
007.170 072 272 100 2182 LDA      CURHP      GET CURRENT COLUMN NUMBER
007.173 306 040    2183 ADI      40Q
007.175 315 375 013 2184 CALL     PCOFT      PUT IN FIFO
007.200 311        2185 RET

```

```

2187 **      CRT - CURSOR RIGHT
2188 *
2189 *      *CRT* MOVES THE CURSOR RIGHT ONE COLUMN. IF ALREADY AT THE LAST
2190 *      COLUMN, THE CURSOR IS ADVANCED TO THE BEGINNING OF THE NEXT LINE.
2191 *      *CRT* WILL NOT ADVANCE THE CURSOR PAST COLUMN 79 OF LINE 23.
2192 *
2193 *
2194 *      ENTRY     NONE
2195 *
2196 *      EXIT      NONE
2197 *
2198 *      USES      A,H,L,F
2199
2200
007.201 072 272 100 2201 CRT LDA      CURHP      GET CURRENT HORIZONTAL POSITION
007.204 376 117    2202 CPI      79         CURSOR AT LAST COLUMN?
007.206 310        2203 RZ          EXIT IF AT END OF LINE
2204
007.207 074        2205 INR      A          ELSE, INCREMENT CURSOR POSITION
007.210 062 272 100 2206 STA      CURHP
007.213 052 274 100 2207 LHLD     CURAD      GET CURSOR ADDRESS
007.216 043        2208 INX      H          INCREMENT ADDRESS
007.217 174        2209 MOV      A,H        STAY IN VIDEO RAM
007.220 366 370    2210 ORI      VRAMS/256
007.222 147        2211 MOV      H,A
007.223 042 274 100 2212 SHLD     CURAD      UPDATE CURAD
2213
2214
007.226 311        2215 RET      EXIT REGARDLESS

```

```

2217 **      CUP - CURSOR UP
2218 *
2219 *      *CUP* MOVES THE CURSOR UP ONE LINE ON THE DISPLAY. *CUP* WILL
2220 *      NOT MOVE THE CURSOR PAST LINE ZERO
2221 *
2222 *
2223 *      ENTRY    NONE
2224 *
2225 *      EXIT     NONE
2226 *
2227 *      USES     A,B,C,D,E,H,L,F
2228 *
2229 *
007,227 072 273 100 2230 CUP LDA CURVP GET CURRENT VERTICAL POSITION
007,232 267          2231 ORA A CHECK FOR LINE ZERO
007,233 310          2232 RZ IF LINE ZERO, EXIT WITHOUT MOVING CURSOR
2233 *
2234 *      JMP      PRLF DO A REVERSE LINE FEED
000,000 2235 *      ERRNZ *-PRLF

```

```

2237 **      PRLF - PERFORM A REVERSE LINE FEED
2238 *
2239 *      *PRLF* MOVES THE CURSOR UP ONE LINE IN THE VIDEO MEMORY. IF THE
2240 *      CURSOR WAS ALREADY ON THE TOP LINE OF THE DISPLAY, THE DISPLAY IS
2241 *      SCROLLED DOWN AND THE NEW LINE IS FILLED WITH SPACES.
2242 *
2243 *
2244 *      ENTRY    NONE
2245 *
2246 *      EXIT     NONE
2247 *
2248 *      USES     A,B,C,D,E,H,L,F
2249 *
2250 *
007,234 072 273 100 2251 PRLF LDA CURVP GET VERTICAL POSITION
007,237 376 030      2252 CPI 24 25TH LINE?
007,241 310          2253 RZ IF 80, FORGET RLF
2254 *
2255 *
007,242 021 260 377 2256 PRLF0,2 LXI D,-80 (D,E) = TWOS COMPLEMENT OF 80
007,245 052 270 100 2257 LHL CLSA GET CURRENT LINE ADDRESS
007,250 031          2258 DAD D SUBTRACT ONE LINE
007,251 174          2259 MOV A,H STAY IN VIDEO RAM
007,252 366 370      2260 ORI VRAMS/256
007,254 147          2261 MOV H,A
007,255 042 270 100 2262 SHLD CLSA UPDATE LINE ADDRESS
007,260 072 273 100 2263 LDA CURVP GET CURRENT DISPLAYED LINE NUMBER
007,263 267          2264 ORA A CHECK FOR LINE ZERO
007,264 040 067      2265 JR NZ,PRLF1 IF NOT ON LINE ZERO
2266 *
007,266 072 311 100 2267 LDA MODEI GET MODE FLAGS
007,271 346 200      2268 ANI MI,25L IS 25TH LINE ON?
007,273 050 021      2269 JR Z,PRLF0,5 IF NOT ON

```

```
2270
2271 *      25TH LINE IS ON, COPY TO 24TH BEFORE DISPLAY IS MOVED
2272 *
007.275 052 266 100 2273 LHL D SHOME GET HOME ADDRESS
007.300 021 060 007 2274 LXI D,23*80 FIND ADDRESS OF LINE #23
007.303 031 2275 DAD D
007.304 353 2276 XCHG (D,E) = BEGINNING OF LINE 23
007.305 041 120 000 2277 LXI H,80 FIND ADDRESS OF LINE #24
007.310 031 2278 DAD D
007.311 006 005 2279 MVI B,80/16 COPY ONE LINE
007.313 315 040 010 2280 CALL CPM16
2281
2282 *      ERASE TOP LINE
2283 *
007.316 052 270 100 2284 PRLF0.5 LHL D CLSA LINE ZERO ADDRESS TO (H,L) FOR ERASE
007.321 006 005 2285 MVI B,5 ERASE LINE (5*16 SPACES)
007.323 315 212 016 2286 CALL WSV A
007.326 052 266 100 2287 LHL D SHOME GET OLD HOME POSITION
007.331 021 260 377 2288 LXI D,-80
007.334 031 2289 DAD D SUBTRACT ONE LINE
007.335 174 2290 MOV A,H STAY IN VIDEO RAM
007.336 366 370 2291 ORI VRAMS/256
007.340 147 2292 MOV H,A
007.341 042 266 100 2293 SHLD SHOME UPDATE HOME POSITION
007.344 174 2294 MOV A,H SET HOME POSITION FOR CRT
007.345 346 007 2295 ANI HOMAX/256
007.347 147 2296 MOV H,A
007.350 042 301 100 2297 SHLD VI,SA
007.353 030 004 2298 JR PRLF2 UPDATE CURSOR
2299
007.355 075 2300 PRLF1 DCR A DECREMENT LINE COUNTER
007.356 062 273 100 2301 STA CURVP
2302
007.361 052 274 100 2303 PRLF2 LHL D CURAD GET CURRENT CURSOR ADDRESS
007.364 031 2304 DAD D SUBTRACT ONE LINE
007.365 174 2305 MOV A,H STAY IN VIDEO RAM
007.366 366 370 2306 ORI VRAMS/256
007.370 147 2307 MOV H,A
007.371 042 274 100 2308 SHLD CURAD UPDATE CURSOR ADDRESS
2309
2310
007.374 303 146 016 2311 JMP UCP, EXIT
```

```
2313 **      EID - ERASE IN DISPLAY
2314 *
2315 *      *EID* ERASES THE AMOUNT OF THE SCREEN SPECIFIED BY PN
2316 *
2317 *
2318 *      ENTRY (B) = ZERO IF NO PN WAS INPUT
2319 *      (D,E) = PSDW
2320 *
2321 *      EXIT NONE
2322 *
```



```

2323 *      USES      A,B,C,D,E,H,L,F
2324
2325
007.377 170      2326 EID      MOV      A,B      SEE IF PN WAS INPUT
010.000 267      2327      ORA      A
010.001 312 317 011 2328      JZ       ERM      IF NO PN, ERASE TO END OF SCREEN
2329
010.004 353      2330      XCHG     (H,L) = PSDW
010.005 176      2331      MOV      A,M      GET PN
010.006 267      2332      ORA      A      ZERO?
010.007 312 317 011 2333      JZ       ERM      IF ZERO, ERASE TO END OF PAGE
2334
010.012 075      2335      DCR      A      ONE?
010.013 312 315 010 2336      JZ       EBD      IF ONE, ERASE BEGINNING OF DISPLAY
2337
010.016 075      2338      DCR      A      TWO?
010.017 300      2339      RNZ      IF NOT TWO, EXIT
2340
000.000      2341 *      JMP       CLR      ELSE, CLEAR DISPLAY
2342      ERRNZ    *-CLR
2343
2344 **      CLR - CLEAR
2345 *
2346 *      *CLR* PLACES THE SOFTWARE HOME POSITION BACK TO THE HARDWARE
2347 *      HOME POSITION (BEGINNING OF VIDEO RAM) AND WRITES ASCII SPACES
2348 *      INTO THE FIRST 1920 BYTES (24 LINES X 80 CHARACTERS)
2349 *
2350 *
2351 *      ENTRY      NONE
2352 *
2353 *      EXIT       NONE
2354 *
2355 *      USES      A,B,C,D,E,H,L,F
2356
2357
010.020 072 273 100 2358 CLR      LDA      CURVP    GET VERTICAL POSITION
010.023 376 030      2359      CPI      24      SEE IF ON 25TH LINE
010.025 312 051 011 2360      JZ       EEL      IF SO, JUST ERASE LINE
2361
010.030 315 271 015 2362      CALL     SCH
010.033 006 170      2363      MVI      B,1920/16    SET CURSOR TO HOME POSITION (H,L) = CURAD
010.035 303 212 016 2364      JMP       WSV4      ERASE 24 LINES WORTH OF CHARACTERS
2365

```

```
2367 **      CPM16 - COPY MEMORY - MODULO SIXTEEN
2368 *
2369 *      *CPM16* COPYS SIXTEEN BYTES FROM AND TO VIDEO RAM. FROM AND TO
2370 *      ADDRESSES MUST BE AT THE BEGINNING OF A LINE.
2371 *
2372 *
2373 *      ENTRY (H,L) = ADDRESS TO COPY FROM
2374 *      (D,E) = ADDRESS TO COPY TO
2375 *      (B) = NUMBER OF BYTES TO COPY /16
2376 *
2377 *      EXIT NONE
2378 *
2379 *      USES A,B,D,E,H,L,F
2380
010.040 172 2381 CPM16 MOV A,D      KEEP BOTH ADDRESSES IN VIDEO RAM AREA
010.041 366 370 2382 ORI VRAMS/256
010.043 127 2383 MOV D,A
010.044 174 2384 MOV A,H
010.045 366 370 2385 ORI VRAMS/256
010.047 147 2386 MOV H,A
2387
2388 *      COPY SIXTEEN BYTES
2389 *
010.050 176 2390 MOV A,M      GET BYTE FROM FIRST LINE
010.051 022 2391 STAX D      PUT IN SAME COLUMN ON OTHER LINE
010.052 043 2392 INX H      POINT TO NEXT COLUMN ON BOTH LINES
010.053 023 2393 INX D
2394
010.054 176 2395 MOV A,M      *2
010.055 022 2396 STAX D
010.056 043 2397 INX H
010.057 023 2398 INX D
2399
010.060 176 2400 MOV A,M      *3
010.061 022 2401 STAX D
010.062 043 2402 INX H
010.063 023 2403 INX D
2404
010.064 176 2405 MOV A,M      *4
010.065 022 2406 STAX D
010.066 043 2407 INX H
010.067 023 2408 INX D
2409
010.070 176 2410 MOV A,M      *5
010.071 022 2411 STAX D
010.072 043 2412 INX H
010.073 023 2413 INX D
2414
010.074 176 2415 MOV A,M      *6
010.075 022 2416 STAX D
010.076 043 2417 INX H
010.077 023 2418 INX D
2419
010.100 176 2420 MOV A,M      *7
010.101 022 2421 STAX D
010.102 043 2422 INX H
```

010.103	023	2423	INX	D	
		2424			
010.104	176	2425	MOV	A,M	*8
010.105	022	2426	STAX	D	
010.106	043	2427	INX	H	
010.107	023	2428	INX	D	
		2429			
010.110	176	2430	MOV	A,M	*9
010.111	022	2431	STAX	D	
010.112	043	2432	INX	H	
010.113	023	2433	INX	D	
		2434			
010.114	176	2435	MOV	A,M	*10
010.115	022	2436	STAX	D	
010.116	043	2437	INX	H	
010.117	023	2438	INX	D	
		2439			
010.120	176	2440	MOV	A,M	*11
010.121	022	2441	STAX	D	
010.122	043	2442	INX	H	
010.123	023	2443	INX	D	
		2444			
010.124	176	2445	MOV	A,M	*12
010.125	022	2446	STAX	D	
010.126	043	2447	INX	H	
010.127	023	2448	INX	D	
		2449			
010.130	176	2450	MOV	A,M	*13
010.131	022	2451	STAX	D	
010.132	043	2452	INX	H	
010.133	023	2453	INX	D	
		2454			
010.134	176	2455	MOV	A,M	*14
010.135	022	2456	STAX	D	
010.136	043	2457	INX	H	
010.137	023	2458	INX	D	
		2459			
010.140	176	2460	MOV	A,M	*15
010.141	022	2461	STAX	D	
010.142	043	2462	INX	H	
010.143	023	2463	INX	D	
		2464			
010.144	176	2465	MOV	A,M	*16
010.145	022	2466	STAX	D	
010.146	043	2467	INX	H	
010.147	023	2468	INX	D	
		2469			
010.150	020 266	2470	DJNZ	CPM16	
010.152	311	2471	RET		TIL DONE

```

2473 **      D25L - DISABLE 25TH LINE
2474 *
2475 *      *D25L* DISABLES THE DISPLAY OF THE 25TH LINE
2476 *
2477 *
2478 *      ENTRY    NONE
2479 *
2480 *      EXIT      NONE
2481 *
2482 *      USES      A,F
2483
2484
010.153 072 311 100 2485 D25L LDA    MODEI    GET MODE FLAGS
010.156 346 177      2486      ANI    255-MI.25L  CLEAR 25TH LINE FLAG
010.160 062 311 100 2487      STA    MODEI
010.163 076 030      2488      MVI    A,24
010.165 062 276 100 2489      STA    VI.VD    UPDATE VIDEO DISPLAYED INFO FOR NMI
010.170 311          2490      RET

```

```

2492 **      DALF - DISABLE AUTO LINE FEED
2493 *
2494 *      *DALF* DISABLES A CARRIAGE RETURN CAUSING AN AUTOMATIC LINE FEED
2495 *
2496 *
2497 *      ENTRY    (R,C) = MODEB
2498 *
2499 *      EXIT      NONE
2500 *
2501 *      USES      A,F
2502
2503
010.171 012          2504 DALF  LDAX    B        GET MODE FLAGS
010.172 346 367      2505      ANI    255-MB.ALF  CLEAR AUTO LINE FEED
010.174 002          2506      STAX   B
010.175 311          2507      RET

```

```

2509 **      DC - DISABLE CURSOR
2510 *
2511 *      *DC* INHIBITS THE DISPLAY OF THE CURSOR, ALL OTHER FUNCTIONS
2512 *      PERFORM AS THEY WOULD IF THE CURSOR WERE ON
2513 *
2514 *
2515 *      ENTRY    NONE
2516 *
2517 *      EXIT      NONE
2518 *
2519 *      USES      A
2520
2521
010.176 072 307 100 2522 DC    LDA    MODEA    GET MODE FLAGS

```

010.201	388 020	2523	ORI	MA,CD	SET CURSOR DISABLED
010.203	062 307 100	2524	STA	MODEA	
010.208	046 040	2525	MVI	H,VB,CND	CURSOR NOT DISPLAYED
010.210	056 000	2526	MVI	L,0	SET CURSOR END ADDRESS TO ZERO
010.212	042 277 100	2527	SHLD	VI,CSE	
010.215	311	2528	RET		

2530 ** DEOL - DISCARD AT END OF LINE
2531 *
2532 * *DEOL* RESETS THE WRAP AROUND AT END OF LINE FLAG. CHARACTERS
2533 * INCOMING CHARACTERS PAST COLUMN 79 ARE PLACED IN COLUMN 79 UNTIL
2534 * A CARRIAGE RETURN IS RECEIVED
2535 *
2536 *

2537 * ENTRY (B+C) = MODEB
2538 *
2539 * EXIT NONE
2540 *
2541 * USES A,F
2542 *

010.216	012	2544	DEOL	LDAX B	GET MODE FLAGS
010.217	346 373	2545		ANI 255-MB,WRAP	CLEAR WRAP AROUND FLAG
010.221	002	2546		STAX B	
010.222	311	2547		RET	

2549 ** DING - DING BELL
2550 *
2551 *
2552 * ENTRY NONE
2553 *
2554 * EXIT NONE
2555 *
2556 * USES NONE
2557 *

010.223		2558			
010.223	323 340	2559	DING	EQU *	
010.225	311	2560		OUT MP,BELL	
		2561		RET	

2563 ** DKI - DISABLE KEYBOARD INPUT
2564 *
2565 * *DKI* CAUSES ALL KEYBOARD ENTRYS TO BE IGNORED
2566 *
2567 *
2568 * ENTRY NONE
2569 *

```

2570 *      EXIT      NONE
2571 *
2572 *      USES      A,F
2573
2574
010.226 072 311 100 2575 DKI      LDA      MODEI      GET PROPER MODE FLAGS
010.231 366 004      2576      ORI      MI,KID      SET KEYBOARD INPUT DISABLED
010.233 062 311 100 2577      STA      MODEI
010.236 311      2578      RET

2580 **      E25L - ENABLE 25TH LINE
2581 *
2582 *      *E25L* ENABLES THE DISPLAY OF THE 25TH LINE ONLY IF IT HAS NOT
2583 *      BEEN PREVIOUSLY ENABLED.  THE 25TH LINE IS CLEARED AT THE TIME
2584 *      IT IS ENABLED.
2585 *
2586 *
2587 *      ENTRY      NONE
2588 *
2589 *      EXIT      NONE
2590 *
2591 *      USES      A,B,C,D,E,H,L,F
2592
2593
010.237 072 311 100 2594 E25L      LDA      MODEI      GET MODE FLAGS
010.242 107      2595      MOV      B,A      SAVE
010.243 346 200      2596      ANI      MI,25L      SEE IF 25TH LINE ALREADY ON
010.245 300      2597      RNZ      IF ON
2598
010.246 076 200      2599      MVI      A,MI,25L      ELSE, SET FLAG
010.250 260      2600      ORA      B
010.251 062 311 100 2601      STA      MODEI
010.254 052 266 100 2602      LHLD      SHOME      GET CURRENT HOME POSITION
010.257 021 200 007 2603      LXI      D,1920      ADD 24 LINE SIZE FOR BEGINNING OF 25TH
010.262 031      2604      DAD      D      (H,L) = STARTING ADDRESS OF LINE 25
010.263 006 005      2605      MVI      B,80/16      SET MODULO 16 COUNT FOR ERASE
010.265 315 212 016 2606      CALL     WSWA,      ERASE LINE
2607
010.270 076 031      2608      MVI      A,25      SET VERTICAL DISPLAYED INFO TO 25 LINES
010.272 062 276 100 2609      STA      VI,VD
010.275 311      2610      RET

```

```

2612 **      EACR - ENTER AUTO CARRIAGE RETURN
2613 *
2614 *      *EACR* ENABLES THE TERMINAL TO PERFORM AN AUTOMATIC CARRIAGE
2615 *      RETURN UPON RECEIPT OF A LINE FEED CHARACTER
2616 *
2617 *
2618 *      ENTRY      (B,C) = MODEB
2619 *

```


GENERAL USE SUBROUTINES

EACR

09:16:03 30-MAY-80

		2620	*	EXIT	NONE	
		2621	*			
		2622	*	USES	A,F	
		2623				
		2624				
010.276	012	2625	EACR	LDAX	B	GET MODE FLAGS
010.277	366 020	2626		ORI	MB.ACR	SET AUTO CARRIAGE RETURN
010.301	002	2627		STAX	B	
010.302	311	2628		RET		

		2630	**	EALF - ENABLE AUTO LINE FEED		
		2631	*			
		2632	*	*EALF* ENABLES THE TERMINAL TO PERFORM AN AUTOMATIC LINE FEED		
		2633	*	UPON RECEIPT OF A CARRIAGE RETURN		
		2634	*			
		2635	*			
		2636	*	ENTRY (B,C) = MODEB		
		2637	*			
		2638	*	EXIT	NONE	
		2639	*			
		2640	*	USES	A,F	
		2641				
		2642				
010.303	012	2643	EALF	LDAX	B	GET MODE FLAGS
010.304	366 010	2644		ORI	MB.ALF	
010.306	002	2645		STAX	B	
010.307	311	2646		RET		

		2648	**	EAM - ENTER ANSI MODE		
		2649	*			
		2650	*	*EAM* PLACES THE TERMINAL IN THE ANSI MODE FOR ESCAPE CODES.		
		2651	*			
		2652	*			
		2653	*	ENTRY (B,C) = MODEB		
		2654	*			
		2655	*	EXIT	NONE	
		2656	*			
		2657	*	USES	A,F	
		2658				
		2659				
010.310	012	2660	EAM	LDAX	B	GET MODE FLAGS
010.311	366 040	2661		ORI	MB.ANSI	SET ANSI MODE FLAG
010.313	002	2662		STAX	B	
010.314	311	2663		RET		

```

2665 **      EBD - ERASE BEGINNING OF DISPALY
2666 *
2667 *      *EBD* ERASES THE SCREEN FROM *HOME* TO THE CURRENT CURSOR POSITION
2668 *
2669 *
2670 *      ENTRY    NONE
2671 *
2672 *      EXIT      NONE
2673 *
2674 *      USES      A,B,C,D,E,H,L,F
2675
2676
010.315      2677 EBD      EQU      *
010.315 072 273 100 2678      LDA      CURVP      GET VERTICAL POSITION
010.320 376 030 2679      CPI      24      SEE IF ON 25TH LINE
010.322 050 026 2680      JR       Z,EBL      IF SO, JUST DO BEGINNING OF THIS LINE
2681
2682 *      ERASE ALL LINES ABOVE CURRENT LINE
2683 *
010.324 072 273 100 2684      LDA      CURVP      GET CURRENT LINE NUMBER
010.327 267 2685      ORA      A      SEE IF ALREADY ON HOME LINE
010.330 050 020 2686      JR       Z,EBD1     IF SO, NO FULL LINES TO ERASE
2687
010.332 157 2688      MOV      L,A      MULTIPLY LINE COUNT BY 5 FOR MODULO 16 COLUMNS
010.333 137 2689      MOV      E,A
010.334 046 000 2690      MVI      H,0
010.336 127 2691      MOV      D,A
010.337 031 2692      DAD      D      *2
010.340 031 2693      DAD      D      *3
010.341 031 2694      DAD      D      *4
010.342 031 2695      DAD      D      *5
010.343 105 2696      MOV      B,L      (B) = RESULT
010.344 052 266 100 2697      LHLD     SHOME      (H,L) = FIRST ADDRESS TO SPACE
010.347 315 212 016 2698      CALL     WSVA      WRITE SPACES
2699
010.352      2700 EBD1     EQU      *
000.000      2701 *      JMP      EBL      ERASE BEGINNING OF CURRENT LINE
2702      ERRNZ   *-EBL

2704 **      EBL - ERASE BEGINNING OF LINE
2705 *
2706 *      *EBL* ERASES FROM THE BEGINNING OF THE CURRENT LINE TO THE CURSOR
2707 *
2708 *
2709 *      ENTRY    NONE
2710 *
2711 *      EXIT      NONE
2712 *
2713 *      USES      A,B,H,L,F
2714
2715
010.352 052 270 100 2716 EBL      LHLD     CLSA      GET ADDRESS OF FIRST COLUMN ON THIS LINE
010.355 072 272 100 2717      LDA      CURHP      GET COLUMN COUNT

```

```
010.360 074      2718      INR      A      ADD ONE FOR THE CURSOR POSITION
010.361 107      2719      MOV      B,A    (B) = COUNT
                2720
                2721
010.362 076 040  2722      MVI      A,    WRITE SPACES
010.364 167      2723 EBL1      MOV      M,A  PUT SPACE IN DISPLAY
010.365 043      2724      INX      H      POINT TO NEXT
010.366 020 374  2725      DJNZ     EBL1    UNTIL DONE
                2726
010.370 311      2727      RET
                2728
```

```
                2730 **      EC - ENABLE CURSOR
                2731 *
                2732 *      *EC* ENABLES THE DISPLAY OF THE CURSOR
                2733 *
                2734 *
                2735 *      ENTRY    NONE
                2736 *
                2737 *      EXIT     NONE
                2738 *
                2739 *      USES     A,F
                2740
                2741
010.371 072 307 100 2742 EC      LDA      MODEA    GET MODE FLAGS
010.374 346 357      2743      ANI      255-MA,CD  SHOW CURSOR AS NOT DISABLED
010.376 062 307 100 2744      STA      MODEA
011.001 072 310 100 2745      LDA      MODEB    GET OTHER MODE FLAGS
011.004 346 001      2746      ANI      MB,CBLK  BLOCK CURSOR SELECTED?
011.006 302 261 015 2747      JNZ      SBC,    IF BLOCK SELECTED, SET IT
                2748
011.011 303 026 016 2749      JMP      SUC,    ELSE, SET UNDERSCORE CURSOR
```

```
                2751 **      EDD - ENCODE DECIMAL DIGITS
                2752 *
                2753 *      *EDD* ENCODES TWO DECIMAL DIGITS FROM THE BINARY VALUE SUPPLIED,
                2754 *      THE DECIMAL DIGITS ARE IN THE FORM OF TWO BCD BYTES (NOT ASCII).
                2755 *
                2756 *
                2757 *      ENTRY    (A) = BINARY VALUE TO BE ENCODED
                2758 *
                2759 *      EXIT     (D) = DECIMAL TENS DIGIT (IN BCD)
                2760 *      (E) = DECIMAL ONES DIGIT (IN BCD)
                2761 *
                2762 *      USES     A,D,E
                2763
                2764
011.014 026 000      2765 EDD      MVI      D,0    CLEAR DECIMAL COUNTERS
011.016 376 012      2766 EDD1     CPI      10    SEE IF BINARY IS MORE THAN NINE
011.020 070 005      2767      JR      C,EDD2    IF LESS THAN TEN
```

011.022	326 012	2768				
011.024	024	2769	SUI	10	ELSE, SUBTRACT TEN FROM BINARY	
011.025	030 367	2770	INR	D	ADD ONE TO TENS DIGIT	
		2771	JR	EDD1	SEE IF MORE TENS	
		2772				
011.027	137	2773	EDD2	MOV	E,A	LEFTOVERS ARE ONES DIGIT
011.030	311	2774	RET			

		2776	**		EIL - ERASE IN LINE	
		2777	*			
		2778	*		*EIL* ERASES THE PORTION OF THE CURRENT LINE AS SPECIFIED BY PN	
		2779	*			
		2780	*			
		2781	*	ENTRY	(B) = ZERO IF NO PN WAS INPUT	
		2782	*		(D,E) = PSDW	
		2783	*			
		2784	*	EXIT	NONE	
		2785	*			
		2786	*	USES	A,B,C,D,E,H,L,F	
		2787				
		2788				
011.031	170	2789	EIL	MOV	A,B	SEE IF PN WAS INPUT
011.032	267	2790		ORA	A	
011.033	312 277 011	2791		JZ	EOL	IF NO PN, ERASE TO END OF LINE
		2792				
011.036	353	2793		XCHG	(H,L) = PSDW	
011.037	176	2794		MOV	A,M	GET PN
011.040	267	2795		ORA	A	ZERO?
011.041	312 277 011	2796		JZ	EOL	IF ZERO, ERASE TO END OF LINE
		2797				
011.044	075	2798		DCR	A	ONE?
011.045	050 303	2799		JR	Z,EBL	IF ONE, ERASE BEGINNING OF LINE
		2800				
011.047	075	2801		DCR	A	TWO?
011.050	300	2802		RNZ		IF NOT TWO, ILLEGAL, EXIT
		2803				
		2804	*	JMP	EEL	ELSE, ERASE ENTIRE LINE
000.000		2805		ERRNZ	*-EEL	

2807	**		EEL - ERASE ENTIRE LINE
2808	*		
2809	*		*EEL* WRITES SPACES INTO THE ENTIRE LINE WHERE THE CURSOR RESIDES
2810	*		
2811	*		
2812	*	ENTRY	NONE
2813	*		
2814	*	EXIT	NONE
2815	*		
2816	*	USES	A,B,C,H,L,F
2817			

GENERAL USE SUBROUTINES

EEL

09:16:05 30-MAY-80

```

2818
011.051 052 270 100 2819 EEL LHLI CLSA START ERASING AT BEGINNING OF CURRENT LINE
011.054 006 005 2820 MVI B,80/16 MODULO 16 COUNT FOR NUMBER TO WRITE
011.056 303 212 016 2821 JMP WSWA WRITE SPACES AND EXIT

```

```

2823 ** EGM - ENTER GRAPHICS MODE
2824 *
2825 * *EGM* SETS THE GRAPHICS MODE FLAG
2826 *
2827 *
2828 * ENTRY (D,E) = MODEA
2829 *
2830 * EXIT NONE
2831 *
2832 * USES A,F
2833
2834
011.061 353 2835 EGM XCHG (H,L) = MODE
2836 * SET IB,GRPH,(HL) SET GRAPHICS MODE FLAG
011.062 313 316 2837 DB I,SETHA,I,SETHB,IB,GRPH
011.064 311 2838 RET

```

```

2840 ** EHM - ENTER HEATH MODE
2841 *
2842 * *EHM* TAKES THE TERMINAL OUT OF THE ANSI MODE AND INTO THE HEATH MODE
2843 *
2844 *
2845 * ENTRY NONE
2846 *
2847 * EXIT NONE
2848 *
2849 * USES A,F
2850
2851
011.065 072 310 100 2852 EHM LDA MODEB GET MODE FLAGS
011.070 346 337 2853 ANI 255-MB,ANSI
011.072 062 310 100 2854 STA MODEB
011.075 311 2855 RET

```

```

2857 ** EHSM - ENTER HOLD SCREEN MODE
2858 *
2859 *
2860 * *EHSM* SETS THE HOLD SCREEN MODE FLAG
2861 *
2862 *
2863 * ENTRY (D,E) = MODEA
2864 *

```

```
2865 *      EXIT      NONE
2866 *
2867 *      USES      A,F
2868
2869
011.076 353      2870 EHSM  XCHG      (H,L) = MODEA
2871 *      SET      IB.HSM,(H,L)  SET HOLD SCREEN MODE FLAG
011.077 313 306  2872      DB      I.ETHA,I.ETHB!IB.HSM
011.101 076 001  2873      MVI      A,1      SET LINE COUNTER TO ONE
011.103 062 313 100 2874      STA      HSMLC
011.106 311      2875      RET

2877 **      EICH - ENTER INSERT CHARACTER MODE
2878 *
2879 *      *EICH* SETS THE INSERT CHARACTER MODE FLAG
2880 *
2881 *
2882 *      ENTRY      (D,E) = MODEA
2883 *
2884 *      EXIT      NONE
2885 *
2886 *      USES      A,F
2887
2888
011.107 353      2889 EICH  XCHG      (H,L) = MODEA
2890 *      SET      IB.ICM,(HL)   SET INSERT CHARACTER MODE FLAG
011.110 313 366  2891      DB      I.ETHA,I.ETHB!IB.ICM
011.112 311      2892      RET

2894 **      EKAM - ENTER KEYPAD ALTERNATE MODE
2895 *
2896 *      *EKAM* SETS THE KEYPAD ALTERNATE MODE FLAG IN *MODE*
2897 *
2898 *
2899 *      ENTRY      (B,C) = MODEB
2900 *
2901 *      EXIT      NONE
2902 *
2903 *      USES      A,F
2904
2905
011.113 012      2906 EKAM  LDAX      B      GET MODEB FLAGS
011.114 366 200  2907      ORI      MB.KPDA  SET KEYPAD ALTERNATE MODE
011.116 002      2908      STAX      B
011.117 311      2909      RET
```


GENERAL USE SUBROUTINES

EKC

09:16:06 30-MAY-80

```

2911 **      EKC - ENABLE KEYBOARD CLICK
2912 *
2913 *      *EKC* RESETS THE FLAG WHICH INHIBITS THE KEY CLICK
2914 *
2915 *
2916 *      ENTRY   (B,C) = MODEB
2917 *
2918 *      EXIT     NONE
2919 *
2920 *      USES     A,F
2921 *
2922 *
011.120 012 2923 EKC  LDAX  B      GET MODE FLAGS
011.121 346 375 2924     ANI   255-MB.NOTK  CLEAR NO TICK FLAG
011.123 002 2925     STAX  B
011.124 311 2926     RET

```

```

2928 **      EKI - ENABLE KEYBOARD INPUT
2929 *
2930 *      *EKI* RESETS THE FLAG WHICH DISABLES INPUT FROM THE KEYBOARD
2931 *
2932 *
2933 *      ENTRY   NONE
2934 *
2935 *      EXIT     NONE
2936 *
2937 *      USES     A,F
2938 *
2939 *
011.125 072 311 100 2940 EKI  LDA   MODEI      GET MODE FLAGS
011.130 346 373 2941     ANI   255-MI.KID  TOSS KEYBOARD DISABLE FLAG
011.132 062 311 100 2942     STA   MODEI
011.135 311 2943     RET

```

```

2945 **      EKS - ENTER KEYPAD SHIFTED MODE
2946 *
2947 *      *EKS* SETS THE KEYPAD SHIFTED MODE FLAG
2948 *
2949 *
2950 *      ENTRY   (B,C) = MODEB
2951 *
2952 *      EXIT     NONE
2953 *
2954 *      USES     A,F
2955 *
2956 *
011.136 012 2957 EKS  LDAX  B      GET MODEB FLAGS
011.137 366 100 2958     ORI   MB.KPDS
011.141 002 2959     STAX  B
011.142 311 2960     RET

```

```
2962 **      ELB - ESCAPE LEFT BRACKET
2963 *
2964 *      *ELB* IS A CONTINUATION OF THE ESCAPE SEQUENCE PROCESSING FOR
2965 *      ANSI ESCAPE SEQUENCES. THE FINAL CHARACTER OF THE SEQUENCE IS
2966 *      DECODED WITH OR WITHOUT A PRECEDING PARAMETER STRING AND
2967 *      CONTROL IS PASSED ON TO THE ASSOCIATED ROUTINE
2968 *
2969 *
2970 *      ENTRY    NONE
2971 *
2972 *      EXIT      TO REQUESTED ROUTINE WITH
2973 *                (R) = ZERO IF NO PARAMETER STRING WAS INPUT
2974 *
2975 *      USES      A,B,C,D,E,H,L,F
2976
2977
011.143 315 346 014 2978 ELB    CALL    PSD    DECODE PARAMETER STRING
011.146 305          2979    PUSH    R    SAVE (R)
2980
2981 *      SEARCH TABLE FOR FINAL CHARACTER OF SEQUENCE
2982 *
011.147 026 027 2983    MVI    D,ELBTL    SET TABLE LENGTH
011.151 036 003 2984    MVI    E,ELBTW    SET TABLE WIDTH
011.153 041 172 011 2985    LXI    H,ELBT     SET TABLE ADDRESS
011.156 315 363 015 2986    CALL    STAB      SEARCH TABLE
011.161 301          2987    POP     R    RESTORE (R)
011.162 330          2988    RC        IF CHARACTER NOT FOUND IN TABLE, EXIT NOW
2989
011.163 043          2990    INX     H    ELSE, GET ADDRESS OF ROUTINE
011.164 146          2991    MOV     H,M    GET MSB
011.165 157          2992    MOV     L,A    GET LSB
011.166 021 314 100 2993    LXI    D,PSDW    (D,E) = PSD WORK AREA
011.171 351          2994    PCHL      GO TO ROUTINE

2996 *      ELBT - ESCAPE LEFT BRACKET TABLE
2997 *
2998 *      *ELBT* CONTAINS THE THIRD AND/OR FINAL CHARACTERS OF THE ANSI
2999 *      ESCAPE SEQUENCES
3000
3001
011.172          3002 ELBT    EQU     *
3003
011.172 076          3004    DB      '>'    ESC [ >
011.173 073 005 3005    DW      A2M    ANSI SET MODE #2
3006
011.175 077          3007    DB      '?'    ESC [ ?
011.176 376 004 3008    DW      A1M    ANSI SET MODE #1
3009
011.200 101          3010    DB      'A'    ESC [ A
011.201 346 005 3011    DW      ACUP    ANSI CURSOR UP
3012
011.203 102          3013    DB      'B'    ESC [ B
011.204 156 005 3014    DW      ACDN    ANSI CURSOR DOWN
3015
```

GENERAL USE SUBROUTINES

ELBT

09:16:07 30-MAY-80

011.206	103	3016	DB	'C'	ESC [C
011.207	324 005	3017	DW	ACRT	ANSI CURSOR RIGHT
		3018			
011.211	104	3019	DB	'D'	ESC [D
011.212	201 005	3020	DW	ACLFT	ANSI CURSOR LEFT
		3021			
011.214	110	3022	DB	'H'	ESC [H
011.215	371 005	3023	DW	APCA	ANSI PERFORM CURSOR ADDRESSING
		3024			
011.217	112	3025	DB	'J'	ESC [J
011.220	377 007	3026	DW	EID	ERASE IN DISPLAY
		3027			
011.222	113	3028	DB	'K'	ESC [K
011.223	031 011	3029	DW	EIL	ERASE IN LINE
		3030			
011.225	114	3031	DB	'L'	ESC [L
011.226	116 006	3032	DW	APIL	ANSI PERFORM INSERT LINE
		3033			
011.230	115	3034	DB	'M'	ESC [M
011.231	073 006	3035	DW	APDL	ANSI PERFORM DELETE LINE
		3036			
011.233	120	3037	DB	'P'	ESC [P
011.234	050 006	3038	DW	APDC	ANSI PERFORM DELETE CHARACTER
		3039			
		3040			
011.236	146	3041	DB	'f'	ESC [f (LOWER CASE F)
011.237	371 005	3042	DW	APCA	ANSI PERFORM CURSOR ADDRESSING
		3043			
011.241	150	3044	DB	'h'	ESC [h (LOWER CASE H)
011.242	301 006	3045	DW	ASH	ANSI SET MODE
		3046			
011.244	154	3047	DB	'l'	ESC [l (LOWER CASE L)
011.245	141 006	3048	DW	ARM	ANSI RESET MODE
		3049			
011.247	155	3050	DB	'm'	ESC [m (LOWER CASE M)
011.250	222 006	3051	DW	ASGM	ANSI SET GRAPHICS MODE
		3052			
011.252	156	3053	DB	'n'	ESC [n (LOWER CASE N)
011.253	223 005	3054	DW	ACPR	ANSI CURSOR POSITION REPORT
		3055			
011.255	160	3056	DB	'p'	ESC [p (LOWER CASE P)
011.256	247 017	3057	DW	AXMTP	ANSI TRANSMIT PAGE
		3058			
011.260	161	3059	DB	'q'	ESC [q (LOWER CASE Q)
011.261	323 016	3060	DW	AXMT25	ANSI TRANSMIT 25TH LINE
		3061			
011.263	162	3062	DB	'r'	ESC [r (LOWER CASE R)
011.264	206 006	3063	DW	ASBR	ANSI SET BAUD RATE
		3064			
011.266	163	3065	DB	's'	ESC [s (LOWER CASE S)
011.267	127 015	3066	DW	ASCP	ANSI SAVE CURSOR POSITION
		3067			
011.271	165	3068	DB	'u'	ESC [u (LOWER CASE U)
011.272	311 015	3069	DW	AUSCP	ANSI UNSAVE CURSOR POSITION
		3070			
011.274	172	3071	DB	'z'	ESC [z (LOWER CASE Z)

011.275	375 012	3072	DW	ARAMP	ANSI RESET ALL MODES TO POWER UP CONFIGURATION
		3073			
000.003		3074	ELBTW	EQU 3	TABLE WIDTH IS 3
000.027		3075	ELRTL	EQU *-ELBT/ELBTW	TABLE LENGTH

		3077	**	EOL - ERASE TO END OF LINE	
		3078	*		
		3079	*	*EOL* PLACES SPACES IN VIDEO RAM FROM THE CURRENT CURSOR POSITION	
		3080	*	TO THE END OF THE CURRENT LINE, CURSOR POSITION DOES NOT CHANGE.	
		3081	*		
		3082	*		
		3083	*	ENTRY	NONE
		3084	*		
		3085	*	EXIT	NONE
		3086	*		
		3087	*	USES	A,B,C,D,E,H,L,F
		3088			
		3089			
011.277	052 274 100	3090	EOL	LHLD	CURAD
011.302	072 272 100	3091		LDA	CURHP
		3092	*	NEG	
011.305	355 104	3093		DB	I.NEGA,I.NEGB
011.307	306 120	3094		ADI	80
011.311	137	3095		MOV	E,A
011.312	026 000	3096		MVI	D,0
011.314	303 160 016	3097		JMP	WSV
					WRITE SPACES ON REST OF LINE

		3100	**	ERM - ERASE REST OF MEMORY	
		3101	*		
		3102	*	*ERM* ERASES THE SCREEN FROM THE CURRENT CURSOR POSITION TO	
		3103	*	THE END OF THE SCREEN	
		3104	*		
		3105	*		
		3106	*	ENTRY	NONE
		3107	*		
		3108	*	EXIT	NONE
		3109	*		
		3110	*	USES	A,B,C,D,E,H,L,F
		3111			
		3112			
011.317	072 273 100	3113	ERM	LDA	CURVP
011.322	376 030	3114		CPI	24
011.324	050 351	3115		JR	Z,EOL
		3116			
011.326	052 266 100	3117		LHLD	SHOME
011.331	021 177 007	3118		LXI	D,1919
					GET HOME ADDRESS
					ADD DISPLAY SIZE TO FIND END

```

011.334 031      3119      DAD      D
011.335 067      3120      STC
011.336 077      3121      CMC      CLEAR CARRY BIT FOR NEXT OPERATION
                                *
011.337 355 133   3122      LD      DE,(CURAD)
011.341 274 100   3123      DB      I,LDEDA,I,LDEDB
                                *
011.343 355 122   3124      DW      CURAD
011.345 043       3125      SBC      HL,DE      SUBTRACT CURSOR ADDRESS FROM END OF DISPLAY
011.346 353       3126      DB      I,SHDA,I,SHDB
011.347 172       3127      INX      H      ADD ONE TO ERASE CHARACTER AT (CURAD)
011.350 346 007   3128      XCHG     (D,E) = COUNT TO END OF DISPLAY
011.352 127       3129      MOV      A,D      MASK TO KEEP COUNT UNDER 2K
011.353 052 274 100 3130      ANI      00000111B
011.356 303 160 016 3131      MOV      D,A
011.357 3132      LHL      CURAD      (H,L) = ADDRESS OF FIRST SPACE TO WRITE
011.358 3133      JMP      WSV      WRITE SPACES

```

```

3135 **      ERVM - ENTER REVERSE VIDEO MODE
3136 *
3137 *      *ERV* SETS THE REVERSE VIDEO MODE FLAG
3138 *
3139 *
3140 *      ENTRY (D,E) = MODEA
3141 *
3142 *      EXIT  NONE
3143 *
3144 *      USES  A,F
3145
3146
011.361      3147 ERVM  EQU  *
3148
3149
011.361 353      3150      XCHG     (H,L) = MODE
011.362 176      3151      MOV      A,M      GET MODE FLAGS
011.363 366 210   3152      ORI      MA,RV+MA,RVP  SET REVERSE VIDEO AND RV PRESENT FLAGS
011.365 167      3153      MOV      M,A
011.366 311      3154      RET

```

```

3156 **      FCIF - FETCH CHARACTER FROM INPUT FIFO
3157 *
3158 *      *FCIF* IS USED TO FETCH A SINGLE CHARACTER FROM THE INPUT FIFO
3159 *      IF ANY ARE AVAILABLE.
3160 *
3161 *
3162 *      ENTRY  NONE
3163 *
3164 *      EXIT  (A) = CHARACTER IF ONE IS AVAILABLE
3165 *      'C' = SET IF NO CHARACTER
3166 *      'C' = CLEAR IF CHARACTER IN ACCUMULATOR
3167 *
3168 *      USES  A,B,H,L,F

```

```

3169
3170
011.367 072 241 100 3171 FCIF LDA IFC GET INPUT FIFO COUNTER
011.372 267 3172 ORA A SEE IF FIFO IS EMPTY
011.373 067 3173 STC SET 'C' FOR NO CHARACTER
011.374 310 3174 RZ IF NO CHARACTER IN FIFO, EXIT
3175
011.375 363 3176 DI LOCK OUT ANY ENTRIES FOR NOW
011.376 072 241 100 3177 LDA IFC DECREMENT INPUT FIFO COUNTER
012.001 075 3178 DCR A
012.002 062 241 100 3179 STA IFC
012.005 072 240 100 3180 LDA IFP GET INPUT FIFO POINTER
012.010 107 3181 MOV B,A SAVE VALUE
012.011 041 000 100 3182 LXI H,INF POINT TO INPUT FIFO
012.014 205 3183 ADD L ADD POINTER
012.015 157 3184 MOV L,A
012.016 170 3185 MOV A,B INCREMENT POINTER
012.017 074 3186 INR A
012.020 346 177 3187 ANI IFCHSK KEEP POINTER IN FIFO
012.022 062 240 100 3188 STA IFP UPDATE POINTER
012.025 176 3189 MOV A,M READ CHARACTER FROM FIFO
012.026 067 3190 STC CLEAR 'C'
012.027 077 3191 CMC
012.030 373 3192 EI ALLOW NEW ENTRIES TO FIFO
012.031 311 3193 RET

```

```

3195 ** FCOF - FETCH CHARACTER FROM OUTPUT FIFO
3196 *
3197 * *FCOF* FETCHES A CHARACTER FROM THE OUTPUT FIFO IF ANY ARE AVAILABLE.
3198 *
3199 *
3200 * ENTRY NONE
3201 *
3202 * EXIT (A) = CHARACTER IF AVAILABLE
3203 * 'C' = SET IF NO CHARACTERS IN FIFO
3204 * 'C' = CLEAR IF CHARACTER IN ACCUMULATOR
3205 *
3206 * USES A,B,H,L,F
3207
3208
012.032 072 243 100 3209 FCOF LDA OFC GET OUTPUT FIFO COUNTER
012.035 267 3210 ORA A SEE IF FIFO IS EMPTY
012.036 067 3211 STC SET 'C' FOR NO CHARACTERS
012.037 310 3212 RZ IF NO CHARACTERS IN FIFO
3213
012.040 075 3214 DCR A DECREMENT COUNTER
012.041 062 243 100 3215 STA OFC
012.044 072 242 100 3216 LDA OFP GET OUTPUT FIFO POINTER
012.047 107 3217 MOV B,A SAVE FOR LATER
012.050 041 200 100 3218 LXI H,OUTF POINT TO OUTPUT FIFO
012.053 205 3219 ADD L ADD POINTER
012.054 157 3220 MOV L,A
012.055 170 3221 MOV A,B INCREMENT POINTER

```



```

012.056 074      3222      INR      A
012.057 346 037   3223      ANI      OFCMASK      KEEP POINTER IN FIFO
012.061 062 242 100 3224      STA      OFF      UPDATE OUTPUT FIFO POINTER
012.064 176      3225      MOV      A,M      READ CHARACTER FROM FIFO
012.065 067      3226      STC      CLEAR 'C'
012.066 077      3227      CMC
012.067 311      3228      RET

3230 **      FNCP - FETCH NEXT CHARACTER FOR PRIVATE PROCESSING
3231 *
3232 *      FNCP GETS THE NEXT CHARACTER AVAILABLE FROM THE INPUT FIFO.
3233 *      IF NONE ARE AVAILABLE, FNCP CONTINUES TO PROCESS KEYBOARD
3234 *      CHARACTERS AND OUTPUT FIFO CHARACTERS
3235 *
3236 *
3237 *      ENTRY      NONE
3238 *
3239 *      EXIT      (A) = CHARACTER FROM INPUT FIFO
3240 *      'C' = CLEARED
3241 *
3242 *      USES      A,F
3243
3244
012.070 305      3245      FNCP      PUSH      B      SAVE REGISTERS
012.071 325      3246      PUSH      D
012.072 345      3247      PUSH      H
012.073 315 016 000 3248      FNCP1      CALL      MAIN.N      SERVICE KEYBOARD AND OUTPUT FIFO
012.076 315 367 011 3249      CALL      FCIF      SEE IF THERE IS A CHARACTER IN THE INPUT FIFO
012.101 070 370   3250      JR      C,FNCP1      IF NO CHARACTER YET
3251
3252      ELSE, RESTORE REGISTERS AND EXIT
012.103 341      3253      POP      D
012.104 321      3254      POP      B
012.105 301      3255      RET
012.106 311

```

```

3258 **      FVKF - FETCH VALUE FROM KEYBOARD FIFO
3259 *
3260 *      *FVKF* FETCHES A TWO BYTE VALUE FROM THE KEYBOARD FIFO
3261 *      AND THEN DOES A BUBBLE DOWN ON THE REST OF THE CONTENTS OF THE FIFO
3262 *      AND UPDATES THE KEYBOARD FIFO POINTER
3263 *
3264 *
3265 *      ENTRY      NONE
3266 *
3267 *      EXIT      (D,E) = TWO BYTE VALUE FROM KEYBOARD FIFO IF AVAILABLE
3268 *      'C' = SET IF FIFO WAS EMPTY

```

```

3269 *      'C' = CLEAR IF VALUE WAS PLACED IN (D,E)
3270 *
3271 *      USES      A,D,E,F
3272
3273
012.107 305      3274 FVKF  PUSH  B      SAVE (B,C,H,L)
012.110 345      3275      PUSH  H
012.111 363      3276      DI      INHIBIT ANY NEW ENTRYS WHILE REMOVING OLD
012.112 052 264 100 3277      LHLD  KBDFP      (H,L) = KEYBOARD FIFO POINTER
012.115 175      3278      MOV   A,L      CHECK LSB TO SEE IF THERE ARE ANY ENTRYS
012.116 376 244      3279      CFI   KBDFMIN&3770
012.120 067      3280      STC      SET CARRY IN CASE NO ENTRY
012.121 050 030      3281      JR    Z,FVKF1      IF FIFO EMPTY
3282
012.123 053      3283      DCX   H      ELSE, UPDATE FIFO POINTER
012.124 053      3284      DCX   H
012.125 042 264 100 3285      SHLD  KBDFP
012.130 041 244 100 3286      LXI   H,KBDF      (H,L) = BEGINNIG OF FIFO
012.133 126      3287      MOV   D,M      (D) = VALUE FROM IP.KBD1
012.134 043      3288      INX   H
012.135 136      3289      MOV   E,M      (E) = VLAUE FROM IP.KBD2
012.136 043      3290      INX   H      POINT TO NEXT ENTRY
012.137 325      3291      PUSH  D      SAVE KEYBOARD VALUES
012.140 021 244 100 3292      LXI   D,KBDF      (D,E) = BEGINNING OF FIFO FOR BUBBLE DOWN
012.143 001 016 000 3293      LXI   B,KBDFL-2      (B,C) = NUMBER OF BYTES TO BUBBLE
3294 *      LDIR      BUBBLE UNTIL (B,C) = ZERO
012.146 355 260      3295      DB    I.LDIRA,I.LDIRB
012.150 067      3296      STC      CLEAR CARRY BIT TO INDICAT VALUE FOUND
012.151 077      3297      CMC
012.152 321      3298      POP   D      (D,E) = KEYBOARD VALUES
012.153 341      3299 FVKF1  POP   H      RESTORE REGISTERS
012.154 301      3300      POP   B
012.155 373      3301      EI
012.156 311      3302      RET

3304 **      SBR - SET BAUD RATE
3305 *
3306 *      *SBR* ALLOWS THE BUAD RATE TO BE SET INDEPENDANT OF THE POWER-UP
3307 *      SWITCH CONFIGURATION
3308 *
3309 *
3310 *      ENTRY  NONE
3311 *
3312 *      EXIT   NONE
3313 *
3314 *      USES   A,B,C,D,E,H,L,F
3315
3316
012.157 315 070 012 3317 SBR  CALL  FNCP      FETCH NEXT CHARACTER
3318
3319 *      INPUT CHARACTER MUST BE AN ASCII A,B,C,D,E,F,G OR H. (A=110, B=150,
3320 *      C=300, D=600, E=1200, F=1800, G=2000, H=2400, I=3600, J=4800, K=7200,
3321 *      L=9600)

```

```

3322 *
012.162 376 101 3323 SBR1 CPI 'A' SEE IF CHARACTER IS IN RANGE
012.164 330 3324 RC IF LESS THAN AN 'A'
3325
012.165 376 116 3326 CPI 'N'
012.167 320 3327 RNC IF GREATER THAN A 'P'
3328
012.170 346 017 3329 ANI P1.BR MASK FOR LOWER BITS
3330
3331 * ALTERNATE ENTRY POINT FROM *ASBR*
3332 *
012.172 107 3333 SBR, MOV B,A SAVE RESULT
012.173 072 312 100 3334 LDA MODES GET SERIAL I/O MODE
012.176 346 360 3335 ANI 3770-MS.BR TOSS OLD BAUD RATE
012.200 260 3336 ORA B REPLACE WITH NEW BAUD RATE
012.201 062 312 100 3337 STA MODES UPDATE *IMAGE*
3338 * JMP IACE SET ACE TO NEW RATE
000.000 3339 * ERRNZ *-IACE

3341 ** IACE - INITIALIZE ACE (UART)
3342 *
3343 * *IACE* SETS UP THE DEFAULT I/O PARAMETERS ACCORDING TO THE SWITCH
3344 * POSITIONS ON PORT MP.PUP1
3345 *
3346 *
3347 * ENTRY NONE
3348 *
3349 * EXIT NONE
3350 *
3351 * USES A,B,C,D,E,H,L,F
3352
3353
012.204 076 200 3354 IACE MVI A,AB.DLAB SET DIVISOR LATCH ACCESS BIT
012.206 323 103 3355 OUT AP.LCR
3356
3357 * SET BAUD RATE DIVISORS TO DESIRED BAUD RATE
3358 *
012.210 072 312 100 3359 LDA MODES GET SERIAL I/O MODE (POWER-UP SWITCH #1)
012.213 117 3360 MOV C,A SAVE IMAGE
012.214 346 017 3361 ANI MS.BR MASK FOR BAUD RATE SWITCHES
012.216 050 001 3362 JR Z,IACE0.5 IF SWITCHES ARE SET TO ZERO KEEP 110 BAUD
3363
012.220 075 3364 DCR A ELSE, SWITCHES = SWITCHES-1
012.221 107 3365 IACE0.5 MOV B,A
012.222 007 3366 RLC SWITCHES*2 = TABLE VECTOR
012.223 041 301 012 3367 LXI H,BRTAB POINT TO BAUD RATE DIVISOR TABLE
012.226 205 3368 ADD L ADD VECTOR
012.227 157 3369 MOV L,A
012.230 176 3370 MOV A,M GET DESIRED DIVISOR LSB
012.231 323 100 3371 OUT AP.DLL OUTPUT TO ACE
012.233 043 3372 INX H
012.234 176 3373 MOV A,M GET DIVISOR MSB
012.235 323 101 3374 OUT AP.DLM OUTPUT TO ACE

```

```
3375
3376 *      SET WORD CONFIGURATION
3377 *
012,237 257 3378 XRA A      CLEAR ACC
012,240 260 3379 ORA B      SEE IF 110 BAUD
012,241 006 000 3380 MVI B,0     SET ONE STOP BIT IF NOT 110 BAUD
012,243 040 002 3381 JR NZ,ACE1   IF (B) NOT 110 BAUD
3382
012,245 006 004 3383 MVI B,AB.2SB  ELSE, SET TWO STOP BITS IN B
012,247 171 3384 ACE1 MOV A,C     GET PARITY CONFIGURATION
012,250 346 160 3385 ANI P1.PEN+P1.EPS+P1.SPS
012,252 017 3386 RRC      SHIFT INTO POSITION FOR UART
012,253 260 3387 ORA B      ADD NUMBER OF STOP BITS
012,254 107 3388 MOV B,A     SAVE RESULT
012,255 346 010 3389 ANI P1.PEN/2  SEE IF PARITY WAS ON
012,257 076 002 3390 MVI A,AB.7BW  SET SEVEN BIT WORD IF PARITY ON
012,261 040 002 3391 JR NZ,ACE2   IF PARITY ON
3392
012,263 076 003 3393 MVI A,AB.8BW  ELSE, SET AN 8 BIT WORD WITH NO PARITY
012,265 260 3394 ACE2 ORA B      ADD TO STOP BITS AND PARITY SELECT/TYPE
012,266 323 103 3395 OUT AF.LCR    OUTPUT WORD SIZE AND PARITY SELECTION TO ACE
3396
012,270 076 001 3397 MVI A,AB.ERDA  ENABLE RECEIVED DATA AVAILABLE INTERRUPTS
012,272 323 101 3398 OUT AP.IER
012,274 076 003 3399 MVI A,AB.DTR+AB.RTS SET DATA TERMINAL READY
012,276 323 104 3400 OUT AP.MCR
012,300 311 3401 RET
```

```
3403 **      BRTAB - BAUD RATE DIVISOR TABLE
3404 *
3405 *      *BRTAB* CONTAINS THE ACE DIVISOR LSB FOLLOWED BY THE MSB
3406 *
3407 *      TABLE MUST RESIDE IN ONE PAGE
3408
3409
012,301 3410 BRTAB EQU *
012,301 321 006 3411 BR110 DB 209,6 110 BAUD
012,303 000 005 3412 BR150 DB 0,5 150 BAUD
012,305 173 002 3413 BR300 DB 123,2 300 BAUD
012,307 100 001 3414 BR600 DB 64,1 600 BAUD
012,311 240 000 3415 BR1200 DB 160,0 1200 BAUD
012,313 153 000 3416 BR1800 DB 107,0 1800 BAUD
012,315 140 000 3417 BR2000 DB 96,0 2000 BAUD
012,317 120 000 3418 BR2400 DB 80,0 2400 BAUD
012,321 065 000 3419 BR3600 DB 53,0 3600 BAUD
012,323 050 000 3420 BR4800 DB 40,0 4800 BAUD
012,325 033 000 3421 BR7200 DB 27,0 7200 BAUD
012,327 024 000 3422 BR9600 DB 20,0 9600 BAUD
012,331 012 000 3423 BR19.2K DB 10,0 19,200 BAUD
000,012 3424 , SET BRTAB/256
000,000 3425 ERNZ */256-
```

```
3427 **      ICRT - INITIALIZE CRT CONTROLLER
3428 *
3429 *      *ICRT* SETS THE CRT CONTROLLER FOR AN 80 COLUMN, 24 LINE
3430 *      DISPLAY WITH THE DISPLAY HOME ADDRESS AND THE CURSOR ADDRESS
3431 *      AT *VRAMS*
3432 *
3433 *
3434 *      ENTRY    NONE
3435 *
3436 *      EXIT     NONE
3437 *
3438 *      USES     A,B,C,H,L,F
3439
3440
012.333      3441 ICRT    EQU    *
3442
012.333      3443        IN      MP,PUP2      GET CONFIGURATION SWITCH INFO
3444
012.335      3445        ANI      P2,50HZ
012.337      3446        LXI      H,VPARD50    (H,L) = 50 HERTZ VIDEO PARAMETERS
012.342      3447        JR       NZ,ICRT0.5   IF SET FOR 50 HZ
3448
012.344      3449        LXI      H,VPARD60    (H,L) = 60 HERTZ VIDEO PARAMETERS
3450
012.347      3451 ICRT0.5 MVI      B,16      16 REGISTERS TO INITIALIZE IN CRTC
012.351      3452        MVI      C,0      START WITH REGISTER ZERO
3453
012.353      3454 ICRT1   MOV      A,C      GET REGISTER ADDRESS
012.354      3455        OUT      VP,AR      SET ADDRESS REGISTER IN CRTC
012.356      3456        MOV      A,M      GET DATA FOR CRTC REGISTER
012.357      3457        OUT      VP,REGD    OUTPUT TO REGISTER
012.361      3458        INR      C      POINT TO NEXT REGISTER
012.362      3459        INX      H      POINT TO NEXT REGISTER'S DATA
012.363      3460        DJNZ     ICRT1     IF NOT DONE WITH ALL REGISTERS
3461
012.365      3462        RET
3463
3464 **      IDT - IDENTIFY TERMINAL
3465 *
3466 *      *IDT* IDENTIFYS THE TERMINAL AS A DEC VT52 SO THAT EXISTING DEC
3467 *      SOFTWARE WHICH INTERROGATES THE CONSOLE TYPE WILL OPERATE AS IT
3468 *      WOULD WITH A VT52
3469 *
3470 *
3471 *      ENTRY    NONE
3472 *
3473 *      EXIT     NONE
3474 *
3475 *      USES     A,B,C,H,L,F
3476
3477
012.366      3478 IDT     CALL     PSOF      REPLY WITH *ESC / K*
012.371      3479        DB       ESC,'/',',K'+2000
```

012.374 311

3480

RET

3482 ** ARAMP - ANSI RESET ALL MODES TO POWER UP CONFIGURATION

3483 *

3484 *

3485 *

3486 *

3487 *

3488 *

3489 *

3490 *

3491 *

3492 *

3493 *

3494 *

012.375 170

3495 ARAMP

MOV

A,B

SEE IF PN WAS INPUT

012.376 267

3496

ORA

A

012.377 300

3497

RNZ

IF PN WAS INPUT, ILLEGAL, EXIT

3498

3499 *

JMP

RAMP

ELSE, CONTINUE LIKE IN HEATH MODE

000.000

3500

ERRNZ

*-RAMP

3502 **

RAMP - RESET ALL MODES TO POWER UP CONFIGURATION

3503 *

3504 *

RAMP PROVIDES THE SAME FUNCTION AS A HARDWARE RESET

3505 *

3506 *

3507 *

3508 *

3509 *

3510 *

3511 *

3512 *

3513 *

013.000 363

3514 RAMP

DI

LOCK OUT THE WORLD

000.000

3515 *

JMP

INIT

3516

ERRNZ

*-INIT

3518 ***

INIT - INITIALIZE SYSTEM ON POWER UP

3519 *

3520 *

3521 *

3522 *

3523 *

3524 *

013.001

3525 INIT

EQU

*

3526 *

JMP

IRAM

INITIALIZE RAM

000.000

3527

ERRNZ *-IRAM

```
3529 **      IRAM - INITIALIZE RAM
3530 *
3531 *      *IRAM* SETS ALL RAM LOCATIONS TO ZERO AND THEN COPYS IN THE
3532 *      DEFAULT DATA FROM PRSTAB
3533 *
3534 *
3535 *      ENTRY    NONE
3536 *
3537 *      EXIT      NONE
3538 *
3539 *      USES      A,B,C,D,E,H,L,F
3540
3541
3542 IRAM LXI    H, RAM      POINT TO BEGINNING OF SCRATCHPAD
3543 LXI    D, RAM+1        COPY TO NEXT LOCATION
3544 LXI    B, 255          COPY 255 TIMES
3545 MVI    M, 0            PLACE ZERO IN FOR COPY
3546 *      LDIR          COPY ZERO THROUGH RAM
3547 DB      I, LDIRA, I, LDIRB
3548
3549 LXI    H, KBDF          SET KEYBOARD FIFO
3550 SHLD   KBDFP
3551 MVI    A, 24           SET VIDEO INFORMATION FOR NMI
3552 STA    VI, VD          VIDEO DISPLAYED
3553 MVI    H, VB, CBE+8    FAST BLINKING CURSOR ON LINE 8
3554 MVI    L, 8            END ON LINE 8 TOO
3555 SHLD   VI, CSE
3556
3557 IN     MP, PUP1        INPUT POWER-UP SWITCH #1
3558
3559 STA    MODES           SAVE AS SERIAL I/O MODE
3560
3561 IN     MP, PUP2        INPUT POWER-UP SWITCH #2
3562 ANI    01111111B      TOSS 50HZ BIT
3563
3564 STA    MODEB           SAVE AS SPECIAL SET UP MODE
3565
3566 IN     MP, PUP2        INPUT POWER-UP SWITCH #2
3567 ANI    377Q-P2, 50HZ  GET ALL BUT LINE FREQUENCY SWITCHES
3568 STA    MODEB           SAVE AS MODEB FLAGS
3569 XRA    A              CLEAR ALL INTERNAL FLAGS
3570 STA    MODEI           SAVE AS INTERNAL MODE WITH ALL OTHER FLAGS = ZERO
3571
3572
3573 LXI    SP, RAM+256     SET STACK POINTER TO TOP OF RAM
3574
3575 LXI    H, VRAMS        SET HOME, CURRENT LINE, AND CURSOR ADDRESSES
3576 SHLD   SHOME
3577 SHLD   CLSA
3578 SHLD   CURAD
3579 LXI    D, 2048         WRITE SPACES IN ALL OF VIDEO RAM
```

```
013.111 315 160 016 3580 CALL WSV
3581
3583 ** CONTINUE INITIALIZATION OF SYSTEM
3584 *
3585
013.114 315 333 012 3586 INIT1 CALL ICRT INITIALIZE CRTC
013.117 315 204 012 3587 CALL IACE INITIALIZE ACE
013.122 315 371 010 3588 CALL EC SET PROPER CURSOR TYPE
3589 * IM1 SET INTERRUPT MODE ONE
013.125 355 126 3590 DB I.IM1A,I.IM1B
013.127 076 000 3591 MVI A,0 CAUSE FIRST NMI
013.131 323 144 3592 OUT VP.AR+VB.NMI
013.133 373 3593 EI LET IT ALL BEGIN
013.134 303 004 000 3594 JMP MAIN GO TO MAIN LOOP
```

```
3596 ** MPY80 - MULTIPLY BY EIGHTY
3597 *
3598 * MULTIPLY AN 8 BIT NUMBER BY EIGHTY
3599 *
3600 *
3601 * ENTRY (A) = MULTIPLICAND
3602 *
3603 * EXIT (H,L) = (A)*80
3604 *
3605 * USES D,E,H,L,F
3606
3607
013.137 157 3608 MPY80 MOV L,A VALUE TO MULTIPLY TO (H,L)
013.140 046 000 3609 MVI H,0
013.142 051 3610 DAD H *16
013.143 051 3611 DAD H
013.144 051 3612 DAD H
013.145 051 3613 DAD H
013.146 124 3614 MOV D,H *5
013.147 135 3615 MOV E,L
013.150 031 3616 DAD D
013.151 031 3617 DAD D
013.152 031 3618 DAD D
013.153 031 3619 DAD D
013.154 311 3620 RET
```

```

3622 **      NKC - NO KEYBOARD CLICK
3623 *
3624 *      *NKC* SETS THE FLAG WHICH DISABLES THE KEYBOARD CLICK DURING *AKI*
3625 *
3626 *
3627 *      ENTRY   (B,C) = MODEB
3628 *
3629 *      EXIT     NONE
3630 *
3631 *      USES     A,F
3632 *
3633 *
013.155 012 3634 NKC LDAX   B      GET CURRENT FLAGS
013.156 366 002 3635 ORI    MB.NOTK SET NO TICK
013.160 002 3636 STAX   B
013.161 311 3637 RET

```

```

3639 **      PCA - PERFORM CURSOR ADDRESSING
3640 *
3641 *      *PCA* SETS THE CURSOR LINE AND COLUMN VALUES ACCORDING TO THE
3642 *      NEXT TWO BYTES FROM THE INPUT FIFO.  LINE NUMBER 40Q IS THE TOP
3643 *      LINE OF THE DISPLAY.  COLUMN 40Q IS THE LEFTMOST COLUMN.  AN ILLEGAL
3644 *      LINE NUMBER WILL CAUSE THE CURSOR TO REMAIN ON THE CURRENT LINE.
3645 *      AN ILLEGAL COLUMN NUMBER WILL CAUSE THE CURSOR TO BE PLACED AT
3646 *      THE END OF THE CURRENT LINE.
3647 *
3648 *
3649 *      ENTRY     NONE
3650 *
3651 *      EXIT      NONE
3652 *
3653 *      USES      A,B,C,D,E,H,L,F
3654 *
3655 *
013.162 315 070 012 3656 PCA  CALL  FNCP      FETCH NEXT INPUT FIFO CHARACTER
013.165 376 030 3657 CPI    CAN      SEE IF TO CANCEL THIS SEQUENCE
013.167 310 3658 RZ      IF CANCEL
3659 *
3660 *      HAVE A LINE NUMBER, PROCESS IT
3661 *
013.170 376 040 3662 PCA1 CPI    40Q      SEE IF LINE NUMBER IS IN RANGE
013.172 070 024 3663 JR     C,PCA2    IF LESS THAN LINE ZERO, USE SAME LINE
3664 *
013.174 376 070 3665 CPI    40Q+24
013.176 070 013 3666 JR     C,PCA1.5  IF LINE 23 OR LESS
3667 *
013.200 040 016 3668 JR     NZ,PCA2    IF NOT 24, USE SAVE
3669 *
013.202 107 3670 MOV    B,A      ELSE, SAVE LINE NUMBER
013.203 072 311 100 3671 LDA    MODE1    GET MODE FLAGS
013.206 346 200 3672 ANI    MI.25L   SEE IF 25TH LINE IS ENABLED
013.210 050 006 3673 JR     Z,PCA2    IF LINE 24 REQUESTED AND NOT AVAILABLE
3674 *

```

H19 TERMINAL FIRMWARE				HEATH HBASM V1.4 01/20/78		PAGE 75
GENERAL USE SUBROUTINES				PCA	09:16:14 30-MAY-80	
013.212	170	3675	MOV	A,B	ELSE, GET LINE 24 VALUE BACK AND USE IT	
		3676				
013.213	326 040	3677	PCA1.5	SUI	40Q	MASK FOR LINE VALUE
013.215	062 273 100	3678		STA	CURVP	SAVE NEW VERTICAL POSITION
		3679				
013.220	315 070 012	3680	PCA2	CALL	FNCP	FETCH NEXT INPUT FIFO CHARACTER
013.223	376 030	3681		CPI	CAN	SEE IF TO CANCEL NOW
013.225	050 017	3682		JR	Z,PCA6	IF TO CANCEL
		3683				
		3684	*			HAVE A COLUMN NUMBER
		3685	*			
013.227	376 040	3686	PCA3	CPI	40Q	SEE IF IN RANGE
013.231	070 004	3687		JR	C,PCA4	IF LESS THAN COLUMN ZERO
		3688				
013.233	376 160	3689		CPI	40Q+80	
013.235	070 002	3690		JR	C,PCA5	IF COLUMN ZERO THRU 79
		3691				
013.237	076 157	3692	PCA4	MVI	A,40Q+79	OUT OF RANGE, SET CURSOR TO END OF LINE
013.241	326 040	3693	PCA5	SUI	40Q	MASK FOR COLUMN VALUE
013.243	062 272 100	3694		STA	CURHP	UPDATE COLUMN COUNTER
		3695				
013.246	303 322 015	3696	PCA6	JMP	SNCP	SET CURSOR POSITION
		3698	**			PCIF - PLACE CHARACTER IN FIFO
		3699	*			
		3700	*			*PCIF* PLACES A SINGLE CHARACTER INTO THE INPUT FIFO
		3701	*			
		3702	*			
		3703	*	ENTRY	(A) = CHARACTER	
		3704	*			
		3705	*	EXIT	(A) = CHARACTER	
		3706	*		'C' = SET IF NO ROOM IN FIFO	
		3707	*			
		3708	*	USES	A,B,C,H,L,F	
		3709				
		3710				
013.251	117	3711	PCIF	MOV	C,A	SAVE CHARACTER FOR FIFO
013.252	072 241 100	3712		LDA	IFC	GET INPUT FIFO COUNTER
013.255	376 200	3713		CPI	IFMAX	CHECK FOR FIFO ALREADY FULL
013.257	067	3714		STC		SET 'C' FOR FIFO FULL
013.260	312 223 010	3715		JZ	DING	DING BELL AND EXIT
		3716				
013.263	107	3717		MOV	B,A	ELSE, SAVE FIFO COUNTER
013.264	072 240 100	3718		LDA	IFP	GET INPUT FIFO POINTER
013.267	200	3719		ADD	B	ADD COUNT FOR VECTOR TO NEXT CHARACTER ADDRESS
013.270	346 177	3720		ANI	IFCMASK	KEEP VECTOR IN FIFO
013.272	041 000 100	3721		LXI	H,INF	POINT TO INPUT FIFO
013.275	205	3722		ADD	L	ADD VECTOR
013.276	157	3723		MOV	L,A	
013.277	161	3724		MOV	M,C	PLACE CHARACTER IN FIFO
013.300	170	3725		MOV	A,B	INCREMENT INPUT FIFO COUNTER
013.301	074	3726		INR	A	
013.302	062 241 100	3727		STA	IFC	

013.305	067	3728	STC		CLEAR 'C' TO SHOW THAT CHARACTER WAS PLACED
013.306	077	3729	CMC		
013.307	171	3730	MOV	A,C	CHARACTER TO (A)
013.310	311	3731	RET		

		3733	**		PCOF - PLACE CHARACTER IN OUTPUT FIFO
		3734	*		
		3735	*		*PCOF* PLACES A SINGLE CHARACTER INTO THE OUTPUT FIFO
		3736	*		
		3737	*		
		3738	*		ENTRY (A) = CHARACTER
		3739	*		
		3740	*		EXIT (A) = CHARACTER
		3741	*		'C' = SET IF NO ROOM IN FIFO
		3742	*		
		3743	*		USES A,B,C,H,L,F
		3744			
		3745			
013.311	117	3746	PCOF	MOV	C,A
					SAVE CHARACTER
013.312	072 311 100	3747		LDA	MODE1
					GET MODE FLAGS
013.315	346 010	3748		ANI	MI.ONLN
					IS TERMINAL ON-LINE?
013.317	040 005	3749		JR	NZ,PCOF1
					IF TERMINAL IS ON-LINE
		3750			
		3751	*		TERMINAL IS OFF-LINE, PLACE CHARACTER IN INPUT FIFO INSTEAD
		3752	*		
013.321	171	3753		MOV	A,C
013.322	315 251 013	3754		CALL	PCIF
					PLACE CHARACTER IN INPUT FIFO
013.325	311	3755		RET	
		3756			
013.326	072 312 100	3757	PCOF1	LDA	MODES
					GET MODE FOR SERIAL I/O
013.331	346 200	3758		ANI	MS.FDX
					IS FULL DUPLEX SELECTED?
013.333	171	3759		MOV	A,C
					(A) = CHARACTER
013.334	314 251 013	3760		CZ	PCIF
					IF HALF DUPLEX, PLACE CHARACTER IN BOTH FIFOS
		3761			
013.337	072 243 100	3762		LDA	OFC
					GET OUTPUT FIFO COUNTER
013.342	376 040	3763		CPI	OFMAX
					SEE IF FIFO IS FULL
013.344	067	3764		STC	
					SET 'C' FOR FULL
013.345	050 025	3765		JR	Z,PCOF2
					IF FIFO IS ALREADY FULL
		3766			
013.347	107	3767		MOV	B,A
					SAVE CURRENT COUNT
013.350	072 242 100	3768		LDA	OFF
					GET OUTPUT FIFO POINTER
013.353	200	3769		ADD	B
					ADD TO COUNT FOR VECTOR TO ADDRESS FOR THIS CHAR
013.354	346 037	3770		ANI	OFCMSK
					KEEP VECTOR IN FIFO
013.356	041 200 100	3771		LXI	H,OUTF
					POINT TO OUTPUT FIFO
013.361	205	3772		ADD	L
					ADD VECTOR
013.362	157	3773		MOV	L,A
013.363	161	3774		MOV	M,C
					PUT CHARACTER IN FIFO
013.364	170	3775		MOV	A,B
					INCREMENT OUTPUT FIFO COUNTER
013.365	074	3776		INR	A
013.366	062 243 100	3777		STA	OFC
013.371	067	3778		STC	
					CLEAR 'C' TO SHOW CHARACTER PLACED
013.372	077	3779		CMC	
013.373	171	3780		MOV	A,C
					(A) = OUTPUT CHARACTER

013.374 311 3781 PCOF2 RET

3783 ** PCOFT - PLACE CHARACTER IN OUTPUT FIFO DURING TASK TIME

3784 *

3785 *

3786 * ENTRY (A) = CHARACTER

3787 *

3788 * EXIT 'C' SET IF NO ROOM

3789 *

3790 * USES A,B,C,H,L,F

3791

3792

013.375 363 3793 PCOFT DI LOCK OUT INTERRUPT CHARACTER REMOVALS

013.376 315 311 013 3794 CALL PCOF PLACE CHARACTER

014.001 373 3795 EI ALLOW INTERRUPTS NOW

014.002 311 3796 RET

3798 ** PCRLF - PERFORM CARRIAGE RETURN AND/OR LINE FEED

3799 *

3800 * *PCRLF* PERFORMS A LINE FEED PRIOR TO PERFORMING A CARRIAGE

3801 * RETURN IF THE AUTO LINE FEED FUNCTION IS SELECTED

3802 *

3803 *

3804 * ENTRY NONE

3805 *

3806 * EXIT NONE

3807 *

3808 * USES A,H,L,F

3809

3810

014.003 072 310 100 3811 PCRLF LDA MODEB GET MODE FLAGS

014.006 346 010 3812 ANI MB,ALF SEE IF AUTO LINE FEED IS SELECTED

014.010 304 354 006 3813 CNZ PLF IF SELECTED

3814 * JMP PCR PERFORM CARRIAGE RETURN

000.000 3815 ERRNZ *-PCR

3817 ** PCR - PERFORM CARRIAGE RETURN

3818 *

3819 * PCR MOVES THE CURSOR TO THE BEGINNING OF THE CURRENT LINE

3820 *

3821 *

3822 * ENTRY NONE

3823 *

3824 * EXIT NONE

3825 *

3826 * USES A,H,L,F

3827


```
3828
014.013 076 000 3829 PCR MVI A,0 SET CURSOR HORIZONTAL POSITION TO ZERO
014.015 062 272 100 3830 STA CURHP
014.020 052 270 100 3831 LHLD CLSA SET CURSOR ADDRESS TO BEGINNING OF LINE
014.023 042 274 100 3832 SHLD CURAD
3833
3834
014.026 311 3835 RET EXIT
```

```
3837 ** PDC - PERFORM DELETE CHARACTER
3838 *
3839 * *PDC* DELETES THE CHARACTER AT THE CURSOR POSITION BY MOVING
3840 * THE REMAINING CHARACTERS ON THE LINE TO THE LEFT ONE COLUMN AND
3841 * INSERTING A SPACE IN THE LAST COLUMN ON THE LINE
3842 *
3843 *
3844 * ENTRY NONE
3845 *
3846 * EXIT NONE
3847 *
3848 * USES A,B,C,D,E,H,L,F
3849
3850
014.027 3851 PDC EQU *
3852
3853
014.027 072 272 100 3854 LDA CURHP GET CURRENT COLUMN POSITION
3855 * NEG SUBTRACT FROM 79 FOR NUMBER OF MOVES
014.032 355 104 3856 DB I,NEGA,I,NEGB
014.034 306 117 3857 ADI 79
014.036 117 3858 MOV C,A SAVE RESULT
014.037 006 000 3859 MVI B,0
3860 * LD DE,(CURAD) (D,E) = CURSOR ADDRESS
014.041 355 133 3861 DB I,LDEDA,I,LDEDB
014.043 274 100 3862 RW CURAD
014.045 050 022 3863 JR Z,PDC2 IF ALREADY AT COLUMN 79
3864
014.047 052 274 100 3865 LHLD CURAD (H,L) = CURSOR ADDRESS + 1
014.052 043 3866 INX H
3867
014.053 172 3868 PDC1 MOV A,D KEEP POINTERS IN VIDEO RAM
014.054 366 370 3869 ORI VRAMS/256
014.056 127 3870 MOV D,A
014.057 174 3871 MOV A,H
014.060 366 370 3872 ORI VRAMS/256
014.062 147 3873 MOV H,A
3874 * LDJ COPY FROM (H,L) TO (D,E)
014.063 355 240 3875 DB I,LDIA,I,LDIB
014.065 170 3876 MOV A,B SEE IF (B,C) = ZERO
014.066 261 3877 ORA C
014.067 040 362 3878 JR NZ,PDC1 IF NOT DONE WITH LAST CHARACTER
3879
014.071 076 040 3880 PDC2 MVI A,' ' PUT SPACE IN LAST COLUMN
```



```
014.155 040 355 3934 JR NZ,PDL1 IF NOT DONE, DO 16 MORE
3935
014.157 353 3936 PDL2 XCHG (H,L) = LINE 23
014.160 006 005 3937 MVI B,5 ERASE 80 CHARACTERS (5*16)
014.162 303 212 016 3938 JMP WSV4 WRITE 80 SPACES AND EXIT

3940 ** PIC - PERFORM INSERT CHARACTER
3941 *
3942 * *PIC* MOVES ALL CHARACTERS THAT ARE AT AND TO THE RIGHT OF THE
3943 * CURSOR ONE COLUMN TO THE RIGHT
3944 *
3945 *
3946 * ENTRY NONE
3947 *
3948 * EXIT NONE
3949 *
3950 * USES A,B,C,D,E,H,L,F
3951
014.165 3952
3953 PIC EQU *
3954
3955
014.165 072 272 100 3956 LDA CURHP GET CURRENT COLUMN POSITION
3957 * NEG SUBTRACT FROM 79 FOR NUMBER OF CHAR. TO MOVE
014.170 355 104 3958 DB I,NEGA,I,NEGB
014.172 306 117 3959 ADI 79
014.174 310 3960 RZ IF AT COLUMN 79, NO COPY NEEDED
3961
014.175 117 3962 MOV C,A (B,C) = RESULT
014.176 006 000 3963 MVI B,0
014.200 052 270 100 3964 LHLD CLSA GET CURRENT LINE STARTING ADDRESS
014.203 021 117 000 3965 LXI D,79 ADD 79 FOR END OF LINE ADDRESS
014.206 031 3966 DAD D (D,E) = ADDRESS OF END OF LINE
014.207 124 3967 MOV D,H
014.210 135 3968 MOV E,L (H,L) = ADDRESS OF END OF LINE -1
014.211 053 3969 DCX H
3970
014.212 172 3971 PIC1 MOV A,D STAY IN VIDEO RAM
014.213 366 370 3972 ORI VRAMS/256
014.215 127 3973 MOV D,A
014.216 174 3974 MOV A,H
014.217 366 370 3975 ORI VRAMS/256
014.221 147 3976 MOV H,A
3977 * LDD COPY CHARACTER
014.222 355 250 3978 DB I,LDDA,I,LDDB
014.224 170 3979 MOV A,B SEE IF COUNT EXHAUSTED
014.225 261 3980 DRA C
014.226 040 362 3981 JR NZ,PIC1 IF NOT DONE YET
3982
014.230 052 274 100 3983 LHLD CURAD GET CURSOR ADDRESS TO PLACE CHARACTER
014.233 311 3984 RET
```

```
3986 **      PIL - PERFORM INSERT LINE
3987 *
3988 *      *PIL* INSERTS A BLANK LINE AT THE CURSOR POSITION AFTER MOVING
3989 *      THE REMAINING LINES DOWN ONE LINE. DATA ON LINE 23 IS LOST.
3990 *
3991 *
3992 *      ENTRY    NONE
3993 *
3994 *      EXIT     NONE
3995 *
3996 *      USES     A,B,C,D,E,H,L,F
3997 *
3998 *
014.234      3999 PIL    EQU    *
4000
4001
014.234 072 273 100 4002 LDA    CURVP      GET CURRENT LINE NUMBER
4003 *      NEG      SUBTRACT FROM 23 FOR NUMBER OF LINES TO MOVE
4004 DB      I,NEGA,I,NEGB
4005 ADI     23
4006 JR      Z,PIL2      IF ON LAST LINE, SKIP COPY
4007
4008 MOV     C,A          LINES*5 = MOD 16 CHARACTER COUNT
4009 ADD     C
4010 ADD     C
4011 ADD     C
4012 ADD     C
4013 MOV     C,A          (C) = RESULT
4014 *      LD      DE,(SHOME) (D,E) = CURRENT HOME POSITION
4015 DB      I,LDEDA,I,LDEDB
4016 DW     SHOME
4017 LXI     H,1819      ADD NUMBER OF CHARACTERS TO POINT TO LAST CHAR.
4018 DAD     D            (H,L) = LAST ADDRESS IN DISPLAY
4019 PUSH    H            SAVE ON STACK
4020 LXI     H,1839      ADD NUMBER OF CHARACTERS TO END OF LINE 22
4021 DAD     D            (H,L) = END OF LINE 22
4022 POP     D            (D,E) = END OF LINE 23
4023
014.271 305      4024 PIL1  PUSH    B          SAVE (B,C)
014.272 172      4025 MOV     A,B          KEEP POINTERS IN VIDEO RAM
014.273 366 370  4026 ORI     VRAMS/256
014.275 127      4027 MOV     B,A
014.276 174      4028 MOV     A,H
014.277 366 370  4029 ORI     VRAMS/256
014.301 147      4030 MOV     H,A
014.302 016 020  4031 MVI     C,16      COPY 16 BYTES
014.304 006 000  4032 MVI     B,0
4033 *      LDDR
014.306 355 270  4034 DB      I,LDDRA,I,LDDRB
014.310 301      4035 POP     B          RESTORE (B,C)
014.311 015      4036 DCR     C          COPY COMPLETE?
014.312 040 355  4037 JR      NZ,PIL1      IF NOT DONE
4038
014.314 172      4039 MOV     A,D          KEEP POINTERS IN VIDEO RAM
014.315 366 370  4040 ORI     VRAMS/256
014.317 127      4041 MOV     D,A
```

```
014.320 174 4042 MOV A,H
014.321 366 370 4043 ORI VRAMS/256
014.323 147 4044 MOV H,A
4045 * LDD COPY FIRST CHARACTER ON THIS LINE
014.324 355 250 4046 DB I,LDDA,I,LDDB
4047
014.326 076 000 4048 PIL2 MVI A,0 SET CURSOR TO BENINNING OF LINE
014.330 062 272 100 4049 STA CURHP
014.333 052 270 100 4050 LHLD CLSA SET CURAD TO BEGINNING OF LINE
014.336 042 274 100 4051 SHLD CURAD
014.341 006 005 4052 MVI B,5 WRITE 80 SPACES (5*16)
014.343 303 212 016 4053 JMP WSA

4055 ** PSD - PARAMETER STRING DECODER
4056 *
4057 * *PSD* INPUTS A PARAMETER STRING OF DECIMAL NUMBERS SEPARATED BY
4058 * A SEMICOLON (TO A MAX OF 15) UNTIL THE FINAL CHARACTER OF THE
4059 * ESCAPE SEQUENCE (NON DECIMAL AND NOT A SEMICOLON) IS INPUT
4060 *
4061 *
4062 * ENTRY NONE
4063 *
4064 * EXIT (A) = FINAL CHARACTER
4065 * (B) = ZERO IF NO PARAMETER STRING PRECEEDING FINAL CHARACTER
4066 *
4067 * USES A,B,C,D,H,L,F
4068
4069
014.346 041 314 100 4070 PSD LXI H,PSDW POINT TO PSD WORK AREA
014.351 001 000 000 4071 LXI B,0 NO PARAMETER STRING YET
014.354 160 4072 MOV M,B FIRST VALUE = ZERO
014.355 315 070 012 4073 CALL FNCF INPUT FIRST CHARACTER
014.360 376 073 4074 CPI ':' CAN'T HAVE SEMICOLON AS FIRST CHARACTER
014.362 310 4075 RZ IF SEMICOLON, END SEQUENCE
4076
014.363 376 060 4077 PSD1 CPI '0' SEE IF LESS THAN DECIMAL
014.365 070 046 4078 JR C,PSD4 IF TOO LOW, EXIT
4079
014.367 376 072 4080 CPI '9'+1 SEE IF GREATER THAN DECIMAL
014.371 060 017 4081 JR NC,PSD2 IF NOT DECIMAL
4082
4083 * INPUT CHARACTER IS DECIMAL
4084 *
014.373 346 017 4085 ANI 00001111B MASK FOR BINARY
014.375 127 4086 MOV D,A SAVE RESULT
4087
4088 * NEW DIGITS VALUE, MULTIPLY OLD VALUE BY TEN
4089 *
014.376 176 4090 MOV A,M GET OLD VALUE
014.377 007 4091 RLC *2
015.000 167 4092 MOV M,A
015.001 007 4093 RLC *4
015.002 007 4094 RLC *8
```

015.003	206	4095	ADD	M	*2 + *8 = *10
015.004	202	4096	ADD	D	ADD NEW DIGITS
015.005	167	4097	MOV	M,A	SAVE RESULT
015.006	004	4098	INR	B	SHOW THAT A PN HAS BEEN INPUT
015.007	014	4099	INR	C	
015.010	030 016	4100	JR	PSD3.5	INPUT NEXT CHARACTER
		4101			
015.012	376 073	4102	PSD2	CPI	' ; '
015.014	040 017	4103	JR	NZ,PSD4	SEE IF CHARACTER IS A SEMICOLON
		4104			IF NOT, THEN CHARACTER IS FINAL
015.016	175	4105	MOV	A,L	ELSE, SEE IF ROOM FOR THIS PARAMETER
015.017	376 332	4106	CPI	PSDWE-2	SAVE ROOM FOR LAST PLUS FINAL
015.021	050 001	4107	JR	Z,PSD3	IF NO MORE ROOM
		4108			
015.023	043	4109	INX	H	POINT TO NEXT CELL
015.024	016 000	4110	PSD3	MVI	C,0
015.026	066 000	4111	MVI	M,0	RESET PARAMETER BUILD REGISTER
015.030	315 070 012	4112	PSD3.5	CALL	FNCP
015.033	030 326	4113	JR	PSD1	GET NEXT CHARACTER
		4114			DECODE CHARACTER
015.035	127	4115	PSD4	MOV	D,A
015.036	257	4116	XRA	A	SAVE FINAL CHARACTER
015.037	261	4117	ORA	C	SEE IF PN IS IN MEMORY AT CURRENT ADDRESS
015.040	050 001	4118	JR	Z,PSD5	
		4119			IF NOTHING IN PROGRESS
015.042	043	4120	INX	H	ELSE, PUT FINAL IN NEXT BYTE
015.043	162	4121	PSD5	MOV	M,D
015.044	172	4122	MOV	A,D	PUT FINAL CHARACTER IN WORK AREA
015.045	021 314 100	4123	LXI	D,PSDW	AND (A)
015.050	311	4124	RET		(D,E) = PSDW

4126 ** PSIF - PUT STRING IN INPUT FIFO

4127 *

4128 * *PSIF* PLACES THE STRING IMMEDIATELY FOLLOWING THE CALL TO
4129 * THIS ROUTINE INTO THE INPUT FIFO

4130 *

4131 *

4132 * ENTRY NONE

4133 *

4134 * EXIT NONE

4135 *

4136 * USES A,B,C,D,E,H,L,F

4137

4138

015.051 321 4139 PSIF POP D GET ADDRESS OF CHARACTERS TO OUTPUT

015.052 032 4140 PSIF1 LDAX D GET CHARACTER

015.053 023 4141 INX D POINT TO NEXT CHARACTER

015.054 267 4142 ORA A SET CPU FLAGS

015.055 372 067 015 4143 JM PSIF2 IF THIS IS LAST CHARACTER TO OUTPUT

015.060 363 4144

015.061 315 251 013 4145 DI LOCK OUT INTERRUPTS

015.064 373 4146 CALL PCIF PLACE CHARACTER

4147 EI

015.065	030 363	4148	JR	PSIF1	GET NEXT CHARACTER
		4149			
015.067	346 177	4150	PSIF2	ANI	01111111B
015.071	325	4151	PUSH	D	SET RETURN ADDRESS BACK ON STACK
015.072	363	4152	DI		
015.073	315 251 013	4153	CALL	PCIF	PLACE LAST CHARACTER
015.076	373	4154	EI		
015.077	311	4155	RET		

		4157	**		PSOF - PUT STRING IN OUTPUT FIFO
		4158	*		
		4159	*		*PSOF* PLACES THE CHARACTER STRING IMMEDIATELY FOLLOWING THE
		4160	*		CALL TO THIS ROUTINE INTO THE OUTPUT FIFO
		4161	*		
		4162	*		
		4163	*	ENTRY	NONE
		4164	*		
		4165	*	EXIT	NONE
		4166	*		
		4167	*	USES	A,B,C,D,E,H,L,F
		4168			
		4169			
015.100	321	4170	PSOF	POP	D
015.101	032	4171	PSOF1	LDAX	D
015.102	023	4172		INX	D
015.103	267	4173		ORA	A
015.104	372 114 015	4174		JM	PSOF2
		4175			
015.107	315 375 013	4176	CALL	PCOFT	PLACE CHARACTER IN OUTPUT FIFO
015.112	030 365	4177	JR	PSOF1	GET NEXT CHARACTER
		4178			
015.114	346 177	4179	PSOF2	ANI	01111111B
015.116	325	4180	PUSH	D	SET RETURN ADDRESS
015.117	303 375 013	4181	JMP	PCOFT	OUTPUT LAST CHARACTER

		4183	**		*RMS* RESETS THE MODE SPECIFIED BY THE LAST CHARACTER IN THE SEQUENCE
		4184	*		
		4185	*		
		4186	*	ENTRY	(B,C) = MODEB
		4187	*		(D,E) = MODEA
		4188	*		
		4189	*	EXIT	NONE
		4190	*		
		4191	*	USES	A,B,C,D,E,H,L,F
		4192			
		4193			
015.122	041 227 015	4194	RMS	LXI	H,RMST
015.125	030 015	4195	JR	SMSA	(H,L) = RESET MODE SEQUENCE TABLE
					CONTINUE SAME AS SET MODE SEQUENCE

```

4197 **      ASCP - ANSI SAVE CURSOR POSITION
4198 *
4199 *      *ASCP* SAVES THE CURRENT LINE AND COLUMN NUMBERS OF THE CURSOR
4200 *      POSITION
4201 *
4202 *
4203 *      ENTRY      (B) = ZERO IF NO PN WAS INPUT
4204 *
4205 *      EXIT      NONE
4206 *
4207 *      USES      A,H,L,F
4208 *
4209 *
015.127 170 4210 ASCP MOV      A,B      SEE IF PN WAS INPUT
015.130 267 4211          ORA      A
015.131 300 4212          RNZ          IF INPUT, ILLEGAL, EXIT
4213 *
4214 *      JMP      SCP      ELSE, SAVE CURSOR POSITION
000.000 4215          ERRNZ    *-SCP

```

```

4217 **      SCP - SAVE CURSOR POSITION
4218 *
4219 *      *SCP* SAVES THE CURRENT POSITION OF THE CURSOR WHICH MAY BE RESTORED
4220 *      WITH THE USE OF *USCP*
4221 *
4222 *
4223 *      ENTRY      NONE
4224 *
4225 *      EXIT      NONE
4226 *
4227 *      USES      H,L
4228 *
4229 *
015.132 052 272 100 4230 SCP    LHLD    CURHP    GET CURSOR POSITIONS
000.000 4231          ERRNZ    CURVP-CURHP-1  MUST BE CONTIGUOUS
015.135 042 305 100 4232          SHLD    CSA      KEEP IN CURSOR SAVED ADDRESS
015.140 311 4233          RET

```

```

4235 **      SMS - SET MODE SEQUENCE
4236 *
4237 *      *SMS* SETS THE MODE SPECIFIED BY THE LAST CHARACTER IN THE SEQUENCE
4238 *
4239 *
4240 *      ENTRY      (B,C) = MODEB
4241 *                (D,E) = MODEA
4242 *
4243 *      EXIT      NONE
4244 *
4245 *      USES      A,B,C,D,E,H,L,F
4246 *

```

		4247				
015.141	041 205 015	4248	SMS	LXI	H,SMST	(H,L) = SET MODE SEQUENCE TABLE
		4249				
015.144	315 070 012	4250	SMSA	CALL	FNCP	GET FINAL SEQUENCE CHARACTER
015.147	376 030	4251		CPI	CAN	SEE IF TO CANCEL
015.151	310	4252		RZ		IF CANCEL, EXIT NOW
		4253				
015.152	376 061	4254		CPI	'1'	CAN'T BE LOWER THAN ONE
015.154	332 120 003	4255		JC	IFCP	IF LOWER, EXIT LIKE NEVER HERE
		4256				
015.157	376 072	4257		CPI	'9'+1	<= 9
015.161	322 120 003	4258		JNC	IFCP	IF GREATER THAN 9
		4259				
015.164	346 017	4260		ANI	00001111B	FORM HALF ASCII FOR TABLE OFFSET
015.166	075	4261	SMSB	DCR	A	1 = FIRST ENTRY
015.167	007	4262		RLC		*2 FOR TABLE WIDTH
015.170	205	4263		ADD	L	ADD TO STARTING ADDRESS OF TABLE
015.171	157	4264		MOV	L,A	
015.172	176	4265		MOV	A,M	GET FUNCTION ADDRESS LSB
015.173	043	4266		INX	H	
015.174	146	4267		MOV	H,M	MSB
015.175	157	4268		MOV	L,A	
015.176	001 310 100	4269		LXI	B,MODEB	(B,C) = MODEB
015.201	021 307 100	4270		LXI	D,MODEA	(D,E) = MODEA
015.204	351	4271		PCHL		GO TO FUNCTION ROUTINE

4273 ** SMST - SET MODE SEQUENCE TABLE

4274 *

4275 * *SMST* CONTAINS THE ADDRESS OF THE ROUTINE WHICH WILL SET
4276 * THE MODE REQUESTED

4277

4278

015.205		4279	SMST	EQU	*	
015.205	237 010	4280		DW	E25L	ENABLE 25TH LINE
015.207	155 013	4281		DW	NKC	NO KEYBOARD CLICK
015.211	076 011	4282		DW	EHSM	ENTER HOLD SCREEN MODE
015.213	251 015	4283		DW	SBC	SET *BLOCK* CURSOR
015.215	176 010	4284		DW	IIC	DISABLE CURSOR
015.217	136 011	4285		DW	EKSM	ENTER KEYPAD SHIFTED MODE
015.221	113 011	4286		DW	EKAM	ENTER KEYPAD ALTERNATE MODE
015.223	303 010	4287		DW	EALF	ENABLE AUTO LINE FEED ON CARRIAGE RETURN
015.225	276 010	4288		DW	EACR	ENABLE AUTO CARRIAGE RETURN ON LINE FEED
000.015		4289		SET	*/256	
000.000		4290		ERRNZ	SMST/256	TABLE MUST RESIDE IN ONE PAGE

```

4292 **      RMST - RESET MODE SEQUENCE TABLE
4293 *
4294 *      *RMST* CONTAINS THE ADDRESSES OF THE ROUTINES WHICH RESET THE
4295 *      MODE SPECIFIED.
4296
4297
015.227      4298 RMST EQU *
015.227 153 010 4299 DW D25L      DISABLE 25TH LINE
015.231 120 011 4300 DW EKC        ENABLE KEYBOARD CLICK
015.233 301 016 4301 DW XHSM       EXIT HOLD SCREEN MODE
015.235 016 016 4302 DW SUC        SET *UNDERSCORE* CURSOR
015.237 371 010 4303 DW EC         ENABLE CURSOR
015.241 316 016 4304 DW XKSM       EXIT KEYPAD SHIFTED MODE
015.243 311 016 4305 DW XKAM       EXIT KEYPAD ALTERNATE MODE
015.245 270 016 4306 DW XALF       EXIT AUTO LINE FEED ON CARRIAGE RETURN
015.247 263 016 4307 DW XACR       EXIT AUTO CARRIAGE RETURN ON LINE FEED
000.015      4308 SET */256
000.000      4309 ERRNZ RMST/256-,      MUST NOT CROSS PAGE BOUNDARY

```

```

4311 **      SRC - SET BLOCK CURSOR
4312 *
4313 *      *SRC* PROGRAMS THE CRTC TO DISPLAY A SLOW BLINKING BLOCK CURSOR
4314 *
4315 *
4316 *      ENTRY (B,C) = MODER
4317 *      (D,E) = MODEA
4318 *
4319 *      EXIT NONE
4320 *
4321 *      USES A,F
4322
4323
015.251 012      4324 SRC LDAX B      GET MODE FLAGS
015.252 366 001 4325 ORI MB.CBLK  FLAG BLOCK CURSOR
015.254 002      4326 STAX B
015.255 032      4327 LDAX D
015.256 346 020 4328 ANI MA.CD    SEE IF CURSOR IS DISABLED
015.260 300      4329 RNZ          IF DISABLED, EXIT
4330
015.261 046 140 4331 SRC. MVI H,0+VB.CBE+VB.CBPS  START ON LINE ZERO, BLINK, SLOW
015.263 056 011 4332 MVI L,9      STOP ON LINE NINE
015.265 042 277 100 4333 SHLD VI.CSE
015.270 311      4334 RET

```

```
4336 **      SCH - SET CURSOR HOME
4337 *
4338 *      *SCH* PLACES THE CURSOR AT LINE ZERO, COLUMN ZERO
4339 *
4340 *
4341 *      ENTRY  NONE
4342 *
4343 *      EXIT   (H,L) = CURSOR ADDRESS
4344 *
4345 *      USES   A,H,L,F
4346 *
4347 *
015.271 041 000 000 4348 SCH LXI H,0 (H,L) = ZERO
015.274 042 272 100 4349 SHLD CURHP (CURHP & CURVP) = ZERO
000.000 4350 ERRNZ CURVP-CURHP-1
015.277 052 266 100 4351 LHL SHOME RESET CURSOR AND LINE ADDRESSES
015.302 042 274 100 4352 SHLD CURAD
015.305 042 270 100 4353 SHLD CLSA
4354 *
4355 *
015.310 311 4356 RET EXIT WITH OR WITHOUT
```

```
4358 **      AUSCP - ANSI UNSAVE CURSOR POSITION
4359 *
4360 *      *AUSCP* RETURNS THE CURSOR TO THE POSTION PREVIOUSLY SAVED BY *ASCP*
4361 *
4362 *
4363 *      ENTRY  (B) = ZERO IF NO PN WAS INPUT
4364 *
4365 *      EXIT   NONE
4366 *
4367 *      USES   A,B,C,D,E,H,L,F
4368 *
4369 *
015.311 170 4370 AUSCP MOV A,B SEE IF PN WAS INPUT
015.312 267 4371 ORA A
015.313 300 4372 RNZ IF PN INPUT, ILLEGAL, EXIT
4373 *
4374 *      JMP USCP ELSE, UNSAVE CURSOR POSITION
000.000 4375 ERRNZ *-USCP
```

```
4377 **      USCP - UNSAVE CURSOR POSITION
4378 *
4379 *      *USCP* RETURNS TO CURHP AND CURVP THE VALUES SAVED WITH THE
4380 *      USE OF *SCP*
4381 *
4382 *
4383 *      ENTRY  NONE
4384 *
4385 *      EXIT   NONE
```

```

4386 *
4387 *      USES      H,L
4388
4389
015.314 052 305 100 4390 USCP  LHLD  CSA      GET SAVED ADDRESS
015.317 042 272 100 4391      SHLD  CURHP    UPDATE CURRENT POINTERS
000.000              4392      ERNZ  CURVP-CURHP-1  POINTERS ARE CONTIGUOUS
4393
4394 *      JMP      SNCP      SET NEW CURSOR POSITION
000.000              4395      ERNZ  *-SNCP

```



```

4397 **      SNCP - SET NEW CURSOR POSITION
4398 *
4399 *      *SNCP* USES THE CURRENT VALUES OF THE VERTICAL AND HORIZONTAL
4400 *      POSITION CELLS TO SET THE CURSOR POSITION
4401 *
4402 *
4403 *      ENTRY  *CURVP* = VERTICAL POSITION TO BE SET
4404 *             *CURHP* = HORIZONTAL POSITION TO BE SET
4405 *
4406 *      EXIT   'C' = CLEARED
4407 *
4408 *      USES   A,D,E,H,L,F
4409
4410
015.322 072 273 100 4411 SNCP  LDA    CURVP    GET VERTICAL POSITION
015.325 315 137 013 4412      CALL  MPYBQ    *BQ
015.330 353              4413      XCHG      (D,E) = NUMBER OF CHARACTERS TO NEW LINE
015.331 052 266 100 4414      LHLD  SHOME    GET HOME ADDRESS
015.334 031              4415      DAD     D      ADD OFFSET FOR THIS LINES STARTING ADDRESS
015.335 174              4416      MOV     A,H      STAY IN VIDEO RAM
015.336 366 370        4417      ORI     VRAMS/256
015.340 147              4418      MOV     H,A
015.341 042 270 100 4419      SHLD  CLSA      SET CURRENT LINE STARTING ADDRESS
4420
015.344 072 272 100 4421      LDA    CURHP    GET HORIZONTAL POSITION
015.347 137              4422      MOV     E,A      ADD TO LINE STARTING ADDRESS
015.350 026 000        4423      MVI     D,0
015.352 031              4424      DAD     D
015.353 174              4425      MOV     A,H      STAY IN VIDEO RAM
015.354 366 370        4426      ORI     VRAMS/256
015.356 147              4427      MOV     H,A
015.357 042 274 100 4428      SHLD  CURAD    SET CURSOR ADDRESS
015.362 311              4429      RET

```



```
4432 ** STAB - SEARCH TABLE
4433 *
4434 * *STAB* SEARCHES TABLES OF SPECIFIED LENGTH AND WIDTH FOR
4435 * A MATCH WITH THE FIRST CHARACTER IN AN ENTRY
4436 *
4437 *
4438 * ENTRY (A) = CHARACTER TO MATCH
4439 * (D) = TABLE LENGTH
4440 * (E) = TABLE WIDTH
4441 * (H,L) = TABLE ADDRESS
4442 *
4443 * EXIT (A) = FIRST CHARACTER IN TABLE AFTER MATCH OR
4444 * ORIGINAL CHARACTER IF NO MATCH
4445 * (H,L) = FIRST ADDRESS AFTER CHARACTER MATCHED
4446 * 'C' = SET IF NO MATCH
4447 *
4448 * USES A,B,C,D,E,H,L,F
4449
015.363 117 4451 STAB MOV C,A SAVE CHARACTER TO MATCH
015.364 256 4452 STAB1 XRA M CHARACTER MATCH TABLE ENTRY?
015.365 050 013 4453 JR Z,STAB3 IF CHARACTER MATCHED
4454
015.367 103 4455 MOV B,E ELSE, GET WIDTH AND ADVANCE TO NEXT ENTRY
015.370 171 4456 MOV A,C GET CHARACTER TO MATCH
015.371 043 4457 STAB2 INX H ADVANCE (E) BYTES
015.372 020 375 4458 DJNZ STAB2
4459
015.374 025 4460 DCR D DECREMENT LENGTH COUNTER
015.375 040 365 4461 JR NZ,STAB1 IF NOT LAST ENTRY
4462
015.377 171 4463 MOV A,C ELSE, RESTORE ORIGINAL CHARACTER AND EXIT
016.000 067 4464 STC SET 'C'
016.001 311 4465 RET
4466
016.002 043 4467 STAB3 INX H MATCH FOUND, GET NEXT BYTE
016.003 176 4468 MOV A,M
016.004 311 4469 RET
```

```
4471 ** SPWE - SET PREVIOUS WAS AN ESCAPE FLAG
4472 *
4473 *
4474 * ENTRY NONE
4475 *
4476 * EXIT NONE
4477 *
4478 * USES A,F
4479
016.005 072 311 100 4481 SPWE LDA MODEI GET INTERNAL MODE FLAGS
016.010 366 001 4482 ORI MI,PWE SET PWE
016.012 062 311 100 4483 STA MODEI UPDATE FLAGS
016.015 311 4484 RET
```

```

4486 **      SUC - SET UNDERSCORE CURSOR
4487 *
4488 *      *SUC* PROGRAMS THE CRTC FOR A SINGLE SCAN LINE CURSOR ON SCAN
4489 *      LINE EIGHT OF THE CHARACTER ROW.
4490 *
4491 *
4492 *      ENTRY      (B,C) = MODEB
4493 *      (D,E) = MODEA
4494 *
4495 *      EXIT      NONE
4496 *
4497 *      USES      A,B,C
4498 *
4499 *
016.016 012 4500 SUC      LDAX      B          GET MODE FLAGS
016.017 346 376 4501      ANI      255-MB,CBLK    RESET CURSOR = BLOCK FLAG
016.021 002 4502      STAX      B
016.022 032 4503      LDAX      D
016.023 346 020 4504      ANI      MA,CD          SEE IF CURSOR IS DISABLED
016.025 300 4505      RNZ                      IF DISABLED, EXIT
4506
016.026 046 110 4507 SUC      MVI      H,8+VB,CBE    START ON LINE 8, BLINK FAST
016.030 056 010 4508      MVI      L,8          ALSO END ON LINE 8
016.032 042 277 100 4509      SHLD     VI,CSE
016.035 311 4510      RET

4512 **      TAB - TAB CURSOR TO NEXT EIGHT COLUMN
4513 *
4514 *      *TAB* PLACES THE CURSOR AT THE NEXT MULTIPLE OF EIGHT COLUMNS
4515 *      FROM THE BEGINNING OF THE LINE UNLESS THE CURSOR IS WITHIN SEVEN
4516 *      COLUMNS OF THE END, IN WHICH CASE THE CURSOR IS MOVED ONLY ONE COLUMN.
4517 *      THE CURSOR IS NOT WRAPPED TO THE NEXT LINE
4518 *
4519 *
4520 *      ENTRY      NONE
4521 *
4522 *      EXIT      NONE
4523 *
4524 *      USES      A,D,E,H,L,F
4525
4526
016.036 072 272 100 4527 TAB      LDA      CURHP          GET CURRENT HORIZONTAL POSITION
016.041 306 010 4528      ADI      8          ADD EIGHT COLUMNS
016.043 346 370 4529      ANI      377Q-7      TOSS ANY LEFT OVERS LESS THAN EIGHT
016.045 376 120 4530      CPI      80          PAST END OF LINE?
016.047 040 016 4531      JR      NZ,TAB2      IF STILL ON SAME LINE
4532
016.051 072 272 100 4533      LDA      CURHP          GET CURRENT POSITION ON LINE
016.054 376 117 4534      CPI      79          AT LAST COLUMN YET?
4535
016.056 050 003 4536      JR      Z,TAB1,5      IF AT LAST COLUMN, STAY
4537
016.060 074 4538 TAB1      INR      A          ELSE, MOVE ONE COLUMN CLOSER

```

GENERAL USE SUBROUTINES

TAB

09:14:25 30-MAY-80

```

016.061 030 004 4539 JR TAB2 UPDATE CURSOR TO NEW POSITION
                                4540
016.063 076 117 4541 TAB1.5 MVI A,79 ELSE, STOP AT LAST COLUMN OF LAST LINE
016.065 030 000 4542 JR TAB2 UPDATE CURSOR ADDRESS
                                4543
016.067 062 272 100 4544 TAB2 STA CURHP UPDATE COLUMN COUNTER
016.072 137 4545 MOV E,A ADD TO LINE ADDRESS
016.073 026 000 4546 MVI D,0
016.075 052 270 100 4547 LHLD CLSA GET CURRENT LINE ADDRESS
016.100 031 4548 DAD D
016.101 174 4549 MOV A,H STAY IN VIDEO RAM
016.102 366 370 4550 ORI VRAMS/256
016.104 147 4551 MOV H,A
016.105 042 274 100 4552 SHLD CURAD UPDATE CURSOR ADDRESS
                                4553
                                4554
016.110 311 4555 RET EXIT

```

```

4557 ** UCP - UPDATE CURSOR POSITION

```

```

4558 *

```

```

4559 * *UCP* SENDS THE LOWER ELEVEN BITS OF THE CURSOR ADDRESS TO THE CRTIC

```

```

4560 *

```

```

4561 *

```

```

4562 * ENTRY NONE

```

```

4563 *

```

```

4564 * EXIT NONE

```

```

4565 *

```

```

4566 * USES A,H,L,F

```

```

4567

```

```

4568

```

```

016.111 072 273 100 4569 UCP LDA CURVP GET LINE COUNT
016.114 315 137 013 4570 CALL MPY80 MULTIPLY BY 80 CHARACTERS PER LINE
016.117 072 272 100 4571 LDA CURHP GET COLUMN COUNT
016.122 137 4572 MOV E,A ADD TO LINE COUNT
016.123 026 000 4573 MVI D,0
016.125 031 4574 DAD D
016.126 353 4575 XCHG (D,E) = CHARACTER OFFSET FROM HOME POSITION
016.127 052 266 100 4576 LHLD SHOME GET HOME POSITION
016.132 174 4577 MOV A,H MASK FOR A 2K ADDRESS
016.133 346 007 4578 ANI HOMAX/256
016.135 147 4579 MOV H,A
016.136 031 4580 DAD D ADD OFFSET
016.137 174 4581 MOV A,H GET CURAD MSB
016.140 346 077 4582 ANI CURMAX/256 TOSS UPPER 5 BITS
016.142 147 4583 MOV H,A
016.143 042 303 100 4584 SHLD VI,CA
                                4585
4586 * HIT NMI TO MAKE SURE ITS RUNNING
4587 *
016.146 076 000 4588 UCP, MVI A,0 SET REGISTER ZERO AS DUMMY
016.150 323 144 4589 OUT VP,AR+VB,NMI OUT NMI REQUEST WITH PORT NUMBER
016.152 311 4590 RET

```

```

4592 **      WEOL - WRAP AROUND AT END OF LINE
4593 *
4594 *      *WEOL* SETS THE FLAG WHICH CAUSES THE TERMINAL TO PERFORM
4595 *      A CARRIAGE RETURN AND LINE FEED WHEN THE 81ST CHARACTER FOR A
4596 *      LINE IS RECEIVED
4597 *
4598 *
4599 *      ENTRY  (B,C) = MODEB
4600 *
4601 *      EXIT   NONE
4602 *
4603 *      USES   A,F
4604
4605
016.153 012 4606 WEOL LDAX  B      GET MODE FLAGS
016.154 366 004 4607 ORI   MB,WRAP  SET WRAP AROUND FLAG
016.156 002 4608 STAX  B
016.157 311 4609 RET

4611 **      WSV - WRITE SPACES TO VIDEO
4612 *
4613 *      *WSV* WRITES N ASCII SPACE CODES INTO THE VIDEO RAM. THE LAST SPACE
4614 *      WRITTEN MUST BE AT THE END OF A VIDEO LINE (X*80+VRAM).
4615 *
4616 *
4617 *      ENTRY  (D,E) = NUMBER OF SPACES TO BE WRITTEN
4618 *      (H,L) = ADDRESS OF FIRST SPACE TO BE WRITTEN
4619 *
4620 *      EXIT   NONE
4621 *
4622 *      USES   A,B,C,D,E,H,L,F
4623
4624
016.160 4625 WSV EQU   *
4626
4627
016.160 175 4628 WSV0.5 MOV  A,L      GET LSB OF ADDRESS
016.161 346 017 4629 ANI  00001111B  MASK FOR ANY CARRY PAST MOD 16
016.163 050 007 4630 JR   Z,WSV2     IF NO EXTRAS
4631
016.165 016 040 4632 MVI  C,' '      SPACE = FILL CHARACTER
016.167 161 4633 MOV  M,C        PLACE SPACE IN MEMORY
016.170 043 4634 INX  H        POINT TO NEXT
016.171 033 4635 DCX  D        DECREMENT COUNT
016.172 030 364 4636 JR   WSV0.5
4637
016.174 006 004 4638 WSV2 MVI  B,4      ROTATE COUNT TO A MOD 16 COUNTER
016.176 172 4639 WSV3 MOV  A,D      ROTATE MSB
4640
016.177 037 4640 RAR                ROTATE LSB
016.200 127 4641 MOV  D,A
4642
016.201 173 4642 MOV  A,E
016.202 037 4643 RAR
4644
016.203 137 4644 MOV  E,A

```

```
016.204 020 370      4645      DJNZ      WSV3      LOOP 4 TIMES
                        4646
016.206 173          4647      MOV       A,E      CHECK FOR ZERO COUNT
016.207 267          4648      ORA       A
016.210 310          4649      RZ              IF NO SPACES LEFT TO BE WRITTEN
                        4650
016.211 103          4651      MOV       B,E      PLACE MOD 16 COUNT IN B
016.212              4652      WSV4      EQU      *      ALTERNATE ENTRY POINT FROM *PLF*
                        4653
                        4654
016.212 016 040      4655      WSV4.     MOV       C, ' '      (C) = ASCII SPACE
016.214 174          4656      WSV4      MOV       A,H      STAY IN VIDEO RAM
016.215 366 370      4657      ORI       VRAMS/256
016.217 147          4658      MOV       H,A
016.220 161          4659      MOV       M,C      PLACE 16 SPACES IN MEMORY
016.221 043          4660      INX       H
016.222 161          4661      MOV       M,C
016.223 043          4662      INX       H
016.224 161          4663      MOV       M,C
016.225 043          4664      INX       H
016.226 161          4665      MOV       M,C
016.227 043          4666      INX       H
016.230 161          4667      MOV       M,C
016.231 043          4668      INX       H
016.232 161          4669      MOV       M,C
016.233 043          4670      INX       H
016.234 161          4671      MOV       M,C
016.235 043          4672      INX       H
016.236 161          4673      MOV       M,C
016.237 043          4674      INX       H
016.240 161          4675      MOV       M,C
016.241 043          4676      INX       H
016.242 161          4677      MOV       M,C
016.243 043          4678      INX       H
016.244 161          4679      MOV       M,C
016.245 043          4680      INX       H
016.246 161          4681      MOV       M,C
016.247 043          4682      INX       H
016.250 161          4683      MOV       M,C
016.251 043          4684      INX       H
016.252 161          4685      MOV       M,C
016.253 043          4686      INX       H
016.254 161          4687      MOV       M,C
016.255 043          4688      INX       H
016.256 161          4689      MOV       M,C
016.257 043          4690      INX       H
016.260 020 332      4691      DJNZ      WSV4      LOOP UNTIL MOD 16 COUNTER = ZERO
                        4692
016.262 311          4693      RET
                        4694
```

```
4696 **      XACR - EXIT AUTO CARRIAGE RETURN
4697 *
4698 *      *XACR* CLEARS THE AUTO CARRIAGE RETURN FLAG
4699 *
4700 *
4701 *      ENTRY  (B,C) = MODEB
4702 *
4703 *      EXIT    NONE
4704 *
4705 *      USES    A,F
4706 *
4707 *
016.263 012 4708 XACR LDAX  B      GET MODE FLAGS
016.264 346 357 4709 ANI   255-MB.ACR  CLEAR AUTO CARRIAGE RETURN
016.266 002 4710 STAX  B
016.267 311 4711 RET
```

```
4713 **      XALF - EXIT AUTO LINE FEED MODE
4714 *
4715 *      *XALF* CLEARS THE AUTO LINE FEED MODE FLAG
4716 *
4717 *
4718 *      ENTRY  (B,C) = MODEB
4719 *
4720 *      EXIT    NONE
4721 *
4722 *      USES    A,F
4723 *
4724 *
016.270 012 4725 XALF LDAX  B      GET MODE FLAGS
016.271 346 367 4726 ANI   255-MB.ALF
016.273 002 4727 STAX  B
016.274 311 4728 RET
```

```
4730 **      XGM - EXIT GRAPHICS MODE
4731 *
4732 *      *EGM* CLEARS THE GRAPHICS MODE FLAG
4733 *
4734 *      ENTRY  (D,E) = MODEA
4735 *
4736 *      EXIT    NONE
4737 *
4738 *      USES    A,F
4739 *
4740 *
016.275 353 4741 XGM  XCHG  (H,L) = MODEA
4742 *      RES   IB,GRPH,(HL)  RESET GRAPHICS MODE FLAG
016.276 313 216 4743 DB    I,RESHA,I,RESHR,IB,GRPH
016.300 311 4744 RET
```



```
4746 **      XHSM - EXIT HOLD SCREEN MODE
4747 *
4748 *      *XHSM* CLEARS THE HOLD SCREEN MODE FLAG
4749 *
4750 *
4751 *      ENTRY  (D,E) = MODEA
4752 *
4753 *      EXIT   NONE
4754 *
4755 *      USES   A,F
4756
4757
016.301 353 4758 XHSM  XCHG      (H,L) = MODEA
4759 *      RES      IB,HSM,(H,L)
016.302 313 206 4760 DB      I,RESHA,I,RESHB!IB,HSM
016.304 311 4761 RET
```

```
4763 **      XICM - EXIT INSERT CHARACTER MODE
4764 *
4765 *      *XICM* CLEARS THE INSERT CHARACTER MODE FLAG
4766 *
4767 *
4768 *      ENTRY  (D,E) = MODEA
4769 *
4770 *      EXIT   NONE
4771 *
4772 *      USES   A,F
4773
4774
016.305 353 4775 XICM  XCHG      (H,L) = MODEA
4776 *      RES      IB,ICM,(HL)  RESET INSERT CHARACTER MODE FLAG
016.306 313 266 4777 DB      I,RESHA,I,RESHB!IB,ICM
016.310 311 4778 RET
```

```
4780 **      XKAM - EXIT KEYPAD ALTERNATE MODE
4781 *
4782 *      *XKAM* CLEARS THE KEYPAD ALTERNATE MODE FLAG
4783 *
4784 *
4785 *      ENTRY  (B,C) = MODEB
4786 *
4787 *      EXIT   NONE
4788 *
4789 *      USES   A,F
4790
4791
016.311 012 4792 XKAM  LDAX      B          GET MODEB FLAGS
016.312 346 177 4793 ANI      377Q-MB,KPDA
016.314 002 4794 STAX      B
016.315 311 4795 RET
```

```

4797 **      XKSM - EXIT KEYPAD SHIFTED MODE
4798 *
4799 *      *XKSM* CLEARS THE KEYPAD SHIFTED MODE FLAG
4800 *
4801 *
4802 *      ENTRY      (B,C) = MODEB
4803 *
4804 *      EXIT      NONE
4805 *
4806 *      USES      A,F
4807 *
4808 *
016.316 012 4809 XKSM LDAX      B      GET MODEB FLAGS
016.317 346 277 4810 ANI      3770-MB,KPDS
016.321 002 4811 STAX      B
016.322 311 4812 RET

```

```

4814 **      AXMT25 - ANSI TRANSMIT 25TH LINE
4815 *
4816 *      *AXMT25* IS THE ENTRY POINT FOR *XMT25* WHEN THE TERMINAL IS
4817 *      IN THE ANSI MODE
4818 *
4819 *
4820 *      ENTRY      (B) = ZERO IF NO PN WAS INPUT
4821 *
4822 *      EXIT      TO *XMT25*
4823 *
4824 *      USES      A,B,C,D,E,H,L,F
4825 *
4826 *
016.323 170 4827 AXMT25 MOV      A,B      SEE IF PN WAS INPUT
016.324 267 4828 ORA      A
016.325 300 4829 RNZ
4830          IF INPUT, ILLEGAL, EXIT
4831 *      JMP      XMT25      ELSE, TRANSMIT PAGE
000.000 4832 ERRNZ *XMT25

```

```

4834 **      XMT25 - TRANSMIT 25TH LINE
4835 *
4836 *      *XMT25* TRANSMITS THE LINE IN THE SAME MANNER AS *XMTF*, BUT ONLY IF
4837 *      THE 25TH LINE IS ENABLED.
4838 *
4839 *
4840 *      ENTRY      NONE
4841 *
4842 *      EXIT      NONE
4843 *
4844 *      USES      A,B,C,D,E,H,L,F
4845 *
4846 *

```

```

016.326 072 311 100 4847 XMT25 LDA MODEI GET MODE FLAGS
016.331 346 200 4848 ANI MI.25L IS 25TH LINE ON?
016.333 050 021 4849 JR Z,XMT25.1 IF NOT ON, JUST SEND CR
4850
016.335 052 266 100 4851 LHLD SHOME GET CURRENT HOME POSITION
016.340 021 200 007 4852 LXI D,1920 ADD 24 LINES*80 COLUMNS
016.343 031 4853 DAD D
016.344 174 4854 MOV A,H STAY IN VIDEO RAM
016.345 366 370 4855 ORI VRAMS/256
016.347 147 4856 MOV H,A
016.350 353 4857 XCHG FIRST ADDRESS ON LINE TO (D,E)
016.351 006 000 4858 MVI B,0 CURRENT TRANSMIT MODE = NONE
016.353 315 001 017 4859 CALL XMTL TRANSMIT LINE
016.356 076 015 4860 XMT25.1 MVI A,CR TERMINATE LINE WITH A CARRIAGE RETURN
016.360 315 366 016 4861 CALL XMTC
016.363 323 340 4862 OUT MP,BELL SIGNAL DONE TO USER
016.365 311 4863 RET

```

```

4865 ** XMTC - TRANSMIT CHARACTER
4866 *
4867 * *XMTC* PLACES THE GIVEN CHARACTER INTO THE OUTPUT FIFO AND
4868 * ASSURES THAT THE TERMINAL IS IN THE ON-LINE STATE UNTIL THE CHARACTER
4869 * IS SENT
4870 *
4871 *
4872 * ***** CAUTION! THIS ROUTINE MAY *****
4873 * ***** ONLY BE USED BY *XMT??* ROUTINES *****
4874 *
4875 *
4876 *
4877 * ENTRY (A) = CHARACTER TO SEND
4878 *
4879 * EXIT NONE
4880 *
4881 * USES A,D,E,H,L,F
4882 *
4883 *
016.366 365 4884 XMTC PUSH PSW SAVE CHARACTER TO SEND
4885
016.367 333 105 4886 XMTC1 IN AP,LSR GET LINE STATUS REGISTER OF UART
016.371 346 040 4887 ANI AB,THRE HOLDING REGISTER EMPTY?
016.373 050 372 4888 JR Z,XMTC1 IF NOT EMPTY
4889
016.375 361 4890 POP PSW ELSE, OUTPUT CHARACTER
016.376 323 100 4891 OUT AP,THR
017.000 311 4892 RET
4893

```

```
4895 **      XMTL - TRANSMIT LINE
4896 *
4897 *      *XMTL* TRANSMITS ONE LINE TO THE HOST INCLUDING THE APPROPRIATE
4898 *      ESCAPE SEQUENCES FOR ENTERING AND EXITING THE GRAPHICS AND
4899 *      REVERSE VIDEO MODES
4900 *
4901 *
4902 *      ENTRY      (B) = CURRENT TRANSMIT MODE (RV AND/OR GRAPHICS)
4903 *      (D,E) = ADDRESS OF BEGINNING OF LINE
4904 *
4905 *      EXIT      (B) = CURRENT TRANSMIT MODE (UPDATED)
4906 *      (D,E) = LAST ADDRESS OF LINE +1
4907 *
4908 *      USES      A,B,C,D,E,H,L,F
4909 *
4910
017.001 046 120 4911 XMTL MVI H,80      SET NUMBER OF CHARACTERS TO SEND
017.003 345 4912 XMTL1,1 PUSH H
017.004 032 4913 LDAX D      GET CHARACTER
017.005 117 4914 MOV C,A      SAVE FOR LATER USE
017.006 023 4915 INX D      INCREMENT MEMORY POINTER
017.007 172 4916 MOV A,D      STAY IN VIDEO RAM
017.010 366 370 4917 ORI VRAMS/256
017.012 127 4918 MOV D,A
017.013 325 4919 PUSH D      SAVE ADDRESS
017.014 171 4920 MOV A,C      GET CHARACTER TO SEND
017.015 346 177 4921 ANI 01111111B    TOSS ANY REVERSE VIDEO BIT FOR NOW
017.017 376 040 4922 CPI ' '      SEE IF LESS THAN A SPACE (GRAPHICS)
017.021 070 010 4923 JR C,XMTL1    IF A GRAPHIC CHARACTER
4924
017.023 376 177 4925 CPI 177Q      177Q IS ALSO A GRAPHIC DISPLAY CHARACTER
017.025 040 055 4926 JR NZ,XMTL4    IF NOT GRAPHIC
4927
4928 *      CHARACTER IS GRAPHIC
4929 *
017.027 076 136 4930 MVI A,'~'      SET PRINTABLE EQUIVALENT OF 177Q
017.031 030 012 4931 JR XMTL2
4932
017.033 376 037 4933 XMTL1 CPI 37Q      SEE IF GRAPHIC '*'
017.035 040 004 4934 JR NZ,XMTL1,3    IF NOT 37Q
4935
017.037 076 137 4936 MVI A,'-'      ELSE, SET PRINTABLE
017.041 030 002 4937 JR XMTL2      CHECK GRAPHIC MODE
4938
017.043 366 140 4939 XMTL1,3 ORI 01100000B    MAKE GRAPHIC PRINTABLE
017.045 365 4940 XMTL2 PUSH PSW      SAVE CHARACTER TO OUTPUT
4941
4942 *      SEE IF LAST CHARACTER OUTPUT WAS ALSO GRAPHIC
4943 *
4944 *
017.046 313 110 4945 DB I,BIT A,I,BIT B!IB,XMTG!IR,B
017.050 040 067 4946 JR NZ,XMTL6      IF LAST CHARACTER WAS ALSO GRAPHIC
4947
4948 *
017.052 313 310 4949 DB I,SET A,I,SET B!IB,XMTG!IR,B
017.054 072 310 100 4950 LDA MODEB      SEE IF IN ANSI MODE
```

XMTL

```

017.057 346 040 4951 ANI MB.ANSI
017.061 050 012 4952 JR Z,XMTL3 IF IN HEATH MODE
4953
017.063 315 302 017 4954 CALL XMTS TRANSMIT ANSI 'ENTER GRAPHICS' SEQUENCE
017.066 033 133 061 4955 DB ESC,'[', '10', 'm'+200Q
4956
017.073 030 044 4957 JR XMTL6 GO CHECK FOR REVERSE VIDEO
4958
017.075 315 302 017 4959 XMTL3 CALL XMTS TRANSMIT HEATH 'ENTER GRAPHICS' SEQUENCE
017.100 033 306 4960 DB ESC,'F'+200Q
017.102 030 035 4961 JR XMTL6 CHECK FOR REVERSE VIDEO
4962
4963 * CHARACTER IS NOT GRAPHIC
4964 *
017.104 365 4965 XMTL4 PUSH PSW SAVE CHARACTER TO OUTPUT
4966 *
017.105 313 110 4967 DB I.BITA,I.BITB!IB.XMTG!IR.B SEE IF LAST WAS GRAPHIC
017.107 050 030 4968 JR Z,XMTL6 IF LAST WAS NOT GRAPHIC EITHER
4969
4970 * RES 1,B ELSE, SET NO GRAPHIC
017.111 313 210 4971 DB I.RESA,I.RESB!IB.XMTG!IR.B
4972
017.113 072 310 100 4973 LDA MODEB SEE IF IN ANSI MODE
017.116 346 040 4974 ANI MB.ANSI
017.120 050 012 4975 JR Z,XMTL5 IF IN HEATH MODE
4976
017.122 315 302 017 4977 CALL XMTS ELSE, TRANSMIT ANSI 'EXIT GRAPHICS' SEQUENCE
017.125 033 133 061 4978 DB ESC,'[', '11', 'm'+200Q
017.132 030 005 4979 JR XMTL6 CHECK FOR REVERSE VIDEO
4980
017.134 315 302 017 4981 XMTL5 CALL XMTS TRANSMIT HEATH 'EXIT GRAPHICS' SEQUENCE
017.137 033 307 4982 DB ESC,'G'+200Q
4983
4984 * SEE IF CHARACTER IS IN REVERSE VIDEO
4985 *
017.141 4986 XMTL6 EQU *
4987
4988 * BIT 7,C SEE IF MSB IS SET FOR RV
017.141 313 171 4989 DB I.BITA,I.BITB!IB.RV!IR.C
017.143 050 035 4990 JR Z,XMTL7,5 IF NOT RV
4991
4992 * CHARACTER IS REVERSE VIDEO
4993 *
4994 * BIT 2,B SEE IF LAST WAS RV
017.145 313 120 4995 DB I.BITA,I.BITB!IB.XMTR!IR.B
017.147 040 063 4996 JR NZ,XMTL9 IF LAST WAS ALSO RV
4997
4998 * SET 2,B ELSE, SET RV MODE AS CURRENT
017.151 313 320 4999 DB I.SETA,I.SETB!IB.XMTR!IR.B
017.153 072 310 100 5000 LDA MODEB SEE IF IN ANSI MODE
017.156 346 040 5001 ANI MB.ANSI
017.160 050 011 5002 JR Z,XMTL7 IF IN HEATH MODE
5003
017.162 315 302 017 5004 CALL XMTS ELSE, TRANSMIT ANSI 'ENTER REVERSE VIDEO'
017.165 033 133 067 5005 DB ESC,'[', '7', 'm'+200Q
017.171 030 041 5006 JR XMTL9 GO TRANSMIT CHARACTER

```

```

017.173 315 302 017 5007
017.176 033 360 5008 XMTL7 CALL XMTS TRANSMIT HEATH 'ENTER REVERSE VIDEO'
017.200 030 032 5009 DB ESC,'P'+200Q
5010 JR XMTL9 OUTPUT CHARACTER
5011
5012 * CHARACTER IS NOT REVERSE VIDEO
5013 *
017.202 5014 XMTL7.5 EQU *
5015 * BIT 2,B SEE IF LAST CHARACTER WAS RV
017.202 313 120 5016 DB I,BITB,I,BITB!IB,XMTR!IR,B
017.204 050 026 5017 JR Z,XMTL9 IF LAST WASN'T EITHER
5018
5019 * RES 2,B ELSE, SET CURRENT MODE AS NOT REVERSE
017.206 313 220 5020 DB I,RESA,I,RESB!IB,XMTR!IR,B
5021
5022 LDA MODER SEE IF IN ANSI MODE
017.210 072 310 100 5023 ANI MB,ANSI
017.213 346 040 5024 JR Z,XMTL8 IF IN HEATH MODE
5025
5026 CALL XMTS ELSE, SEND ANSI 'EXIT RV'
017.217 315 302 017 5027 DB ESC,'E','m'+200Q
017.222 033 133 355 5028 JR XMTL9 SEND CHARACTER
5029
017.227 315 302 017 5030 XMTL8 CALL XMTS SEND HEATH 'EXIT RV' SEQUENCE
017.232 033 361 5031 DB ESC,'a'+200Q
5032
017.234 361 5033 XMTL9 POP PSW GET CHARACTER TO SEND
017.235 315 366 016 5034 CALL XMTS SEND IT
017.240 321 5035 POP D GET LINE ADDRESS
017.241 341 5036 POP H GET COLUMN COUNTER
017.242 045 5037 DCR H SEE IF ANY LEFT TO SEND
017.243 302 003 017 5038 JNZ XMTL1,1 IF NOT DONE YET
5039
017.246 311 5040 RET

```

```

5042 ** AXMTP - ANSI TRANSMIT PAGE
5043 *
5044 * *AXMTP* IS THE ENTRY POINT FOR *XMTMP* WHEN THE TERMINAL IS IN
5045 * THE ANSI MODE
5046 *
5047 *
5048 * ENTRY (B) = ZERO IF NO PN WAS INPUT
5049 *
5050 * EXIT TO *XMTMP*
5051 *
5052 * USES A,B,C,D,E,H,L,F
5053
5054
017.247 170 5055 AXMTP MOV A,B SEE IF PN WAS INPUT
017.250 267 5056 ORA A
017.251 300 5057 RNZ IF INPUT, ILLEGAL, EXIT
5058
5059 * JMP XMTMP ELSE, TRANSMIT PAGE

```


000.000

5060

ERRNZ *-XMTF

5062 ** XMTF - TRANSMIT PAGE

5063 *

5064 *

5065 *

5066 *

5067 *

5068 *

5069 *

5070 *

5071 *

5072 *

5073 *

5074 *

5075 *

5076 *

5077 *

5078 *

5079 *

5080

017.252 052 266 100

5081

5082

017.255 353

017.256 006 000

5083

017.260 046 030

5084

017.262 345

5085

017.263 315 001 017

5086

017.266 341

5087

017.267 045

5088

017.270 040 370

5089

5090

017.272 076 015

5091

017.274 315 366 016

5092

017.277 323 340

5093

017.301 311

5094

LHLD SHOME

XCHG

MVI B,0

MVI H,24

XMTF1 PUSH H

CALL XMTL

POP H

DCR H

JR NZ,XMTF1

MVI A,CR

CALL XMTF

OUT MF,BELL

RET

GET FIRST ADDRESS ON SCREEN

TO (D,E)

CLEAR CURRENT TRANSMIT MODE

SEND 24 LINES

SAVE COUNT

TRANSMIT ONE LINE

GET LINE COUNTER

COUNT - 1

IF NOT DONE

SEND A CARRIAGE RETURN TO TERMINATE PAGE

TRANSMIT CHARACTER

SIGNAL DONE TO USER

5096 ** XMTS - TRANSMIT STRING

5097 *

5098 *

5099 *

5100 *

5101 *

5102 *

5103 *

5104 *

5105 *

5106 *

5107 *

5108 *

5109 *

ENTRY STRING TO BE SENT MUST IMMEDIATELY FOLLOW THE CALL
TO THIS ROUTINE. FINAL CHARACTER MUST HAVE
BIT SEVEN SET

EXIT NONE

USES A,D,E,H,L,F

```
5110
5111
017.302 321 5112 XMTS POP D GET ADDRESS OF CHARACTERS TO BE SENT
017.303 032 5113 XMTS1 LDAX D GET CHARACTER TO SEND
017.304 023 5114 INX D POINT TO NEXT
017.305 267 5115 ORA A SET CPU FLAGS
017.306 372 316 017 5116 JM XMTS2 IF LAST CHARACTER TO SEND
5117
017.311 315 366 016 5118 CALL XMTS SEND ONE CHARACTER
017.314 030 365 5119 JR XMTS1 GET NEXT
5120
017.316 346 177 5121 XMTS2 ANI 01111111B TOSS TERMINATOR BIT
017.320 315 366 016 5122 CALL XMTS OUTPUT LAST CHARACTER
017.323 325 5123 PUSH D SET RETURN ADDRESS
017.324 311 5124 RET
```

```
5126 ** XRVM - EXIT REVERSE VIDEO MODE
5127 *
5128 * **XRVM* CLEARS THE REVERSE VIDEO MODE FLAG
5129 *
5130 *
5131 * ENTRY (D,E) = MODEA
5132 *
5133 * EXIT NONE
5134 *
5135 * USES A,F
5136
5137
017.325 5138 XRVM EQU *
5139
5140
017.325 353 5141 XCHG (H,L) = MODEA
5142 * RES IB,RV,(HL) RESET FLAG
017.326 313 276 5143 DB I,RESHA,I,RESHB,IB,RV
017.330 311 5144 RET
```

5147 ** VPARD60 - VIDEO PARAMETER DATA

5148 *

5149 * THE CONTENTS OF VPARD60 ARE COPIED TO THE CTRC BY *ICRT* IF

5150 * THE POWER UP CONFIGURATION SWITCH IS SET TO THE 60HZ POSITION

5151

017.331		5152	VPARD60 EQU	*	
017.331	140	5153	DB	96	HORIZONTAL TOTAL
017.332	120	5154	DB	80	HORIZONTAL DISPLAYED
017.333	124	5155	DB	84	HORIZONTAL SYNC POSITION
017.334	010	5156	DB	8	HORIZONTAL SYNC WIDTH
017.335	031	5157	DB	25	VERTICAL TOTAL
017.336	004	5158	DB	4	VERTICAL TOTAL ADJUST
017.337	030	5159	DB	24	VERTICAL DISPLAYED
017.340	031	5160	DB	25	VERTICAL SYNC POSITION
017.341	000	5161	DB	0	INTERLACE MODE
017.342	011	5162	DB	9	MAXIMUM SCAN LINE
017.343	110	5163	DB	01001000B	FAST BLINK CURSOR STARTING AT LINE 8
017.344	010	5164	DB	8	CURSOR END AT LINE 8
017.345	000	5165	DB	0	MEMORY STARTING ADDRESS (MSB)
017.346	000	5166	DB	0	MEMORY STARTING ADDRESS (LSB)
017.347	000	5167	DB	0	CURSOR STARTING ADDRESS (MSB)
017.350	000	5168	DB	0	CURSOR STARTING ADDRESS (LSB)

5170 ** VPARD50 - VIDEO PARAMETER DATA FOR 50 HERTZ

5171 *

5172 * THE CONTENTS OF VPARD50 ARE COPIED TO THE CTRC BY *ICRT* IF

5173 * THE POWER UP CONFIGURATION SWITCH IS SET TO THE 50 HZ POSITION

5174

5175

017.351		5176	VPARD50 EQU	*	
017.351	140	5177	DB	96	HORIZONTAL TOTAL
017.352	120	5178	DB	80	HORIZONTAL DISPLAYED
017.353	124	5179	DB	84	HORIZONTAL SYNC POSITION
017.354	010	5180	DB	8	HORIZONTAL SYNC WIDTH
017.355	036	5181	DB	30	VERTICAL TOTAL
017.356	007	5182	DB	7	VERTICAL TOTAL ADJUST
017.357	030	5183	DB	24	VERTICAL DISPLAYED
017.360	033	5184	DB	27	VERTICAL SYNC POSITION
017.361	000	5185	DB	0	INTERLACE MODE
017.362	011	5186	DB	9	MAXIMUM SCAN LINE
017.363	110	5187	DB	01001000B	FAST BLINK CURSOR STARTING AT LINE 8
017.364	010	5188	DB	8	CURSOR END AT LINE EIGHT
017.365	000	5189	DB	0	MEMORY STARTING ADDRESS (MSB)
017.366	000	5190	DB	0	MEMORY STARTING ADDRESS (LSB)
017.367	000	5191	DB	0	CURSOR STARTING ADDRESS (MSB)
017.370	000	5192	DB	0	CURSOR STARTING ADDRESS (LSB)
		5193			
017.371	314	5194	DB	48H+43H+41H	MORAL SUPPORT
017.372	110 061 071	5195	DB	'H19'	FINAL CODE IDENTIFIER
017.375	122 116 102	5196	DB	52H,4EH,42H	CODE SUPPORT CODE
		5197			

5200 *** RAM ALLOCATIONS

100.000	5202	ORG	100000A	
100.000	5203	RAM EQU *		256 BYTE SCRATCHPAD RAM AREA
100.000	5204	INF DS 128		INPUT FIFO
000.000	5205	ERRNZ INF&1111111B		7 LSB MUST BE ZERO
000.000	5206	ERRNZ *-INF/256		FIFO MUST RESIDE IN ONE PAGE
000.200	5207	IFMAX EQU *-INF		
100.200	5208	OUTF DS 32		OUTPUT FIFO
000.000	5209	ERRNZ OUTF&111111B		5 LSB MUST BE ZERO
000.000	5210	ERRNZ *-OUTF/256		FIFO MUST RESIDE IN ONE PAGE
000.040	5211	OFMAX EQU *-OUTF		
	5212			
100.240	5213	IFP DS 1		INPUT FIFO POINTER
100.241	5214	IFC DS 1		INPUT FIFO COUNTER
000.177	5215	IFCMASK EQU IFMAX-1		
100.242	5216	OFF DS 1		OUTPUT FIFO POINTER
100.243	5217	OFC DS 1		OUTPUT FIFO COUNTER
000.037	5218	OFCMASK EQU OFMAX-1		
	5219			
100.244	5220	KBDFMIN EQU *		BEGINNING OF FIFO
100.244	5221	KBDF DS 16		KEYBOARD FIFO (8 ENTRIES)
100.264	5222	KBDFMAX EQU *		END OF FIFO
000.020	5223	KBDFL EQU KBDFMAX-KBDFMIN		KEYBOARD FIFO LENGTH
100.264	5224	KBDFP DS 2		KEYBOARD FIFO POINTER
	5226	*		VIDEO AND CURSOR POSITIONS
	5227	*		
100.266	5228	SHOME DS 2		SOFTWARE HOME POSITION
100.270	5229	CLSA DS 2		CURRENT LINE STARTING ADDRESS
100.272	5230	CURHP DS 1		CURSOR HORIZONTAL POSITION
100.273	5231	CURVP DS 1		CURSOR VERTICAL POSITION
	5232			
100.274	5233	CURAD DS 2		CURSOR ADDRESS (ACTUAL MEMORY ADDRESS)
077.377	5234	CURMAX EQU 77377A		MAXIMUM VALUE OF CURAD FOR CRTC (11 BITS)
	5235			
	5236	*		VIDEO PARAMETERS TO BE SENT TO THE CRTC BY *NMI*
	5237	*		
	5238			
100.276	5239	VI,VD DS 1		VERTICAL DISPLAYED VALUE
100.277	5240	VI,CSE DS 2		CURSOR START/OFF AND END VALUES
100.301	5241	VI,SA DS 2		VIDEO START ADDRESS (LIMIT 2K)
100.303	5242	VI,CA DS 2		CURSOR ADDRESS
	5243			
100.305	5244	CSA DS 2		CURSOR SAVED ADDRESS
	5245			
	5246	*		MODE AND STATUS DEFINITIONS
	5247	*		
100.307	5248	MODEA DS 1		MODE REGISTER A
000.200	5249	MA,RV EQU 10000000B		REVERSE VIDEO MODE
000.100	5250	MA,ICH EQU 01000000B		INSERT CHARACTER MODE

370,000	5291	ORG	370000A	
370,000	5292	VRAMS EQU	*	VIDEO RAM STARTING ADDRESS
007,377	5293	HOMAX EQU	377377A-VRAMS	MAXIMUM VIDEO ADDRESS MASK
370,000	5294	END		

```

ASSEMBLY COMPLETE
5294 STATEMENTS
0 ERRORS DETECTED
11184 BYTES FREE

```

CROSS-REFERENCE TABLE

		3424S	3425	4289S	4290	4308S	4309
A1M	000015	1370L	3008				
A1RM	005047	1382	1433L				
A1RM1	005056	1439L	1448				
A1SM	005015	1379	1399L				
A1SM1	005024	1405L	1418				
A2M	005073	1466L	3005				
A2RM	005134	1475	1519L				
A2RM1	005137	1523L	1532				
A2SM	005112	1472	1491L				
A2SM1	005115	1495L	1504				
AB.2SB	000004	49E	3383				
AB.5BW	000000	45E					
AB.6BW	000001	46E					
AB.7BW	000002	47E	3390				
AB.8BW	000003	48E	3393				
AB.BI	000020	68E					
AB.CTS	000020	76E					
AB.DCTS	000001	73E					
AB.DUSR	000002	74E					
AB.DLAB	000200	54E	3354				
AB.DR	000001	64E					
AB.DRLS	000010	75E					
AB.DSR	000040	77E					
AB.DTR	000001	57E	3399				
AB.EMS	000010	36E					
AB.EPS	000020	51E					
AB.ERDA	000001	33E	3397				
AB.ERLS	000004	35E					
AB.ETRE	000002	34E	289	478			
AB.FE	000010	67E					
AB.IID	000006	42E					
AB.IIP	000001	41E					
AB.LOOP	000020	61E					
AB.OR	000002	65E					
AB.OUT1	000004	59E					
AB.OUT2	000010	60E					
AB.PE	000004	66E					
AB.PEN	000010	50E					
AB.RDA1	000004	39E	427				
AB.RLSD	000200	78E					
AB.RTS	000002	58E	3399				
AB.SBRK	000100	53E	416	423			
AB.SP	000040	52E					
AB.THRE	000040	69E	447	4887			
AB.TREI	000002	40E	462				
AB.TSRE	000100	70E					
ACIN	005156	1548L	3014				
ACIN1	005170	1556L	1560				
ACE1	012247	3381	3384L				
ACE2	012265	3391	3394L				
ACLFT	005201	1577L	3020				
ACLFT1	005214	1586L	1588				
ACPR	005223	1605L	3054				
ACPR1	005257	1620	1624L				
ACPR2	005311	1636	1640L				
ACRT	005324	1660L	3017				
ACRT1	005337	1669L	1671				

PAGE 108

[illegible]

XREF 01.1

PAGE 109

AXMT25	016323	3060	4827L																
AXMTP	017247	3057	5055L																
BELL	000007	12E	1331																
BR110	012301	3411L																	
BR1200	012311	3415L																	
BR150	012303	3412L																	
BR1800	012313	3416L																	
BR19.2K	012331	3423L																	
BR2000	012315	3417L																	
BR2400	012317	3418L																	
BR300	012305	3413L																	
BR3600	012321	3419L																	
BR4800	012323	3420L																	
BR600	012307	3414L																	
BR7200	012325	3421L																	
BR9600	012327	3422L																	
BRTAB	012301	3367	3410E	3424															
BS	000010	13E	1334																
CAN	000030	19E	3657	3681	4251														
CDN	006346	1182	1550	1554	1557	2030L													
CLFT	007126	1188	1579	1583	1586	2147E													
CLR	010020	1191	2342	2358L															
CLSA	100270	2057	2062	2257	2262	2284	2716	2819	3577	3831	3903	3964	4050						
		4353	4419	4547	5229L														
CPM16	010040	2080	2280	2381L	2470														
CPR	007153	1253	2177L																
CR	000015	16E	909	909	1343	4860	5091												
CRT	007201	1185	1662	1666	1669	2201L													
CSA	100305	4232	4390	5244L															
CTLTAB	004354	1075	1330E	1349															
CTLTABL	000006	1076	1349E																
CTLTABW	000003	1077	1348E	1349															
CUP	007227	1179	1690	1694	1697	2230L													
CURAD	100274	1119	1143	2101	2106	2154	2159	2207	2212	2303	2308	3090	3124						
		3132	3578	3832	3862	3865	3904	3983	4051	4352	4428	4552	5233L						
CURHP	100272	1125	1142	1631	1754	2148	2153	2182	2201	2206	2717	3091	3694						
		3830	3854	3902	3956	4049	4230	4231	4349	4350	4391	4392	4421	4527					
		4533	4544	4571	5230L														
CURMAX	077377	4582	5234E																
CURVP	100273	1022	1615	1742	2030	2051	2063	2099	2179	2230	2251	2263	2301						
		2358	2678	2684	3113	3678	3908	4002	4231	4350	4392	4411	4569	5231L					
D25L	010153	2485L	4299																
DALF	010171	2504L																	
DC	010176	2522L	4284																
DEOL	010216	1278	1441	2544L															
DING	010223	1332	2559E	3715															
DKI	010226	1293	1997	2575L															
E25L	010237	2594L	4280																
EACR	010276	2007	2625L	4288															
EALF	010303	2643L	4287																
EAM	010310	1160	2660L																
EBD	010315	1240	2336	2677E															
ERD1	010352	2686	2700E																
ERL	010352	1256	2680	2702	2716L	2799													
ERL1	010364	2723L	2725																
EC	010371	2742L	3588	4303															
EDD	011014	1617	1633	2765L															
EDD1	011016	2766L	2771																

EBOZ	011027	2787	2773L															
EEL	011051	1250	2360	2805	2819L													
EQM	011061	1194	1967	2835L														
EHM	011065	1407	2852L															
EHSM	011076	1231	2870L	4282														
EICM	011107	1176	2002	2889L														
EICSER	000100	785	1174E	1175														
EID	007377	2326L	3026															
EII	011031	2789L	3029															
EKAM	011113	1166	1308	2906L	4286													
EKC	011120	2923L	4300															
EKI	011125	1290	1867	2940L														
ENSM	011136	1269	2957L	4285														
ELB	011143	1317	2978L															
ELBT	011172	2985	3002E	3075														
ELBTL	000027	2983	3075E															
ELBLW	000003	2984	3074E	3075														
EOL	011277	1209	2791	2796	3090L	3115												
ERM	011317	1206	2328	2333	3113L													
ERVM	011361	1259	1964	3147E														
ESC	000033	20E	603	607	628	741	745	764	768	776	780	802	1162					
		1346	1614	2178	3479	4955	4960	4978	4982	5005	5009	5027	5031					
ESCF	000200	227E	587	610	626	721	727	748	785	788	880	881	882					
		883	884	885	886	887	888	898	898	899	899	899	900	900				
		900	901	901	901	902	902	902	903	903	903	903	904	904	904			
		905	905	905	906	906	906	907	907	907	908	908	909	909				
ESCTAB	004134	996	1157E	1296														
ESCTABL	000054	997	1296E															
ESCTABW	000003	998	1295E	1296														
FCIF	011367	261	3171L	3249														
FCOF	012032	471	3209L															
FNCP	012070	3245L	3317	3656	3680	4073	4112	4250										
FNCP1	012073	3248L	3250															
FVKF	012107	264	1034	3274L														
FVNF1	012153	3281	3299L															
HOMAX	007377	2093	2295	4578	5293E													
HSMLC	100313	820	1026	1043	1062	2874	5285L											
HT	000011	14E	1337															
I.BITA	000313	155E	286	438	468	591	599	623	633	655	696	701	707					
		737	760	772	822	835	846	858	960	977	1057	4945	4967	4989				
		4995	5016															
I.BITB	000100	156E	286	438	468	591	599	623	633	655	696	701	707					
		737	760	772	822	835	846	858	960	977	1057	4945	4967	4989				
		4995	5016															
I.BITHA	000313	157E																
I.BITHB	000106	158E																
I.EXAF	000010	173E	312	537														
I.EXX	000331	174E	314	539														
I.IM1A	000355	159E	3590															
I.IM1B	000126	160E	3590															
I.JMP	000303	187E																
I.LDDA	000355	177E	3978	4046														
I.LDDB	000250	178E	3978	4046														
I.LDDRA	000355	179E	4034															
I.LDDRB	000270	180E	4034															
I.LDEDA	000355	175E	3123	3861	4015													
I.LDEDB	000133	176E	3123	3861	4015													
I.LDIA	000355	181E	3875															

CROSS REFERENCE TABLE

I.LDIB	000240	182E	3875						
I.LDIRA	000355	183E	3295	3547	3931				
I.LDIRB	000260	184E	3295	3547	3931				
I.NEGA	000355	161E	3093	3856	3910	3958	4004		
I.NEGR	000104	162E	3093	3856	3910	3958	4004		
I.OUT	000323	185E							
I.RESA	000313	169E	4971	5020					
I.RESB	000200	170E	4971	5020					
I.RESHA	000313	171E	4743	4760	4777	5143			
I.RESHB	000206	172E	4743	4760	4777	5143			
I.RET	000311	186E							
I.RETNA	000355	188E	413						
I.RETNB	000105	189E	413						
I.SETA	000313	163E	4949	4999					
I.SETB	000300	164E	4949	4999					
I.ETHA	000313	165E	2837	2872	2891				
I.ETHB	000306	166E	2837	2872	2891				
I.SHDA	000355	167E	3126						
I.SHDB	000122	168E	3126						
IACE	012204	3339	3354L	3587					
IACE0.5	012221	3362	3365L						
IB.BRK	000020	209E							
IB.CPLK	000010	197E	846						
IB.ESCF	000070	198E	623						
IB.ETRE	000010	199E	286						
IB.GRPH	000010	210E	2837	4743					
IB.HSM	000000	203E	2872	4760					
IB.ICM	000060	205E	2891	4777					
IB.IFF	000070	200E							
IB.KCB	000070	201E	599	633	655	737	760	772	858
IB.KPDA	000070	206E							
IB.KPDS	000060	207E	701	707					
IB.KSB	000000	202E	591	696	822	835	1057		
IB.ONLN	000030	208E	438	468					
IB.PWE	000000	211E	977						
IB.RV	000070	204E	4989	5143					
IB.XMTG	000010	213E	4945	4949	4967	4971			
IB.XMTR	000020	214E	4995	4999	5016	5020			
IB.XOFF	000040	212E	960						
ICRT	012333	3441E	3586						
ICRT0.5	012347	3447	3451L						
ICRT1	012353	3454L	3460						
IDT	012366	1228	3478L						
IFC	100241	442	964	1038	3171	3177	3179	3712	3727
IFCMSK	000177	3187	3720	5215E					5214L
IFCP	003120	262	957L	4255	4258				
IFCP0.5	003155	961	967	977L					
IFCP0.7	003213	989	996L						
IFCP0.9	003222	994	1000L						
IFCP1	003230	979	1005L						
IFCP1.1	003273	1034L	1040						
IFCP1.3	003303	1038L	1053						
IFCP1.5	003322	1035	1046L						
IFCP1.7	003341	1049	1055E						
IFCP1.8	003351	1059	1062L						
IFCP1.9	003364	1006	1067L						
IFCP2	003374	1068	1075L						
IFCP3	004007	1001	1083L						

CROSS-REFERENCE TABLE

IFCP4	004022	1071	1091L							
IFCP5	004045	1099	1104L							
IFCP6	004047	1094	1097	1102	1108L					
IFCP7	004124	1127	1141L							
IFF	000200	226E								
IFMAX	000200	443	965	1039	3713	5207E	5215			
IFP	100240	3180	3188	3718	5213L					
INF	100000	3182	3721	5204L	5205	5206	5207			
INIT	013001	237	3516	3525E						
INIT1	013114	3586L								
IR.A	000007	216E	286	623	701	707	960	977		
IR.B	000000	217E	4945	4949	4967	4971	4995	4999	5016	5020
IR.C	000001	218E	438	468	4989					
IR.D	000002	219E	599	633	655	737	760	772	858	
IR.E	000003	220E	591	696	822	835	846	1057		
IR.H	000004	221E								
IR.L	000005	222E								
IRAM	013001	3527	3542L							
KAE1	002350	580	879E	890						
KAE1L	000011	581	890E							
KAE1W	000002	582	889E	890						
KAE2	002372	687	897E	911						
KAE2L	000014	688	911E							
KAE2W	000005	689	910E	911						
KAE3	003066	839	919E	934						
KAE3L	000015	840	934E							
KAE3W	000002	841	933E	934						
KB.BRK	000004	125E	327							
KB.CHAR	000177	117E								
KB.CPLK	000002	124E								
KB.CTL	000200	118E	499	614						
KB.EX1	000013	119E	499							
KB.EX2	000014	120E								
KB.ONLN	000010	126E	319	324						
KB.RPT	000100	127E								
KB.SHFT	000001	123E								
KB.STB	000200	128E	485							
KBDF	100244	3286	3292	3549	5221L					
KBDFL	000020	3293	5223E							
KBDFMAX	100264	524	5222E	5223						
KBDFMIN	100244	3279	5220E	5223						
KBDFP	100264	522	531	3277	3285	3550	5224L			
KCE	001117	265	568L	1051						
KCE1	001133	579L								
KCE1.2	001204	600	606L							
KCE1.4	001214	596	610L							
KCE1.5	001220	585	613L							
KCE10	002015	713	717L							
KCE10.1	002130	761	767L							
KCE10.2	002140	757	772L							
KCE10.3	002154	773	779L							
KCE10.4	002164	753	783L							
KCE10.5	002203	722	791L							
KCE11	002214	725	801L							
KCE11.5	002235	807	810L							
KCE12	002246	684	817L							
KCE12.5	002263	823	828L							
KCE13	002266	818	835L							

XREF V1.1
PAGE 113

KCE13.5	002306	836	846L																
KCE14	002324	847	850	853	858L														
KCE2	001226	588	592	611	623L	749	786	789	795										
KCE2.3	001271	647	650L																
KCE2.7	001276	641	653L																
KCE3	001277	574	616	624	655L	719													
KCE4	001311	634	663L																
KCE4.3	001335	672	675L																
KCE4.7	001340	666	677L																
KCE5	001341	656	678L																
KCE6	001344	577	683L																
KCE7	002002	698	707L																
KCE8	002006	703	710L																
KCE9	002007	702	708	712L															
KE10.03	002062	738	744L																
KE10.07	002071	728	734	748L															
KP.1	000200	116E	490																
KP.2	000240	122E	316	482	492														
LF	000012	15E	1005	1340															
MA.	000004	5254E																	
MA.BRK	000040	270	337	420	5251E														
MA.CD	000020	2523	2743	4328	4504	5252E													
MA.GRPH	000002	1092	5255E																
MA.HSM	000001	1011	5256E																
MA.ICM	000100	756	784	1115	5250E														
MA.RV	000200	1110	1112	3152	5249E														
MA.RVP	000010	3152	5253E																
MAIN	000004	258	258L	3594															
MAIN.N	000016	264L	3248																
MAIN1	000037	273L																	
MAIN2	000066	282	287	291L															
MAINA	000045	279L	1032	1052															
MB.ACR	000020	2126	2626	4709	5263E														
MB.ALf	000010	2505	2644	3812	4726	5262E													
MB.ANSI	000040	595	640	665	732	752	805	987	2661	2853	4951	4974	5001						
		5023	5264E																
MB.CBLK	000001	2746	4325	4501	5259E														
MB.KFDA	000200	712	2907	4793	5266E														
MB.KFDS	000100	2958	4810	5265E															
MB.NOTK	000002	515	2924	3635	5260E														
MB.WRAP	000004	1130	2545	4607	5261E														
MI.	000040	5274E																	
MI.25L	000200	1738	2070	2268	2486	2596	2599	3672	4848	5276E									
MI.KID	000004	333	503	509	2576	2941	5271E												
MI.QNLN	000010	274	322	324	3748	5272E													
MI.PFF	000100	5275E																	
MI.PWE	000001	984	4482	5269E															
MI.XMTM	000002	5270E																	
MI.XOFF	000020	453	969	5273E															
MODEA	100307	269	328	338	421	755	783	1010	1088	1091	1109	1114	1864						
		1945	1994	2522	2524	2742	2744	4270	5248L										
MODEB	100310	514	594	639	664	697	731	751	804	986	1087	1129	1404						
		1438	1863	1993	2125	2745	2852	2854	3564	3568	3811	4269	4950	4973					
		5000	5022	5258L															
MODEI	100311	273	321	325	332	452	454	500	504	958	970	983	985						
		1737	2069	2267	2485	2487	2575	2577	2594	2601	2940	2942	3570	3671					
		3747	4481	4483	4847	5268L													
MODES	100312	3334	3337	3359	3559	3757	5278L												

[illegible]

PAGE 115

[illegible]

[illegible]

CROSS REFERENCE TABLE

PAGE 117

XMTC1	016367	4886L	4888									
XMTL	017001	4859	4911L	5086								
XMTL1	017033	4923	4933L									
XMTL1.1	017003	4912L	5038									
XMTL1.3	017043	4934	4939L									
XMTL2	017045	4931	4937	4940L								
XMTL3	017075	4952	4959L									
XMTL4	017104	4926	4965L									
XMTL5	017134	4975	4981L									
XMTL6	017141	4946	4957	4961	4968	4979	4986E					
XMTL7	017173	5002	5008L									
XMTL7.5	017202	4990	5014E									
XMTL8	017227	5024	5030L									
XMTL9	017234	4996	5006	5010	5017	5028	5033L					
XMTP	017252	1172	5060	5081L								
XMTP1	017262	5085L	5089									
XMTS	017302	4954	4959	4977	4981	5004	5008	5026	5030	5112L		
XMTS1	017303	5113L	5119									
XMTS2	017316	5116	5121L									
XOFF	000023	18E	450	1030								
XON	000021	17E	972	1044								
XRUM	017325	1262	1961	5138E								

14484 BYTES FREE

